

V1.0-2026-01-10

Residential All-In-One Energy Storage System

ESA 5-30kW

GW5.1-BAT-D-G20

GW8.3-BAT-D-G20

GW5.1-BAT-D-G21

GW8.3-BAT-D-G21

Solutions Manual

GOODWE

Copyright Statement

Copyright Statement

Copyright© GoodWe Technologies Co., Ltd. 2026. All rights reserved.

Without the authorization of GoodWe Technologies Co., Ltd., no part of this manual may be reproduced, distributed, or uploaded to third-party platforms such as public networks in any form.

Trademark Authorization

GOODWE and other GOODWE trademarks used in this manual are owned by GoodWe Technologies Co., Ltd. All other trademarks or registered trademarks mentioned in this manual belong to their respective owners.

NOTICE

Due to product version upgrades or other reasons, the content of this document is updated periodically. Unless otherwise agreed, the content of this document cannot replace the safety precautions on the product label. All descriptions in the document are for guidance only.

About This Manual

Overview

This document primarily introduces the product information, installation wiring, configuration and commissioning, troubleshooting, and maintenance content for the energy storage system composed of inverters, Battery system, and smart meters. Please read this manual carefully before installing and using the product to understand the product safety information and familiarize yourself with the product's functions and features. The document may be updated periodically; please obtain the latest version of the materials and more product information from the official website.

Applicable Model

The energy storage system includes the following products:

| Product Type | Product Information | Description |
|----------------|--|--------------------------------|
| Inverter | GW5K-ETA-G20 GW6K-ETA-G20 GW8K-ETA-G20 GW9.999K-ETA-G20 GW10K-ETA-G20 GW12K-ETA-G20 GW15K-ETA-G20 GW20K-ETA-G20 GW25K-ETA-G20 GW29.999K-ETA-G20 GW30K-ETA-G20 GW5K-BTA-G20 GW6K-BTA-G20 GW8K-BTA-G20 GW9.999K-BTA-G20 GW10K-BTA-G20 GW12K-BTA-G20 GW15K-BTA-G20 GW20K-BTA-G20 GW25K-BTA-G20 GW29.999K-BTA-G20 GW30K-BTA-G20 | Nominal output power: 5kW-30kW |
| Battery system | GW5.1-BAT-D-G20 GW5.1-BAT-D-G21 | Rated energy 5.12kWh |
| | GW8.3-BAT-D-G20 GW8.3-BAT-D-G21 | Rated energy 8.32kWh |

| Product Type | Product Information | Description |
|-------------------|---------------------|---|
| Electricity meter | GMK330 GM330 | A monitoring module in the energy storage system that can detect operating voltage, current, and other information within the system. |
| smart dongle | WiFi/LAN Kit-20 | Uploads system operating information to the monitoring platform via WiFi or LAN signals. |

Symbol Definition

| |
|--|
|  DANGER |
| Indicates a highly potential danger that, if not avoided, will result in death or serious injury. |
|  WARNING |
| Indicates a moderately potential danger that, if not avoided, may result in death or serious injury. |
|  CAUTION |
| Indicates a low potential danger that, if not avoided, may result in moderate or minor injury. |
| NOTICE |
| Emphasizes and supplements the content, and may also provide tips or tricks for optimizing product use, helping you solve a problem or save your time. |

Table of Contents

| | |
|---|----|
| 1 Safety Precautions | 10 |
| 1.1 General Safety | 10 |
| 1.2 Personnel requirements | 11 |
| 1.3 System Safety | 12 |
| 1.3.1 PV String Safety | 14 |
| 1.3.2 Inverter Safety | 15 |
| 1.3.3 Battery Safety | 16 |
| 1.3.4 Smart Meter Safety | 19 |
| 1.4 Safety Symbols and Certification Marks | 19 |
| 1.5 EU Declaration of Conformity | 21 |
| 1.5.1 Equipment with Wireless Communication Modules | 21 |
| 1.5.2 Equipment without Wireless Communication Modules (Except Battery) | 21 |
| 1.5.3 Battery | 22 |
| 2 System Introduction | 23 |
| 2.1 System Overview | 23 |
| 2.2 Product Overview | 36 |
| 2.2.1 Residential All-in-One System | 36 |
| 2.2.2 Smart Meter | 42 |
| 2.2.3 Smart dongle | 43 |
| 2.3 Supported Grid Types | 44 |
| 2.4 System Working Mode | 44 |

| | |
|---|----|
| 2.5 Features | 54 |
| 3 Check and Storage | 59 |
| 3.1 Check Before Receiving | 59 |
| 3.2 Deliverables | 59 |
| 3.2.1 Inverter Deliverables | 59 |
| 3.2.2 Batteries Deliverables | 63 |
| 3.2.2.1 Expansion Base Deliverables | 63 |
| 3.2.2.2 Wall-Mount Bracket Deliverables | 65 |
| 3.2.3 Smart Meter Deliverables GM330&GMK330 | 66 |
| 3.2.3.1 Accessory List | 66 |
| 3.3 Storage | 67 |
| 4 Installation | 69 |
| 4.1 Installation Requirements | 69 |
| 4.1.1 Installation Environment Requirements | 69 |
| 4.1.2 Installation Space Requirements | 71 |
| 4.1.3 Tool Requirements | 73 |
| 4.2 Equipment Handling | 75 |
| 4.3 Installation equipment | 76 |
| 4.4 Installing the Smart Meter | 81 |
| 5 System Wirings | 83 |
| 5.1 System Wiring Electrical Block Diagram | 84 |
| 5.2 Detailed System Wiring Diagram | 88 |

| | |
|--|-----|
| 5.3 Preparing Materials..... | 98 |
| 5.3.1 Preparing Breakers..... | 99 |
| 5.3.2 Preparing Cables..... | 103 |
| 5.4 Connecting the PE cable..... | 106 |
| 5.5 Connecting the PV Cable..... | 107 |
| 5.6 Connecting the Battery Cable..... | 109 |
| 5.7 Connecting the AC Cable..... | 111 |
| 5.8 Connecting the Meter Cable..... | 113 |
| 5.9 Connecting the Inverter Communication Cable..... | 115 |
| 6 System Commissioning..... | 121 |
| 6.1 Check Before Power ON..... | 121 |
| 6.2 Power ON..... | 121 |
| 6.3 Installing the Protective Cover..... | 124 |
| 6.4 Indicators..... | 124 |
| 6.4.1 Inverter Indicators..... | 124 |
| 6.4.2 Battery Indicators..... | 127 |
| 6.4.3 Smart Meter Indicators GM330&GMK330..... | 127 |
| 6.4.3.1 Indicator Description..... | 127 |
| 6.4.4 Smart Dongle Indicator..... | 128 |
| 7 System Commissioning..... | 131 |
| 7.1 Setting Inverter Parameters via App..... | 131 |
| 7.1.1 Downloading and Installing SEMS+ App..... | 131 |

| | |
|--|-----|
| 7.2 Monitoring Power Station via SEMS+ WEB | 132 |
| 8 Maintenance | 133 |
| 8.1 Power OFF the System | 133 |
| 8.2 Removing the Equipment | 134 |
| 8.3 Disposing of the Equipment | 135 |
| 8.4 Routine Maintenance | 135 |
| 8.5 Fault | 139 |
| 8.5.1 Viewing Fault/Alarms Information | 139 |
| 8.5.2 Fault Information and Troubleshooting | 139 |
| 8.5.2.1 Inverter Fault | 141 |
| 8.5.2.1.1 Troubleshooting (Fault Code F01-F40) | 141 |
| 8.5.2.1.2 Troubleshooting (Fault Code F41-F80) | 159 |
| 8.5.2.1.3 Troubleshooting (Fault Code F81-F121) | 168 |
| 8.5.2.1.4 Troubleshooting (Fault Code F122-F163) | 180 |
| 8.5.2.1.5 Troubleshooting (Fault Phenomenon) | 189 |
| 8.5.2.2 Battery Fault | 207 |
| 9 Technical parameter | 226 |
| 9.1 Inverter Parameters | 226 |
| 9.2 Battery Technical Data | 274 |
| 9.3 Smart Meter Technical Data | 276 |
| 9.3.1 GM330 | 276 |
| 9.3.2 GMK330 | 277 |

| | |
|--|-----|
| 9.4 Smart Dongle Technical Data | 279 |
| 9.4.1 WiFi/LAN Kit-20 | 279 |
| 10 Appendix | 280 |
| 10.1 FAQ | 280 |
| 10.1.1 How to conduct auxiliary detection for smart meters/CT? | 280 |
| 10.1.2 How to Upgrade the Device Version | 280 |
| 10.2 Abbreviations | 281 |
| 10.3 Explanation of Terms | 284 |
| 10.4 Battery SN code meaning | 285 |
| 11 Contact Information | 287 |

1 Safety Precautions

The safety precautions information contained in this document must always be followed when operating the device.

WARNING

The device has been strictly designed and tested in accordance with safety regulations, but as an electrical device, before performing any operations on the device, relevant safety instructions must be followed. Improper operation may lead to serious injury or property damage.

1.1 General Safety

NOTICE

- Due to product version upgrades or other reasons, the document content will be updated periodically. Unless otherwise agreed, the document content cannot replace the safety precautions on product labels. All descriptions in the document are for guidance only.
- Please read this document carefully before installing the device to understand the product and precautions.
- All operations of the device must be performed by professional and qualified electrical technicians who are familiar with the relevant standards and safety regulations at the project location.
- When operating the device, use insulated tools and wear personal protective equipment to ensure personal safety. When handling electronic components, wear anti-static gloves, anti-static wrist straps, anti-static clothing, etc., to protect the device from electrostatic damage.
- Unauthorized disassembly or modification may cause device damage, and such damage is not covered by the warranty.
- Device damage or personal injury caused by not installing, using, or configuring the device according to the requirements of this document or the corresponding user manual is beyond the manufacturer's liability. For more product warranty information, please obtain it through the official website:
<https://en.goodwe.com/warrantyrelated.html>.

1.2 personnel requirements

NOTICE

To ensure safety, compliance, and efficiency throughout the entire process of equipment transportation, Installation, wiring, operation, and maintenance, operations must be performed by qualified personnel.

1. Qualified personnel include:
 - Personnel who have mastered knowledge of equipment working principles, system structure, risks and hazards, and have received professional operation training or possess extensive practical experience.
 - Personnel who have received relevant technical and safety training, possess certain operational experience, are aware of potential dangers specific tasks may pose to themselves, and can take protective measures to minimize risks to themselves and others.
 - Qualified electrical technicians meeting the regulatory requirements of the country/region.
 - Personnel holding a degree in electrical engineering/an advanced diploma in electrical discipline or equivalent/possessing professional qualifications in the electrical field, with at least 2/3/4 years of experience in testing and supervision work using electrical equipment safety standards.
2. Personnel involved in special tasks such as electrical work, work at heights, and special equipment operation must hold valid qualification certificates as required by the equipment's location.
3. Medium-voltage equipment operation must be performed by certified high-voltage electricians.
4. Equipment and component replacement is only permitted to be performed by authorized personnel.

1.3 System Safety



- Before performing electrical connections, disconnect all upstream switches of the device to ensure it is powered off. Working on live circuits is strictly prohibited, as it may lead to hazards such as electric shock.
- To prevent personal injury or equipment damage caused by working on live circuits, a circuit breaker must be added to the voltage input side of the device.
- All operations including transportation, storage, installation, operation, use, and maintenance must comply with applicable laws, regulations, standards, and specifications.
- The specifications of cables and components used for electrical connections must comply with local laws, regulations, standards, and specifications.
- Use the cable connectors provided in the package to connect the device cables. If other models of connectors are used, any resulting equipment damage is not within the manufacturer's liability.
- Ensure all cables of the device are correctly connected, securely fastened, and free from looseness. Improper wiring may cause poor contact or damage the equipment.
- The equipment's protective grounding wire must be firmly connected.
- To protect the equipment and its components from damage during transportation, ensure that transport personnel are professionally trained. Record the operation steps during transportation and keep the equipment balanced to avoid dropping.
- The equipment is heavy. Assign personnel according to the equipment's weight to prevent it from exceeding the human lifting capacity and causing injury from falling.
- Ensure the equipment is placed stably and not tilted. Equipment tipping over may cause equipment damage and personal injury.

 **WARNING**

- During equipment installation, avoid having the terminals bear weight, as this may cause terminal damage.
- If the cable is subjected to excessive tension, it may lead to poor connections. When wiring, leave a certain length of cable slack before connecting it to the equipment's terminal ports.
- Cables of the same type should be bundled together. Different types of cables should be routed at least 30mm apart and must not be intertwined or cross-routed.
- Using cables in high-temperature environments may cause insulation aging and damage. Maintain a distance of at least 30mm between cables and heat-generating components or the periphery of heat source areas.

1.3.1 PV String Safety

WARNING

- Ensure the component frame and mounting system are properly grounded.
- After connecting the DC cables, ensure the cable connections are tight and secure with no looseness. Improper wiring may cause poor contact or high impedance, and damage the inverter.
- Use a multimeter to measure the positive and negative poles of the DC cables to ensure correct polarity, with no reverse connection; and that the voltage is within the permissible range.
- Use a multimeter to measure the DC cables to ensure correct polarity, with no reverse connection; the voltage should be lower than the maximum DC input voltage. Damage caused by reverse connection and overvoltage is not covered by the equipment manufacturer's warranty.
- The PV string output does not support grounding. Before connecting the PV string to the inverter, ensure the minimum insulation resistance to ground of the PV string meets the minimum insulation resistance requirement ($R = \text{Max. Input Voltage (V)} / 30\text{mA}$).
- Do not connect the same PV string to multiple inverters, as this may damage the inverters.
- The PV modules used with the inverter must comply with IEC 61730 Class A standards.
- When the PV string input voltage or input current is high, it may cause the inverter output power to derate.

1.3.2 Inverter Safety

WARNING

- Ensure the voltage and frequency at the grid connection point comply with the inverter's grid-connection specifications.
- It is recommended to install protective devices such as circuit breakers or fuses on the AC side of the inverter. The rating of the protective device must be greater than 1.25 times the maximum AC output current of the inverter.
- If the inverter triggers an arc fault alarm less than 5 times within 24 hours, the alarm can be cleared automatically. After the 5th arc fault alarm, the inverter will shut down for protection. The inverter can resume normal operation only after the fault is cleared.
- If a battery is not configured in the photovoltaic system, it is not recommended to use the BACK-UP function, as it may cause a system power outage risk.
- Grid voltage and frequency fluctuations may cause the inverter output power to derate.

1.3.3 Battery Safety

DANGER

- Before operating any devices in the system, ensure that the devices are powered off to avoid the risk of electric shock. During device operation, strictly adhere to all safety precautions in this manual and the safety labels on the devices.
- Do not disassemble, modify, or repair the battery without official authorization from the device manufacturer. Otherwise, it may cause electric shock or device damage, and any losses incurred are beyond the manufacturer's liability.
- Do not impact, pull, drag, squeeze, or step on the device, and do not place the battery in fire, as the battery may explode.
- Do not place the battery in high-temperature environments. Ensure there are no heat sources near the battery and that it is not exposed to direct sunlight. If the ambient temperature exceeds 60°C, it may cause a fire.
- Do not use the battery if it has obvious defects, cracks, damage, or other conditions. Battery damage may lead to electrolyte leakage.
- Do not move the battery system while it is operating. If battery replacement or addition is needed, contact the after-sales service center.
- Battery short circuits may cause personal injury. The instantaneous high current from a short circuit can release a large amount of energy, which may lead to a fire.
- To protect the battery pack and its components from damage during transportation, ensure that transport personnel are professionally trained. Record the operating steps during transportation and keep the device balanced to avoid dropping.
- The battery device is heavy. Assign personnel according to the device's weight to prevent it from exceeding the weight range that can be manually handled, which could cause injury to personnel.

 **WARNING**

- Battery current may be affected by factors such as temperature, Humidity, weather conditions, etc., which may cause current limiting and affect load capacity.
- If the battery cannot start, contact the after-sales service center as soon as possible. Otherwise, the battery may be permanently damaged.
- Regularly inspect and maintain the battery according to its maintenance requirements.
- Ensure that the battery system is not damaged during transportation and storage. Ensure that the device is placed stably and not tilted, as tipping may cause device damage and personal injury.

Emergency Response Measures

- Battery electrolyte leakage
If a battery module leaks electrolyte, avoid contact with the leaking liquid or gas. Electrolyte is corrosive and contact may cause skin irritation and chemical burns. If accidental contact with the leaked substance occurs, take the following actions:
 - inhalation: Evacuate from the contaminated area and seek medical help immediately.
 - Eye contact: Rinse with clean water for at least 15 minutes and seek medical help immediately.
 - Skin contact: Wash the affected area thoroughly with soap and water and seek medical help immediately.
 - Ingestion: Induce vomiting and seek medical assistance immediately.
- Fire
 - When the battery temperature exceeds 150°C, there is a risk of fire. A battery fire may release toxic and harmful gases.
 - To prevent fire, ensure carbon dioxide or water fire extinguishing equipment is available near the device.
 - When extinguishing a fire, do not use ABC dry powder fire extinguishers. Firefighters must wear protective clothing and self-contained breathing apparatus.
- Battery triggers fire protection
For batteries equipped with optional fire protection functionality, after the fire protection function is triggered, perform the following actions:
 - Immediately cut off the main power switch to ensure no current flows through the battery system.

- Conduct a preliminary visual inspection of the battery for any damage, deformation, leakage, or unusual odor. Check the battery casing, connectors, and cables.
- Use a temperature sensor to detect the battery and its ambient temperature to ensure there is no risk of overheating.
- Isolate and label the damaged battery, and dispose of it properly according to local regulations.

1.3.4 Smart Meter Safety

WARNING

If the grid voltage fluctuation exceeds 265V, long-term overvoltage operation may cause damage to the meter. It is recommended to add a fuse with a rated current of 0.5A on the voltage input side of the meter to protect it.


1.4 Safety Symbols and Certification Marks

DANGER

- After equipment installation, labels and warning signs on the enclosure must remain clearly visible. Do not cover, alter, or damage them.
- The following enclosure warning label descriptions are for reference only. Please refer to the actual labels used on the equipment.

| No. | Symbol | Meaning |
|-----|---|---|
| 1 |  | Potential hazard exists during equipment operation. Please take protective measures when operating the equipment. |
| 2 |  | High voltage hazard. High voltage is present during equipment operation. Please ensure the equipment is powered off before performing any operations. |

| No. | Symbol | Meaning |
|-----|---|--|
| 3 |  | The inverter surface is at high temperature. Do not touch during operation to avoid burns. |
| 4 |  | Use the equipment properly. There is a risk of explosion under extreme conditions. |
| 5 |  | Battery contains flammable materials. Beware of fire. |
| 6 |  | The equipment contains corrosive electrolyte. Avoid contact with leaked electrolyte or volatile gases. |
| 7 |  | Delayed discharge. After powering off the equipment, please wait 5 minutes for it to discharge completely. |
| 8 |  | Keep the equipment away from open flames or ignition sources. |
| 9 |  | Keep the equipment out of reach of children. |
| 10 |  | Do not extinguish with water. |
| 11 |  | Please read the product manual carefully before operating the equipment. |
| 12 |  | Personal protective equipment must be worn during installation, operation, and maintenance. |

| No. | Symbol | Meaning |
|-----|---|--|
| 13 |  | This equipment must not be disposed of as household waste. Please dispose of it according to local laws and regulations, or return it to the manufacturer. |
| 14 |  | Grounding point. |
| 15 |  | Recycling symbol. |
| 16 |  | CE certification mark. |
| 17 |  | TUV mark. |
| 18 |  | RCM mark. |

1.5 EU Declaration of Conformity

1.5.1 Equipment with Wireless Communication Modules

Equipment with wireless communication modules sold in the European market must comply with the following directives:

- Radio Equipment Directive 2014/53/EU (RED)
- Restrictions of Hazardous Substances Directive 2011/65/EU and (EU) 2015/863 (RoHS)
- Waste Electrical and Electronic Equipment 2012/19/EU
- Registration, Evaluation, Authorization and Restriction of Chemicals (EC) No 1907/2006 (REACH)

1.5.2 Equipment without Wireless Communication Modules (Except Battery)

Equipment without wireless communication modules that can be sold in the European market meets the requirements of the following directives:

- Electromagnetic compatibility Directive 2014/30/EU (EMC)
- Electrical Apparatus Low Voltage Directive 2014/35/EU (LVD)
- Restrictions of Hazardous Substances Directive 2011/65/EU and (EU) 2015/863 (RoHS)
- Waste Electrical and Electronic Equipment 2012/19/EU
- Registration, Evaluation, Authorization and Restriction of Chemicals (EC) No 1907/2006 (REACH)

1.5.3 Battery

Batteries sold in the European market must comply with the following directives:

- Electromagnetic compatibility Directive 2014/30/EU (EMC)
- Electrical Apparatus Low Voltage Directive 2014/35/EU (LVD)
- Battery Directive 2006/66/EC and Amending Directive 2013/56/EU
- Waste Electrical and Electronic Equipment 2012/19/EU
- Registration, Evaluation, Authorization and Restriction of Chemicals (EC) No 1907/2006 (REACH)

For more EU Declarations of Conformity, please visit the [official website](#).

2 System Introduction

2.1 System Overview

The integrated residential storage solution combines devices such as an inverter, Battery, Smart Meter, and smart communication stick. In a photovoltaic system, it converts solar energy into electricity to meet household power needs. The energy IoT devices in the system manage electrical appliances by identifying the overall power situation, thereby intelligently managing power for supplying loads, storing to the Battery, or exporting to the grid.

WARNING

- The energy storage system is not suitable for connecting devices that rely on stable power supply, such as life-sustaining medical equipment. Ensure that system power failure does not cause personal injury.
- If the residential storage inverter operates at high temperatures or under BMS current limiting conditions, the battery charging power may be restricted, potentially causing system overvoltage and triggering overvoltage protection.
- The inverter only supports GoodWe brand batteries specified in this manual. If no battery is connected, it can only operate in grid-tied mode and must be installed on the base provided in the package.
- In microgrid scenarios, it is recommended that the PV open-circuit voltage of the residential storage inverter be $< 0.85 * \text{PV maximum input voltage}$ to prevent system overvoltage and triggering of overvoltage protection under harsh operating conditions.
- In microgrid scenarios, ensure that the over-frequency power reduction point of the grid-tied inverter matches that of the residential storage inverter.
- If output power limitation is required for the grid-tied inverter, please connect a meter or CT device separately.
- Ensure the over-frequency power reduction curve of the grid-tied inverter is configured as follows:
 - Set the endpoint power to 0% P_n
 - Set the response delay time to 0, and disable the hysteresis function
- In a fully off-grid inverter system, if the battery remains under low sunlight or rainy conditions for an extended period without timely recharging, it may lead to

 **WARNING**

over-discharge, causing battery performance degradation or damage. To ensure long-term stable system operation, avoid completely draining the battery.

Recommended measures are as follows:

- During off-grid operation, set a minimum SOC protection threshold. It is recommended to set the off-grid battery SOC lower limit to 30%.
- When the SOC approaches the protection threshold, the system will automatically enter load limitation or protection mode.
- If there is insufficient sunlight for several consecutive days and the battery SOC is too low, promptly replenish the battery using external energy sources (such as a generator or grid-assisted charging).
- Regularly check the battery status to ensure it operates within a safe range.
- It is recommended to perform a full charge and discharge cycle every six months to calibrate SOC accuracy.
- Due to product version upgrades or other reasons, document content is updated periodically. For the compatibility relationship between inverters and IoT products, please refer to:
https://en.goodwe.com/Ftp/EN/Downloads/User%20Manual/GW_Compatibility-list-of-GoodWe-inverters-and-IoT-products-EN.pdf
- For detailed networking and wiring schemes for various scenarios, please refer to: [5.2.Detailed System Wiring Diagram\(Page 88\)](#).

When the energy storage system is in off-grid mode, it can normally supply the following loads:

BACK-UP Port Off-grid Load Capacity Specifications

| | | | | |
|---|--|--|----------------------|------------------|
| Inverter Model | GW5K-ETA-G20 GW6K-ETA-G20 GW8K-ETA-G20 GW9.999K-ETA-G20 GW10K-ETA-G20 GW12K-ETA-G20 GW15K-ETA-G20 GW20K-ETA-G20 GW5K-BTA-G20 GW6K-BTA-G20 GW8K-BTA-G20 GW9.999K-BTA-G20 GW10K-BTA-G20 GW12K-BTA-G20 GW15K-BTA-G20 GW20K-BTA-G20 | GW25K-ETA-G20 GW29.999K-ETA-G20 GW30K-ETA-G20 GW25K-BTA-G20 GW29.999K-BTA-G20 GW30K-BTA-G20 | | |
| Load Type | Single-phase | Three-phase | Single-phase | Three-phase |
| Single Motor Load Rated Power (kVA) | 1.1 | 3.3 | 2.2 | 6.6 |
| Total Rated Power of Multiple Motor Loads (kVA) | $0.4 \cdot P_n / 3$ | $0.4 \cdot P_n$ | $0.4 \cdot P_n / 3$ | $0.4 \cdot P_n$ |
| Capacitive Load (kVA) | $0.33 \cdot P_n / 3$ | $0.33 \cdot P_n$ | $0.33 \cdot P_n / 3$ | $0.33 \cdot P_n$ |
| Half-wave Load (kW) | 2 | - | 3 | - |


| Device Type | model | Description |
|-----------------|--|---|
| hybrid inverter | GW5K-ETA-G20 GW6K-ETA-G20 GW8K-ETA-G20 GW9.999K-ETA-G20 GW10K-ETA-G20 GW12K-ETA-G20 GW15K-ETA-G20 GW20K-ETA-G20 GW25K-ETA-G20 GW29.999K-ETA-G20 GW30K-ETA-G20 GW5K-BTA-G20 GW6K-BTA-G20 GW8K-BTA-G20 GW9.999K-BTA-G20 GW10K-BTA-G20 GW12K-BTA-G20 GW15K-BTA-G20 GW20K-BTA-G20 GW25K-BTA-G20 GW29.999K-BTA-G20 GW30K-BTA-G20 | <ul style="list-style-type: none"> • Can be connected to GoodWe AC charging pile. • Supports generator control, generator charging the battery. If a generator needs to be connected, please use GMK330 or GM330 Smart Meter. |

| Device Type | model | Description |
|----------------|--|--|
| Battery system | GW5.1-BAT-D-G20 GW5.1-BAT-D-G21 GW8.3-BAT-D-G20 GW8.3-BAT-D-G21 | <ul style="list-style-type: none"> • Battery modules of different models can be mixed. • The system supports 5-96kWh, meeting the use of different power and energy matching. • Battery heating film is optional; only models configured with heating film can enable the "battery heating" function. Batteries without heating film should not be used in low-temperature environments, otherwise it may cause the device to fail to operate. • GW5.1-BAT-D-G20, GW8.3-BAT-D-G20, GW5.1-BAT-D-G21, GW8.3-BAT-D-G21 When mixed, the battery heating function is unavailable. • If the system has a split expansion requirement, please ensure that the BMS and DCDC software versions are V04 or above. |
| Smart Meter | Inverter built-in meter <hr/> GMK330 (purchased from GoodWe) <hr/> GM330 (purchased from GoodWe) | <ul style="list-style-type: none"> • Built-in meter: Please use the CT shipped with the box to connect to the inverter. <ul style="list-style-type: none"> ◦ CT ratio is 120A:40mA. ◦ When the inverter built-in meter does not meet the use, you can contact dealers to purchase GMK330 or GM330 Smart Meter. • GMK330: CT cannot be replaced, CT ratio is 120A:40mA • GM330: CT can be purchased from GoodWe or on your own, CT ratio is nA:5A. |

| Device Type | model | Description |
|--------------|-----------------|--|
| Smart dongle | WiFi/LAN Kit-20 | <ul style="list-style-type: none"> Use Bluetooth signal to configure device parameters locally, view device operation information, and upload system operation information to the monitoring platform via WiFi or LAN. Please ensure that the firmware version of the Smart dongle is 06 or above. |

Microgrid Scenario

When a grid-tied inverter is connected to the hybrid inverter's BACK-UP port, it constitutes a Microgrid Scenario.



ESA20NET0017


| Device Type | model | Description |
|-----------------|--|---|
| hybrid inverter | GW5K-ETA-G20 GW6K-ETA-G20 GW8K-ETA-G20 GW9.999K-ETA-G20 GW10K-ETA-G20 GW12K-ETA-G20 GW15K-ETA-G20 GW20K-ETA-G20 GW25K-ETA-G20 GW29.999K-ETA-G20 GW30K-ETA-G20 GW5K-BTA-G20 GW6K-BTA-G20 GW8K-BTA-G20 GW9.999K-BTA-G20 GW10K-BTA-G20 GW12K-BTA-G20 GW15K-BTA-G20 GW20K-BTA-G20 GW25K-BTA-G20 GW29.999K-BTA-G20 GW30K-BTA-G20 | <ul style="list-style-type: none"> • In a microgrid scenario, only one hybrid inverter is supported in the system. • In a microgrid scenario, connection to a generator is not supported. |

| Device Type | model | Description |
|----------------|--|--|
| Battery system | GW5.1-BAT-D-G20 GW5.1-BAT-D-G21 GW8.3-BAT-D-G20 GW8.3-BAT-D-G21 | <ul style="list-style-type: none"> • Different models of battery modules can be mixed and used. • The system supports 5-96kWh, meeting different power and energy matching requirements. • Battery heating film is optional. The "Battery Heating" function can only be enabled for models configured with the heating film. Batteries without the heating film should not be used in low-temperature environments, otherwise the equipment may fail to operate. • GW5.1-BAT-D-G20, GW8.3-BAT-D-G20, GW5.1-BAT-D-G21, GW8.3-BAT-D-G21 The battery heating function is unavailable when these models are mixed. • If the system requires expansion with split units, ensure the BMS and DCDC software version is V04 or above. |
| Smart Meter | Inverter Built-in Meter GMK330 (Purchase from GoodWe) GM330 (Purchase from GoodWe) | <ul style="list-style-type: none"> • Built-in meter: Use the CT shipped with the inverter to connect to the inverter. <ul style="list-style-type: none"> ◦ CT ratio is 120A:40mA. ◦ If the inverter's built-in meter is insufficient, contact your dealer to purchase a GMK330 or GM330 Smart Meter. • GMK330: CT cannot be replaced. CT ratio is 120A:40mA. • GM330: CT can be purchased from GoodWe or elsewhere. CT ratio is nA:5A. |

| Device Type | model | Description |
|-----------------------|-----------------|--|
| Smart dongle | WiFi/LAN Kit-20 | <ul style="list-style-type: none"> • Uses Bluetooth signal for local configuration of device parameters and viewing device operation information. Uses WiFi or LAN to upload system operation information to the monitoring platform. • Ensure the firmware version of the Smart Communication Dongle is 06 or above. |
| grid-tied PV inverter | - | <ul style="list-style-type: none"> • GoodWe brand grid-tied inverters are recommended. Third-party grid-tied inverters are supported. • In a microgrid scenario, ensure the grid-tied inverter's rated output power \leq the hybrid inverter's rated output power. • When the microgrid system is in grid-connected mode, if power limitation is required, ensure: <ul style="list-style-type: none"> ◦ For the hybrid inverter, set it in the Grid-connected Power Limitation interface of the SEMS+ App. For the grid-tied inverter, set it according to the actual tools used. ◦ To ensure the grid-tied inverter can continue generating power, adjust the hybrid inverter's output power in the Microgrid Mode interface of the SEMS+ App. <p>Note: The output power control precision varies among different grid-tied inverters. Set the grid-connected power limitation parameter values according to the actual situation.</p> |

Coupled Scenario

When a grid-tied inverter is connected to the hybrid inverter's GRID port, it constitutes a Coupled Scenario.



ESA20NET0018

| Device Type | model | Description |
|-----------------|--|--|
| hybrid inverter | GW5K-ETA-G20 GW6K-ETA-G20 GW8K-ETA-G20 GW9.999K-ETA-G20 GW10K-ETA-G20 GW12K-ETA-G20 GW15K-ETA-G20 GW20K-ETA-G20 GW25K-ETA-G20 GW29.999K-ETA-G20 GW30K-ETA-G20 GW5K-BTA-G20 GW6K-BTA-G20 GW8K-BTA-G20 GW9.999K-BTA-G20 GW10K-BTA-G20 GW12K-BTA-G20 GW15K-BTA-G20 GW20K-BTA-G20 GW25K-BTA-G20 GW29.999K-BTA-G20 GW30K-BTA-G20 | <ul style="list-style-type: none"> • Can be connected to GoodWe AC charging piles. • Supports generator control and generator charging the battery. If connecting a generator, please use the GMK330 or GM330 Smart Meter. |

| Device Type | model | Description |
|----------------|--|--|
| Battery system | GW5.1-BAT-D-G20 GW5.1-BAT-D-G21 GW8.3-BAT-D-G20 GW8.3-BAT-D-G21 | <ul style="list-style-type: none"> • Different models of battery modules can be mixed. • The system supports 5-96kWh, meeting different power and energy matching requirements. • Battery heating film is optional. The "Battery Heating" function can only be enabled for models configured with the heating film. Batteries without the heating film should not be used in low-temperature environments, as this may prevent the device from operating. • GW5.1-BAT-D-G20, GW8.3-BAT-D-G20, GW5.1-BAT-D-G21, GW8.3-BAT-D-G21The battery heating function is unavailable when these models are mixed. • If the system requires split-type expansion, please ensure the BMS and DCDC software version is V04 or higher. |
| Smart Meter | Inverter Built-in Meter | <ul style="list-style-type: none"> • Built-in Meter: Please use the CT shipped with the box to connect to the inverter. <ul style="list-style-type: none"> ◦ CT ratio is 120A:40mA ◦ If the inverter's built-in meter does not meet usage requirements, you can contact dealers to purchase the GMK330 or GM330 Smart Meter. • GMK330: CT cannot be replaced; CT ratio is 120A:40mA. • GM330: CT can be purchased from GoodWe or separately; CT ratio is nA:5A. |
| | GMK330 (Purchase from GoodWe) | |
| | GM330 (Purchase from GoodWe) | |


| Device Type | model | Description |
|-----------------------|-----------------|--|
| Smart dongle | WiFi/LAN Kit-20 | <ul style="list-style-type: none"> • Uses Bluetooth signals for local configuration of device parameters and viewing device operation information. Uses WiFi or LAN to upload system operation information to the monitoring platform. • Please ensure the Smart Communication Dongle's firmware version is 06 or higher. |
| grid-tied PV inverter | - | <ul style="list-style-type: none"> • GoodWe brand grid-tied inverters are recommended, but third-party grid-tied inverters are supported. • In coupling scenarios, ensure the grid-tied inverter's rated output power \leq the hybrid inverter's rated output power. • When the coupled system is in grid-connected mode and power limitation is required, please ensure: The hybrid inverter must be configured via the grid-connected power limit interface in the SEMS+ App. Configure the grid-tied inverter according to the actual tool used. <p>Note: The output power control precision varies among different grid-tied inverters. Please set the grid-connected power limit parameter value according to the actual situation.</p> |

2.2 Product Overview

2.2.1 Residential Three-Phase All-in-One Unit

Residential Three-Phase All-in-One Unit:

The residential three-phase all-in-one unit employs a blind-plug stacking connection method and integrates the Inverter and Battery units through a modular design.




ESA20DSC0007

The energy storage system supports Battery capacity expansion. The total Battery capacity is determined by the number and specifications of Battery modules. Configuration must strictly adhere to the constraints specified in this chapter. Overall system configuration description:

| Mounting Method | Total Batteries | Expansion Groups | Single Group Stacking |
|---|-----------------|------------------|---|
| Floor Installation | ≤12 units | ≤3 groups | Free-standing: ≤4 units Wall-mounted: ≤6 units |
| Wall-mounted Installation (5kWh models) | ≤9 units | ≤3 groups | ≤3 units |
| Wall-mounted Installation (8kWh and models mixed-stacked with them) | ≤6 units | ≤3 groups | ≤2 units |


Note: **Expansion Groups × Single Group Stacking Quantity ≤ Total System Batteries**

Wall-Mounted Installation




Floor-Mounted Installation

- Wall-Adjacent Installation




- Free-Standing Installation (Away from Wall)




Cluster Expansion Installation

- Floor-Mounted Installation




- Wall-Mounted Installation



Inverter:

The Inverter controls and optimizes the energy flow within the photovoltaic system through its integrated energy management system. It can supply power generated by the PV system to loads, store it in the Battery, or export it to the grid.




ESA20DSC0010

| No. | Component/Silkscreen | Description |
|-----|---|--|
| 1 | indicator | Indicates the operating status of the inverter. |
| 2 | heat sink | Heat dissipation for the inverter. |
| 3 | Connector | Power and communication ports for connecting the inverter to the battery. |
| 4 | Smart Communication Stick Connection Port | <ul style="list-style-type: none"> • Can connect to smart communication sticks, such as WiFi/LAN communication modules. Please select the module type according to actual needs. • Supports connecting a USB flash drive for local inverter software version upgrade. |
| 5 | Ventilation valve | - |
| 6 | STS Communication Interface | Reserved |
| 7 | PV Input Terminals | <p>Only for ETA models. BTA models do not have PV input terminals.</p> <ul style="list-style-type: none"> • Can connect to DC input cables from PV modules. • The number of PV input terminals is as follows: <ul style="list-style-type: none"> ◦ GW5K-ETA-G20, GW6K-ETA-G20, GW8K-ETA-G20, GW6K-EHA-G20: 3 ◦ GW9.999K-ETA-G20, GW10K-ETA-G20, GW12K-ETA-G20, GW15K-ETA-G20, GW20K-ETA-G20, GW25K-ETA-G20, GW29.999K-ETA-G20, GW30K-ETA-G20: 4 |
| 8 | BACK-UP Port | Connect AC cables to connect critical loads or grid-tied inverters. |
| 9 | Battery Mounting Holes | Secure the inverter and the battery. |

| No. | Component/Silkscreen | Description |
|-----|--------------------------------|---|
| 10 | Communication Port | Can connect communication cables for load control, CT, RS485, Remote Shutdown/Rapid Shutdown, DRED (Australia)/RCR (Europe), etc. |
| 11 | Carrying Handle Mounting Holes | Used for installing the carrying handle. Used when moving the inverter. |
| 12 | DC Switch | Only for ETA models. BTA models do not have a DC switch. Controls the connection or disconnection of the DC input. |
| 13 | GRID Port | Connect AC cables to connect the inverter to the grid. |
| 14 | Grounding terminal | Connect the chassis protective ground wire. |

Battery:

The Battery system can store and release electrical energy according to the requirements of the photovoltaic energy storage system. Both the input and output ports of this energy storage system are high-voltage direct current.




ESA20DSC0004

| No. | Component | Description |
|-----|--------------------------------------|--|
| 1 | Connector | Power and Communication Port for connecting battery to battery, and battery to inverter. |
| 2 | Anti-tip bracket mounting holes | Used for securing the battery to the wall. |
| 3 | Multifunction button indicator light | <ul style="list-style-type: none"> Indicates the battery operating status. Battery black start function: When there is no PV power generation in the photovoltaic system and the grid is abnormal, the inverter cannot operate normally; you can press and hold the multifunction button for 2 seconds to start the battery system, activate the inverter, putting the inverter into off-grid operation mode, with the battery discharging to power the loads. Battery power-off function: Press and hold the multifunction button for >5 seconds to power off the battery system. |
| 4 | Battery isolation switch | Battery power input/output switch. |
| 5 | Inter-battery mounting holes | Used for securing between two battery units. |
| 6 | heat sink | Battery heat dissipation |
| 7 | Battery lifting holes | Used for hoisting the battery. When stacking more than three batteries, hoisting tools must be used for installation. |
| 8 | Battery or inverter mounting holes | Used for securing between batteries or between the inverter and battery. |
| 9 | Carrying handle mounting holes | Used for installing the carrying handle. Used during manual battery handling. |

2.2.2 Smart Meter

The Smart Meter measures and monitors electrical data in the photovoltaic energy storage system, such as: voltage, current, frequency, Power Factor, power, etc.




| No. | model | Applicable Scenarios |
|-----|--------|---|
| 1 | GM330 | <p>CT can be purchased from GoodWe or separately. CT ratio requirement: nA: 5A</p> <ul style="list-style-type: none"> nA: CT primary side input current, n range is 200-5000 5A: CT secondary side output current |
| 2 | GMK330 | <p>CT is shipped with the meter. CT ratio:</p> <ul style="list-style-type: none"> 120A: 40mA |

2.2.3 smart dongle

The smart dongle is mainly used for real-time transmission of various power generation data from inverters to remote monitoring platforms, and for connecting the smart dongle via the Xiaogu Cloud Window+ App for proximal device debugging.


WiFi/LAN Kit-20



Smart dongle 0006

| No. | model | Signal Type | Applicable Scenario |
|-----|-----------------|----------------------|--|
| 1 | WiFi/LAN Kit-20 | WiFi, LAN, Bluetooth | Can upload system operation information to the monitoring platform via WiFi or LAN signals |

2.3 Supported Grid Types




TNNET0003

2.4 System Working Mode

Self-consumption

- The basic operating mode of the system.
- PV generation first supplies power to the loads, excess energy charges the battery, and any remaining energy is sold to the grid. When PV generation cannot meet the

load demand, the battery supplies power to the loads; when the battery power is also insufficient to meet the load demand, the grid supplies power to the loads.



SLG00NET0009


Backup Mode

- Recommended for use in areas with unstable grids.
- When the grid fails, the inverter switches to off-grid working mode, and the battery discharges to supply power to the loads, ensuring uninterrupted power for the BACK-UP Loads. When the grid is restored, the inverter switches its working mode back to grid-connected operation.
- To ensure the battery SOC is sufficient to maintain normal system operation during off-grid periods, the system will charge the battery using PV or by purchasing electricity from the grid to the backup power SOC during grid-connected operation. If purchasing electricity from the grid to charge the battery, please ensure compliance with local grid laws and regulations.


Back-up Mode ①

Charging from grid: disabled

Back-up SOC: 60%



SLG00NET0002




TOU Mode


In compliance with local laws and regulations, buy and sell electricity during different time periods based on the difference between peak and valley grid electricity prices. For example: During valley price periods, set the battery to charging mode to purchase electricity from the grid for charging; during peak price periods, set the battery to discharging mode to supply power to the loads via the battery.

TOU Mode①

PV: Charge battery in priority



SLG00NET0004



SLG00NET0005


Delayed Charging Mode

- Suitable for areas with grid-connected power output limits.
- Setting a peak power limit can use PV generation exceeding the grid connection limit to charge the battery; or setting a PV charging period to utilize PV generation for charging the battery during that period.

Smart Charging ①

PV > Peak Limit

Switch to Charge: enabled/disabled




SLG00NET0006


Smart Charging ②

PV < Peak Limit

Switch to Charge: enabled




SLG00NET0007



Demand Control Mode

- Primarily applicable to commercial and industrial scenarios.
- When the total load power consumption exceeds the electricity quota within a short period, battery discharge can be used to reduce the portion of consumption exceeding the quota.
- When the battery SOC is lower than the reserved SOC for demand control, the system purchases electricity from the grid based on the time period, load consumption, and peak purchase power limit.




Off-grid Mode

NOTICE

When the inverter is not connected to the battery system, do not operate in pure off-grid mode.

When the grid fails, the inverter switches to off-grid working mode.

- During the day, PV generation first supplies power to the loads, and excess energy charges the battery.
- At night, the battery discharges to supply power to the loads, ensuring uninterrupted power for the BACK-UP Loads.



SLG00NET0012

2.5 Features

NOTICE

Please refer to the actual product configuration for specific features.

AFCI

The inverter integrates an AFCI circuit protection device, which detects arc faults (arc fault) and quickly cuts off the circuit when detected, thereby preventing electrical fires.

Causes of arc generation:

- Damage to connector connections in the photovoltaic system.
- Incorrect or damaged cable connections.

- Aging of connectors and cables.

Fault handling methods:

1. When the inverter detects an arc occurrence, the fault type can be viewed through the App.
2. If the inverter triggers a fault less than 5 times within 24 hours, after waiting for 5 minutes, the machine will automatically restore grid connection protection. After the 5th arc fault, the fault must be cleared before the inverter can operate normally. For specific operations, please refer to the "SEMS+ App User Manual".

| model | Label | Description |
|--|------------------------|--|
| GW5K-ETA-G20 GW6K-ETA-G20 GW8K-ETA-G20 | AFCI: F-I-AFPE-1-2/1-2 | F (Full coverage): Full coverage of inverter PV input ports I (Integrated): Integrated inside the inverter AFPE (arc fault protection equipment): Combines AFD and AFI two types of arc fault detection functions 1: One pair of PV input ports (PV+, PV-) connects to one string of PV input 2/1: One arc fault detection channel has 2 MPPT inputs; one arc fault detection channel has 1 MPPT input; 2: There are 2 arc fault detection channels |

| model | Label | Description |
|--|------------------------|---|
| GW9.999K-ETA-G20 GW10K-ETA-G20 GW12K-ETA-G20 GW15K-ETA-G20 GW20K-ETA-G20 | AFCI: F-I-AFPE-1-2/2-2 | F (Full coverage): Full coverage of inverter PV input ports I (Integrated): Integrated inside the inverter AFPE (arc fault protection equipment): Combines AFD and AFI two types of arc fault detection functions 1: One pair of PV input ports (PV+, PV-) connects to one string of PV input 2/2: Each arc fault detection channel has 2 MPPT inputs; 2: There are 2 arc fault detection channels |
| GW25K-ETA-G20 GW29.999K-ETA-G20 GW30K-ETA-G20 | AFCI: F-I-AFPE-1-2/4-2 | F (Full coverage): Full coverage of inverter PV input ports I (Integrated): Integrated inside the inverter AFPE (arc fault protection equipment): Combines AFD and AFI two types of arc fault detection functions 1: One pair of PV input ports (PV+, PV-) connects to one string of PV input 2/4: One arc fault detection channel has 2 MPPT inputs; one arc fault detection channel has 4 MPPT inputs; 2: There are 2 arc fault detection channels |

Three-Phase Unbalanced Output

Both the grid connection end and the BACK-UP end of the inverter support three-phase unbalanced output, and each phase can be connected to loads of different power. The maximum output power per phase for different models is shown in the table below:

| No. | model | Single-Phase Maximum Output Power |
|-----|--|-----------------------------------|
| 1 | GW5K-ETA-G20 GW5K-BTA-G20 | 2.5kW |
| 2 | GW6K-ETA-G20 GW6K-BTA-G20 | 3kW |
| 3 | GW8K-ETA-G20 GW8K-BTA-G20 | 4kW |
| 4 | GW9.999K-ETA-G20 GW9.999K-BTA-G20 | 5kW |
| 5 | GW10K-ETA-G20 GW10K-BTA-G20 | 5kW |
| 6 | GW12K-ETA-G20 GW12K-BTA-G20 | 6kW |
| 7 | GW15K-ETA-G20 GW15K-BTA-G20 | 7.3kW |
| 8 | GW20K-ETA-G20 GW20K-BTA-G20 | 7.3kW |
| 9 | GW25K-ETA-G20 GW25K-BTA-G20 | 11kW |
| 10 | GW29.999K-ETA-G20 GW29.999K-BTA-G20 | 11kW |
| 11 | GW30K-ETA-G20 GW30K-BTA-G20 | 11kW |

Rapid Shutdown (RSD)

In a Rapid Shutdown system, the Rapid Shutdown transmitter and receiver are used together to achieve rapid system shutdown. The receiver maintains component output by receiving signals from the transmitter. The transmitter can be external or built into the inverter. In emergency situations, by enabling an external triggering device, the transmitter can be stopped, thereby shutting down the components.

- External transmitter
 - Transmitter models: GTP-F2L-20, GTP-F2M-20
<https://en.goodwe.com/Ftp/Installation-instructions/RSD2.0-transmitter.pdf>
 - Receiver models: GR-B1F-20, GR-B2F-20

https://en.goodwe.com/Ftp/EN/Downloads/User%20Manual/GW_RSD-20_Quick-Installation-Guide-POLY.pdf

- Built-in transmitter
 - External triggering device: External switch
 - Receiver models: GR-B1F-20, GR-B2F-20

https://en.goodwe.com/Ftp/EN/Downloads/User%20Manual/GW_RSD-20_Quick-Installation-Guide-POLY.pdf

3 Check and Storage

3.1 Check Before Receiving

Before receiving the product, please carefully check the following:




1. Check if the outer packaging is damaged, such as deformation, holes, cracks, or other signs that could cause damage to the equipment inside the box. If damaged, do not open the packaging and contact your dealer.
2. Check if the device model is correct. If it does not match, do not open the packaging and contact your dealer.









3.2 deliverables








 **WARNING**


Check if the type and quantity of the delivered items are correct, and if there is any damage to the appearance. If there is any damage, please contact your dealer. After removing the delivered items from the packaging, do not place them on rough, uneven, or sharp surfaces to avoid paint chipping.


3.2.1 Inverter Deliverables

| Component | Description | Component | Description |
|---|---------------------------|--|----------------------------|
|  | Inverter x 1 |  | Decorative cover top x 1 |
|  | Decorative cover left x 1 |  | Decorative cover right x 1 |


| Component | Description | Component | Description |
|---|--|--|--|
|  <p>or</p>  | <p>AC terminal kit x 2</p> <ul style="list-style-type: none"> • AC wiring terminal x 2 • PIN terminal x N <ul style="list-style-type: none"> ◦ 5-20kW: <ul style="list-style-type: none"> ▪ 4mm² x 5 ▪ 6mm² x 5 ▪ 10mm² x 5 ▪ 16mm² x 5 ◦ 25-30kW: <ul style="list-style-type: none"> ▪ 10mm² x 5 ▪ 16mm² x 5 ▪ 25mm² x 5 |  | <p>Handle x 2</p> |
|  | <p>OT grounding terminal x 1</p> |  | <p>6PIN communication terminal x 2</p> |
|  | <p>2PIN communication terminal x 2</p> |  | <p>PIN terminal x 16</p> |
|  | <p>CT connection cable x 1</p> |  | <p>CT x 1</p> |

| Component | Description | Component | Description |
|---|---------------------------|--|--|
|  | Battery base x 1 |  | Adjustable feet x 4 |
|  | Anti-tip bracket x 4 |  | M5*16 screw x 9 |
|  | M5*60 expansion screw x 4 |  | Drilling template paper x 2 |
|  | |  | PV terminal unlocking tool x N N: China region x 0; Other regions x 1. |



| Component | Description | Component | Description |
|-----------|---|--|-------------------------|
| | <p>PV terminal and PV terminal anti-tamper cover</p> <ul style="list-style-type: none"> • GW5K-ETA-G20 , GW6K-ETA-G20 , GW8K-ETA-G20, GW6K-EHA-G20: 3 • GW9.999K-ETA-G20, GW10K-ETA-G20, GW12K-ETA-G20, GW15K-ETA-G20, GW20K-ETA-G20, GW25K-ETA-G20, GW29.999K-ETA-G20, GW30K-ETA-G20: 4 • GW5K-BTA-G20, GW6K-BTA-G20, GW8K-BTA-G20, GW9.999K-BTA-G20, GW10K-BTA-G20, GW12K-BTA-G20, GW15K-BTA-G20, GW20K-BTA-G20, GW25-BTA-G20, GW29.999K-BTA-G20, GW30K-BTA-G20: 0 |  | <p>Smart dongle x 1</p> |

| Component | Description | Component | Description |
|---|---------------------------|---|---|
|  | Product documentation x 1 |  | Manual transfer switch (Australia only) x 1 |

3.2.2 Batteries Deliverables

| Part | Description | Part | Description |
|--|------------------|---|-----------------|
|  | Battery x 1 |  | M5*16 screw x 2 |
|  | Silicone cap x 2 | - | - |







Battery rack (optional)




| Component | Description | Component | Description |
|---|----------------------|---|-------------------------|
|  | Mounting bracket x 2 |  | M10 expansion screw x 6 |
|  | M10 screw x 4 | - | - |

3.2.2.1 Battery Expansion Kit Deliverables (Optional)


NOTICE


The system supports 5-96kWh. A single stack can accommodate up to 6 batteries. For scenarios requiring more energy, needing to reduce single-stack height due to installation constraints, or other expansion needs, please contact GoodWe or your distributor to purchase a battery expansion kit.

| Part | Description | Part | Description |
|---|-----------------------|--|------------------------------|
|  | Base x 1 |  | locking bracket x 4 |
|  | M5 Screw x 7 |  | M6 Expansion Screw x 4 |
|  | Adjustable Feet x 4 |  | OT Grounding Terminal x 1 |
|  | Terminal resistor x 1 |  | Battery Decorative Cover x 1 |

| Part | Description | Part | Description |
|---|---|--|---|
|  | Drilling Template Paper x 2 |  | Battery Cluster Expansion Harness x 1 |
|  | PIN terminal x 8 |  | Battery Cluster Expansion Positive Connection Harness x 1 |
|  | Battery Cluster Expansion Negative Connection Harness x 1 |  | Battery Cluster Expansion Network Cable x 1 |
|  | Silicone Cap x 2 |  | Handle x 2 |
|  | Hex Key x 1 |  | Product Documentation x 1 |





3.2.2.2 Wall-Mount Bracket Deliverables (Optional)

| Component | Description | Component | Description |
|---|------------------------|---|------------------------|
|  | Wall-mount bracket x 2 |  | M6 expansion screw x 4 |

| Component | Description | Component | Description |
|---|---------------------|-----------|-------------|
|  | M5 fixing screw x 4 | - | - |

3.2.3 Smart Meter Delivery Set GM330&GMK330

3.2.3.1 Attachment List

| Part | Description | Part | Description |
|---|--|---|--|
|  | Smart meter x1 GMK330: CT x 3; GMK360: CT x 6; GM330: CT x 0. |  | 2PIN communication terminal x1 Applicable to GM330. |
|  | 6PIN communication terminal x1 Applicable to GM330. |  | 7PIN communication terminal x1 Applicable to GM330. |
|  | Meter communication terminal Applicable to GMK330/GMK360. |  | RS485 communication terminal x 1 |
|  | 2PIN terminal and RJ45 terminal adapter cable x 1 |  | screwdriver x1 |

| Part | Description | Part | Description |
|---|--|---|------------------------------|
|  | PIN terminal GMK330/GMK360: x 5 ; GM330: x 6. |  | Product documentation x 1 |

3.3 Storage

- If the inverter has been stored for more than two years or remains unused for more than 6 months after installation, it is recommended to have it inspected and tested by qualified personnel before putting it into operation.
- To ensure the good electrical performance of the internal electronic components of the inverter, it is recommended to power it on every 6 months during storage. If it has not been powered on for more than 6 months, it is recommended to have it inspected and tested by qualified personnel before putting it into operation.
- To ensure battery performance and service life, it is recommended to avoid long-term idle storage. Prolonged storage may cause the battery to deep discharge, leading to irreversible chemical degradation, capacity decay, or even complete failure, therefore timely use is advised. If the battery requires long-term storage, please maintain it according to the following requirements:

NOTICE

[1] The storage time is calculated from the SN date on the battery outer packaging. After exceeding the storage cycle, charge-discharge maintenance is required. (Battery maintenance time = SN date + charge-discharge maintenance cycle). For the method to view the SN date, refer to: [10.4.Battery SN Code Meaning\(Page 285\)](#).

[2] After the charge-discharge maintenance is qualified, if there is a Maintaining Label on the outer box, please update the maintenance information on the Maintaining Label. If there is no Maintaining Label, please record the maintenance time and battery SOC yourself and keep the data properly to facilitate the preservation of maintenance records.

| Battery Model | Initial SOC Range for Battery Storage | Recommended Storage Temperature | Charge/Discharge Maintenance Cycle ^[1] | Battery Maintenance Method ^[2] |
|-----------------|---------------------------------------|---------------------------------|---|---|
| GW5.1-BAT-D-G20 | 35~45% | 0~35°C | -20~35°C, 12 months 35~45°C, 6 months | For maintenance methods, please consult the dealer or after-sales service center. |
| GW8.3-BAT-D-G20 | | | | |
| GW5.1-BAT-D-G21 | | | | |
| GW8.3-BAT-D-G21 | | | | |

Packaging Requirements:

Ensure the outer packaging box is not removed and the desiccant inside the box is not missing.

Environmental Requirements:

1. Ensure the device is stored in a cool place, avoiding direct sunlight.
2. Ensure the storage environment is clean, with appropriate temperature and humidity ranges, and free from condensation. If condensation is observed on the device ports, do not install the device. Battery storage humidity range: 5%-95%.
3. Ensure the device is stored away from flammable, explosive, corrosive, and other hazardous materials.

Stacking Requirements:

1. Ensure the stacking height and orientation of the device comply with the instructions on the packaging box label.
2. Ensure there is no risk of the stacked devices tipping over.

4 Installation

DANGER

When performing equipment installation and electrical connections, please use the delivery items shipped with the box. Otherwise, any resulting equipment damage will not be covered under warranty.

4.1 Installation Requirements

4.1.1 Installation Environment Requirements


NOTICE

- Inverter operating temperature range: -35°C to 60°C .
- GW5.1-BAT-D-G20, GW8.3-BAT-D-G20: Charging temperature range: -18°C to 55°C ; Discharging temperature range: -20°C to 55°C . If installed in an environment below -18°C , the battery will be unable to recharge and restore energy after being depleted, leading to battery undervoltage protection.
- GW5.1-BAT-D-G21, GW8.3-BAT-D-G21: Charging temperature range: 2°C to 55°C ; Discharging temperature range: -20°C to 55°C . If installed in an environment below 2°C , the battery will be unable to recharge and restore energy after being depleted, leading to battery undervoltage protection.

1. The equipment must not be installed in flammable, explosive, corrosive, or similar environments.
2. The temperature and humidity of the installation environment must be within a suitable range.
3. The installation location must be out of reach of children and avoid areas where it is easily touched.
4. The equipment surface may become hot during operation to prevent burns.
5. The equipment must be installed away from direct sunlight, rain, snow accumulation, and similar conditions. It is recommended to install it in a sheltered location. If necessary, a sunshade can be constructed.
6. The installation space must meet the equipment's ventilation, heat dissipation, and

operational space requirements.

7. The installation environment must satisfy the equipment's protection rating. The Inverter, battery, and smart communication stick are suitable for indoor and outdoor installation; the meter is suitable for indoor installation.
8. The installation height of the equipment should facilitate operation and maintenance, ensuring the equipment indicator lights, all labels are easy to view, and the wiring terminals are easy to operate.
9. The installation altitude of the equipment must be lower than the maximum operating altitude.
10. For outdoor installation in salt damage areas, please consult the equipment manufacturer. Salt damage areas mainly refer to regions within 500m of the coast. The affected area is related to factors such as sea breeze, precipitation, and terrain.
11. The equipment generates noise during operation. The installation location should be away from areas highly sensitive to noise, such as residential living areas, schools, and hospitals. This is to prevent the noise generated during equipment operation from disturbing people living in the nearby environment.
12. Keep away from strong magnetic field environments to avoid electromagnetic interference. If there are radio stations or wireless communication equipment below 30MHz near the installation location, please install the equipment according to the following requirements:
 - Inverter: Add ferrite cores with multiple windings or add low-pass EMI filters at the DC input lines or AC output lines of the Inverter; or ensure the distance between the Inverter and the wireless electromagnetic interference equipment exceeds 30m.
 - Other equipment: Ensure the distance between the equipment and the wireless electromagnetic interference equipment exceeds 30m.




ESA20INT0011

4.1.2 Installation Space Requirements

When installing equipment in the system, a certain amount of space should be reserved around the equipment to ensure sufficient space for installation and heat dissipation.


- Installing a CT requires using shielded network cable of CAT 5E or above, with a cable distance not exceeding 30 meters.
- The RS485 twisted-pair shielded cable for communication between the inverter and the meter should not exceed 100 meters in length.

Communication Cable Length



ESA20INT0012

Installation Space




ESA20INT0018

4.1.3 Tool Requirements



NOTICE

During installation, it is recommended to use the following installation tools. If necessary, other auxiliary tools may be used on-site.

Installation Tools

| Tool Type | Description | Tool Type | Description |
|---|-----------------------------------|--|---|
|  | diagonal plier |  | RJ45 connector crimping tool |
|  | wire stripper |  | Level bar |
|  | open-end wrench |  | PV terminal crimping tool PV-CZM-61100 |
|  | hammer drill (drill bit Φ12mm) |  | torque wrench M4, M5, M6, M10 |
|  | rubber hammer |  | socket wrench |
|  | marker pen |  | multimeter Range ≤ 1000V |
|  | heat shrink tubing |  | heat gun |
|  | cable tie |  | vacuum cleaner |


Personal Protective Equipment

| Tool Type | Description | Tool Type | Description |
|---|-------------------------------------|---|--------------|
|  | Insulated gloves, protective gloves |  | Dust mask |
|  | goggle |  | Safety shoes |

4.2 Equipment Handling

CAUTION

- During operations such as transportation, handling, and installation, the laws, regulations, and relevant standards of the country or region must be complied with.
- Before installation, the equipment needs to be moved to the installation site. To avoid personal injury or equipment damage during the moving process, please note the following:
 1. Based on the equipment weight, arrange a sufficient number of personnel to avoid the equipment exceeding the human lifting capacity and causing injury.
 2. Please wear safety gloves to prevent injury.
 3. Ensure the equipment remains balanced during movement to prevent it from falling.
 4. The battery system can be transported to the installation site using lifting methods.
 5. When using lifting methods to move the equipment, please use flexible slings or straps. The load-bearing capacity per single strap must meet the following requirements:
 - GW5.1-BAT-D-G20, GW5.1-BAT-D-G21 $\geq 180\text{KG}$
 - GW8.3-BAT-D-G20, GW8.3-BAT-D-G21 $\geq 240\text{KG}$



ESA20INT0013

4.3 Equipment Installation

⚠ CAUTION

- When drilling holes, ensure the drilling location avoids water pipes, cables, etc., inside the wall to prevent danger.
- When drilling holes, please wear safety goggles and a dust mask to avoid inhaling dust into the respiratory tract or getting it into the eyes.
- The inverter is installed above the battery; do not install the battery above the inverter.
- When installing the battery system, ensure it is level and secure. When placing the battery base, battery, and inverter, confirm that the hole positions on the upper and lower layers are aligned; the anti-tipping bracket should be vertical and tightly attached to the ground, wall, or battery system surface.
- When using an impact drill to make holes, use cardboard or other coverings to shield the battery system to prevent foreign objects from entering the device and causing damage.
- When installing on the wall, to ensure the safety of your life and property, be sure to assess the wall's load-bearing capacity.

NOTICE

- The battery must be installed on a base, which can be floor-mounted or installed on a mounting bracket.
- For floor installation, a maximum of 4 batteries can be stacked when placed away from the wall, and a maximum of 6 batteries can be stacked when placed against the wall.
- The maximum stacking quantity when using a mounting bracket is as follows:
 - Same energy capacity stacking:
 - GW5.1-BAT-D-G20, GW5.1-BAT-D-G21: Maximum of 3 units.
 - GW8.3-BAT-D-G20, GW8.3-BAT-D-G21: Maximum of 2 units.
 - Mixed energy capacity stacking:
 - GW5.1-BAT-D-G20, GW5.1-BAT-D-G21: When mixed stacking, the system supports a maximum of 3 units per group.
 - GW8.3-BAT-D-G20, GW8.3-BAT-D-G21 and models mixed and stacked with them: The system supports a maximum of 2 units per group.
- When installed against a wall, the base, mounting bracket, and the top battery must be secured to the wall using an anti-tip bracket.
- When marking drilling positions for bracket installation, have one person hold the base steady while another uses a marker to mark the drilling spots.
- When installing the battery and inverter, remove the protective cover from the blind-mate connector before stacking.

Wall-Mounted Installation

Step 1: Install the base onto the mounting bracket.

Step 2: Place the mounting bracket flush against the wall. Ensure the bracket is positioned stably and observe the spirit level in the center of the base.


Step 3: After adjusting the bracket's position and level, use a marker to mark the drilling points. Once marked, remove the bracket. (A: PACK fixing holes; B: Bracket fixing holes.)

Step 4: Drill holes and install expansion bolts.

1. Use an impact drill to drill the holes.
2. Clean the holes.
3. Use a rubber mallet to install the expansion bolts into the holes.
4. Use a hex wrench to tighten the nut clockwise to expand the bolt.

5. Rotate the nut counterclockwise to remove it.
6. Use a torque screwdriver to secure the anti-tip bracket to the wall.

Step 5: Use a hex wrench to secure the mounting bracket to the wall.



ESA20INT0003

Floor Installation

Wall-Adjacent Installation


Step 1: Install the adjustable feet onto the bottom of the base and secure the anti-tip bracket to the base.

Step 2: Place the base 50-60mm away from the wall, keeping it parallel to the wall. Observe the spirit level in the center of the base. If the bubble is not centered, use the adjustable feet to level it.


Step 3: After adjusting the base's position and level, use a drilling template to mark the drilling points. Once marked, remove the base. (A: PACK fixing holes; B: Bracket fixing holes.)

Step 4: Use an impact drill to drill the holes and clean them.

Step 5: Use a Phillips screwdriver to secure the anti-tip bracket to the wall.



a: Base fixing surface; b: Wall fixing surface.



ESA20INT0004

Freestanding Installation (Away from Wall)


Step 1: Install the adjustable feet onto the bottom of the base. Observe the spirit level in the center of the base. If the bubble is not centered, use the adjustable feet to level it.

Step 2: After adjusting the base's position and level, secure the freestanding installation bracket to the base. Choose a suitable location to mark the drilling points. Once marked, remove the base.

Step 3: Drill holes and install expansion bolts.

1. Use an impact drill to drill the holes.
2. Clean the holes.
3. Use a rubber mallet to install the expansion bolts into the holes.
4. Use a hex wrench to tighten the nut clockwise to expand the bolt.
5. Rotate the nut counterclockwise to remove it.
6. Use a torque screwdriver to secure the anti-tip bracket (for freestanding) to the floor.

Step 4: Use a hex wrench to secure the base to the floor.



ESA20INT0015

Installing the Battery and Inverter

NOTICE

When installing against the wall, the topmost battery must be secured to the wall using an anti-tipping bracket.

Step 1: Remove the protective cover from the blind-mate connector on the bottom of the inverter or battery.

Step 2: (Optional) Install the handle, then stack the battery onto the base.

If installing more than 3 batteries, use lifting equipment.


Step 3: Tighten the screws between the battery and the base, or between batteries.

If installing multiple batteries, repeat **Step 1** and **Step 2** to complete the installation of all batteries. The number of stacked batteries must comply with the "[2.2.1.System Overall Configuration Description\(Page 36\)](#)".


Step 4: (Optional) Secure the topmost battery to the wall using an anti-tip bracket.

Step 5: Install the inverter or battery decorative cover.

- All-in-One Installation: Lift the inverter, align it, and stack it on top of the battery. Tighten the screws between the inverter and the battery. If the system is an all-in-one configuration, the installation is now complete.
- Split-Type Expansion: Repeat the battery installation steps. After completing the electrical connections, place the battery decorative cover on top of the battery and tighten the side screws.



a: PACK fixing surface; b: Wall fixing surface.




4.4 Installing the Smart Meter

⚠ WARNING

In areas with lightning hazard, if the meter cable length exceeds 10m and the cable is not routed using grounded metal conduit, it is recommended to install external lightning protection devices.

GM330&GMK330



Step 1: Pull out the buckle at the bottom of the smart meter.

Step 2: Place the smart meter on the positioning rail and reattach the buckle to the

meter.

5 System Wirings

DANGER

- The installation, routing, and connection of cables must comply with local laws, regulations, and code requirements.
- All operations during electrical connection, as well as the specifications of cables and components used, must meet local legal and regulatory requirements.
- Before performing electrical connections, disconnect the DC switch and AC output switch of the equipment to ensure it is powered off. Live working is strictly prohibited, as it may lead to hazards such as electric shock.
- Cables of the same type should be bundled together and arranged separately from different types of cables. Intertwining or cross-routing is prohibited.
- If cables are subjected to excessive tension, poor connections may result. During wiring, leave a certain length of cable slack before connecting to the inverter terminals.
- When crimping terminals, ensure the conductor part of the cable makes full contact with the terminal. Do not crimp the cable insulation together with the terminal, as this may cause the equipment to malfunction, or lead to overheating and damage to the inverter terminal block due to unreliable connections during operation.
- The inverter is not tested to AS/NZS 4777.2:2020 for combinations and/or multiple phase inverter combinations so that combinations should not be used.
- Unused cable entry holes and ports (including communication ports) must be reliably sealed using the dedicated terminal blocks or plugs provided in the accessory kit. Failure to do so may result in the following risks:
 - Electric Shock Hazard: Open electrical ports may allow direct contact with live parts, leading to electric shock accidents.
 - Protection Failure: Open ports can allow dust, moisture, or foreign objects to enter, potentially causing short circuits, fires, or equipment failure.

NOTICE

- When performing electrical connections, wear personal protective equipment such as safety shoes, protective gloves, and insulating gloves as required.
- Only qualified personnel are permitted to perform electrical connection operations.
- The cable colors shown in the graphics in this document are for reference only. Actual cable specifications must comply with local regulations.

5.1 System Wiring Electrical Block Diagram

NOTICE


- Depending on regional regulatory requirements, the wiring methods for the N and PE lines of the inverter's GRID and BACK-UP ports may differ. Please comply with local regulations.
- The inverter has a built-in energy meter and can be directly connected to a CT for use. The CT network cable included in the shipment is 10 meters. For longer distances, you can use shielded network cable of CAT5E or higher grade to extend it up to 30 meters.
- CT accuracy will decrease when the connection length to the inverter exceeds 30m. For higher accuracy requirements, an external smart meter can be connected.
- The inverter's GRID AC port has a built-in relay. When the inverter is in off-grid mode, the built-in GRID relay is open; when the inverter is in grid-connected mode, the built-in GRID relay is closed.
- When the inverter is powered on, the BACK-UP AC port is live. If maintenance on the BACK-UP Loads is required, please power down the inverter to avoid electric shock.
- In a whole-house backup scenario, if the total power of the connected loads exceeds 1.1 times the inverter's rated power, the inverter will stop outputting due to overload protection after a grid outage. In this case, please turn off some non-essential loads to ensure the total load power is less than 1.1 times the inverter's rated power.

N and PE lines are connected together in the distribution box


NOTICE

- To maintain neutral integrity, the neutral lines of the grid-connected side and the off-grid side must be connected together; otherwise, the off-grid function cannot operate normally.
- The diagram below illustrates the grid system for regions such as Australia and New Zealand:

Whole-house backup power



Partial backup power




ESA20ELC0015

N and PE lines are wired separately in the distribution box

NOTICE


- Please ensure that the protective ground wire of BACK-UP is correctly and securely connected; otherwise, the BACK-UP function may malfunction when a grid fault occurs.
- Other regions except Australia, New Zealand, etc. are applicable to the following wiring methods:

Whole-house backup power



ESA20ELC0022

Partial backup power



ESA20ELC0016

5.2 Detailed System Wiring Diagram


When all loads in the photovoltaic system cannot consume the electricity generated by the system, the surplus electricity will be fed into the grid. In this case, a smart meter or CT monitoring system can be used to monitor the system's power generation and control the amount of electricity fed into the grid.

- Connecting a smart meter enables output power limiting and load monitoring functions.
- After connecting the smart meter, please enable the "Export power limit" function via the Xiaogu Cloud Window+ App.

The Detailed System Wiring Diagram only shows wiring examples using some model devices. Please refer to the corresponding wiring guide chapter for the actual devices you are using for wiring.

⚠ WARNING

The common contact of the manual transfer switch must be at the Inverter's BACK-UP load side, do not connect to the GRID grid side. If connected to the GRID grid side, the Inverter's off-grid mode and bypass mode operate simultaneously, when the grid power is out, the distribution cabinet connected to the Inverter's GRID port still has high voltage electricity, there may be a risk of electric shock.



ESA20ELC0019

NOTICE

- In microgrid and coupling scenarios, if grid-tied inverter power generation monitoring and load monitoring functions are required, dual-meter networking must be used.
 - Meter 1 or the built-in meter is used to monitor the system's grid-connected power.
 - Meter 2 is used to monitor the grid-tied inverter's power generation.
 - By integrating data from Meter 1 and Meter 2, the monitoring platform can achieve real-time monitoring of load power consumption.
- If output power limitation is required for the grid-tied inverter, please connect separate equipment such as a meter or CT.
- In microgrid and coupling scenarios configured with dual meters, the meter wiring method is the same.
- When not using the inverter's built-in meter, do not connect to the inverter's CT port.
- The manual transfer switch is shipped as an optional accessory; please decide whether to install it based on the actual usage scenario. If using a self-provided ATS or STS switch, this switch must have an interlock function.


Dual Meter Configuration Scenarios

| Meter 1 (Grid Side) | Meter 2 (Grid-tied Inverter AC Side) |
|---------------------|--------------------------------------|
| Built-in Meter | GMK330 |
| Built-in Meter | GM330 |
| GMK330 | GMK330 |
| GM330 | GM330 |
| GMK330 | GM330 |
| GM330 | GMK330 |


General Scenario

Scenario with Built-in Meter


The scenario with a built-in meter does not support connecting a generator.



Scenario with GM330 Meter




Scenario with GMK330 Meter




Microgrid Scenario Network Diagram

- The Microgrid Scenario does not support connecting a generator.
- The manual transfer switch is optional. Please choose whether to install it based on the actual usage scenario.

Built-in Meter + GM330 Meter Network Diagram




GMK330 + GMK330



Microgrid Scenario, Grid-tied Inverter Export Power Limit Network Diagram

If output power limiting is required for grid-tied inverters in a Microgrid Scenario, please connect a meter or CT device separately.


GM330 + GMK330




Coupled Scenario Dual Meter Network Diagram

- The manual transfer switch is optional. Please choose whether to install it based on the actual usage scenario.
- The scenario with a built-in meter does not support connecting a generator.

Built-in Meter + GMK330




GM330 + GM330 Network Diagram



Coupled Scenario, Grid-tied Inverter Export Power Limit Network Diagram

If output power limiting is required for grid-tied inverters in a Coupled Scenario, please connect a meter or CT device separately.

GMK330 + GM330



5.3 Preparing Materials



- Do not connect loads between the inverter and the AC switch directly connected to the inverter.
- Each inverter must be equipped with an AC output circuit breaker. Multiple inverters cannot be connected to one AC circuit breaker simultaneously.
- To ensure that the inverter can safely disconnect from the grid in case of abnormalities, please connect an AC circuit breaker on the AC side of the inverter. Select a suitable AC circuit breaker according to local regulations.
- When the inverter is powered on, the BACK-UP AC port is live. If maintenance is required on the BACK-UP Loads, please power off the inverter; otherwise, it may cause electric shock.
- For cables used in the same system, it is recommended that the following cable conductor material, cross-sectional area, length, etc., be consistent.
 - Inverter's BACK-UP AC cable
 - Inverter's GRID AC cable
- The inverter supports connecting to a generator via an ATS switch to achieve switching between grid and generator power supply. The ATS switch is by default connected to the grid.

5.3.1 Preparing Breakers

| No. | breaker | Recommended Specifications | Acquisition Method | Remarks |
|-----|---------------------------------|---|--------------------|---|
| 1 | GRID breaker BACK-UP breaker | <p>For partial backup power scenarios, the recommendations are as follows:</p> <ul style="list-style-type: none"> • Nominal Voltage $\geq 230V_{ac}$ • Nominal current requirements are as follows: <ul style="list-style-type: none"> ◦ GW5K-ETA-G20: 20A ◦ GW6K-ETA-G20: 20A ◦ GW8K-ETA-G20: 20A | Self-provided | In actual selection, you can also choose a breaker that meets local installation regulations based on the actual working current. |

| No. | breaker | Recommended Specifications | Acquisition Method | Remarks |
|-----|---------|---|--------------------|---------|
| | | <ul style="list-style-type: none"> ◦ GW9.999K-ETA-G20: 32A ◦ GW10K-ETA-G20: 32A ◦ GW12K-ETA-G20: 40A ◦ GW15K-ETA-G20: 50A ◦ GW20K-ETA-G20: 50A ◦ GW25K-ETA-G20: 63A ◦ GW29.999K-ETA-G20: 80A ◦ GW30K-ETA-G20: 80A ◦ GW5K-BTA-G20: 20A ◦ GW6K-BTA-G20: 20A ◦ GW8K-BTA-G20: 20A ◦ GW9.999K-BTA-G20: 32A ◦ GW10K-BTA-G20: 32A ◦ GW12K-BTA-G20: 40A ◦ GW15K-BTA-G20: 50A ◦ GW20K-BTA-G20: 50A ◦ GW25K-BTA-G20: 63A ◦ GW29.999K-BTA-G20: 80A ◦ GW30K-BTA-G20: 80A <p>For whole-house backup power scenarios, the recommendations are as follows:</p> <ul style="list-style-type: none"> • Nominal Voltage $\geq 230V_{ac}$ • Nominal current requirements are as follows: <ul style="list-style-type: none"> ◦ GW5K-ETA-G20: 63A | | |

| No. | breaker | Recommended Specifications | Acquisition Method | Remarks |
|-----|---------|--|--------------------|---------|
| | | <ul style="list-style-type: none"> ◦ GW6K-ETA-G20: 63A ◦ GW8K-ETA-G20: 63A ◦ GW9.999K-ETA-G20: 80A ◦ GW10K-ETA-G20: 80A ◦ GW12K-ETA-G20: 80A ◦ GW15K-ETA-G20: 100A ◦ GW20K-ETA-G20: 100A ◦ GW25K-ETA-G20: 125A ◦ GW29.999K-ETA-G20: 125A ◦ GW30K-ETA-G20: 125A ◦ GW5K-BTA-G20: 63A ◦ GW6K-BTA-G20: 63A ◦ GW8K-BTA-G20: 63A ◦ GW9.999K-BTA-G20: 80A ◦ GW10K-BTA-G20: 80A ◦ GW12K-BTA-G20: 80A ◦ GW15K-BTA-G20: 100A ◦ GW20K-BTA-G20: 100A ◦ GW25K-BTA-G20: 125A ◦ GW29.999K-BTA-G20: 125A ◦ GW30K-BTA-G20: 125A <p>Note: If the inverter BACK-UP port is not used, the GRID breaker can be selected based on the maximum grid-connected current.</p> | | |

| No. | breaker | Recommended Specifications | Acquisition Method | Remarks |
|-----|------------|--|--------------------|---------|
| 2 | ATS switch | The specifications of the ATS switch and GRID breaker for the same model are consistent. | Self-provided | |
| 3 | RCD | RCD device installation and RCD specification selection: It is recommended to connect a Type A RCD with a residual current trip level $\geq 300\text{mA}$ to the AC output side of the inverter (for inverter capacity $< 30\text{kVA}$, select the residual current action level as 300mA ; for inverter capacity $\geq 30\text{kVA}$, select the residual current action level as 10mA/kVA). Alternatively, select an appropriate RCD specification based on local regulatory requirements. | Self-provided | - |

| No. | breaker | Recommended Specifications | Acquisition Method | Remarks |
|-----|--------------------------------------|--|---|---|
| 4 | (Optional) Manual transfer switch | <p>Nominal Voltage $\geq 230\text{Vac}$ Nominal current requirements are as follows:</p> <ul style="list-style-type: none"> • GW5K-ETA-G20, GW6K-ETA-G20, GW8K-ETA-G20, GW9.999K-ETA-G20, GW10K-ETA-G20, GW12K-ETA-G20, GW15K-ETA-G20, GW20K-ETA-G20, GW5K-BTA-G20, GW6K-BTA-G20, GW8K-BTA-G20, GW9.999K-BTA-G20, GW10K-BTA-G20, GW12K-BTA-G20, GW15K-BTA-G20, GW20K-BTA-G20: 63A • GW25K-ETA-G20, W29.999K-ETA-G20, GW30K-ETA-G20, GW25K-BTA-G20, GW29.999K-BTA-G20, GW30K-BTA-G20: 80A | <ul style="list-style-type: none"> • Self-provided • Shipped with the inverter (Australia only) | <p>In actual selection, you can also choose an appropriate manual transfer switch based on local regulations.</p> |

5.3.2 Preparing Cables

| No. | Cable | Recommended Specification | Source |
|-----|--|---|---------------|
| 1 | Inverter Chassis Protective Ground Cable | <ul style="list-style-type: none"> • Single-core outdoor copper cable • Conductor cross-sectional area: <ul style="list-style-type: none"> ◦ GW5K-ETA-G20, GW6K-ETA-G20, GW8K-ETA-G20, GW5K-BTA-G20, GW6K-BTA-G20, GW8K-BTA-G20: 4-6mm² ◦ GW9.999K-ETA-G20, GW10K-ETA-G20, GW12K-ETA-G20, GW15K-ETA-G20, GW20K-ETA-G20, GW9.999K-BTA-G20, GW10K-BTA-G20, GW12K-BTA-G20, GW15K-BTA-G20, GW20K-BTA-G20: 6-10 mm² ◦ GW25K-ETA-G20, GW29.999K-ETA-G20, GW30K-ETA-G20, GW25K-BTA-G20, GW29.999K-BTA-G20, GW30K-BTA-G20: 10-16 mm² | User-provided |
| 2 | PV DC Cable | <ul style="list-style-type: none"> • Industry-standard outdoor photovoltaic cable • Conductor cross-sectional area: 4mm²-6mm² • Cable outer diameter: 5.9mm-8.8mm | User-provided |

| No. | Cable | Recommended Specification | Source |
|-----|-------------------------|---|---------------|
| 3 | AC Cable | <ul style="list-style-type: none"> • Inverter AC input/output cable (BACK UP/GRID): • Conductor cross-sectional area: <ul style="list-style-type: none"> ◦ GW5K-ETA-G20, GW6K-ETA-G20, GW8K-ETA-G20, GW5K-BTA-G20, GW6K-BTA-G20, GW8K-BTA-G20: 4-6mm² ◦ GW9.999K-ETA-G20, GW10K-ETA-G20, GW12K-ETA-G20, GW9.999K-BTA-G20, GW10K-BTA-G20, GW12K-BTA-G20: 6-10mm² ◦ GW15K-ETA-G20, GW20K-ETA-G20, GW15K-BTA-G20, GW20K-BTA-G20: 10-16mm² ◦ GW25K-ETA-G20, GW29.999K-ETA-G20, GW30K-ETA-G20, GW25K-BTA-G20, GW29.999K-BTA-G20, GW30K-BTA-G20: 16-25mm² • Multi-core outdoor copper cable outer diameter: <ul style="list-style-type: none"> ◦ GW5K-ETA-G20, GW6K-ETA-G20, GW8K-ETA-G20, GW9.999K-ETA-G20, GW10K-ETA-G20, GW12K-ETA-G20, GW5K-BTA-G20, GW6K-BTA-G20, GW8K-BTA-G20, GW9.999K-BTA-G20, GW10K-BTA-G20, GW12K-BTA-G20: 10-26mm ◦ GW15K-ETA-G20, GW20K-ETA-G20, GW15K-BTA-G20, GW20K-BTA-G20: 18-30mm | User-provided |
| 4 | Smart Meter Power Cable | <ul style="list-style-type: none"> • Outdoor copper cable • Conductor cross-sectional area: 1mm² | User-provided |

| No. | Cable | Recommended Specification | Source |
|-----|---|--|---------------|
| 5 | Meter RS485 Communication cable | <ul style="list-style-type: none"> • Shielded twisted pair • Conductor cross-sectional area: 0.2mm²-0.4mm² | User-provided |
| 6 | EMS or Charging Pile RS485 Communication cable | | |
| 7 | Remote Shutdown | <ul style="list-style-type: none"> • Shielded cable meeting local standards • Conductor cross-sectional area: 0.2mm²-0.4mm² • Cable outer diameter: 5mm-8mm | User-provided |
| 8 | Load Control and Generator Control DO Communication cable | | |
| 9 | RCR/DRED/14a Signal Cable | | |
| 10 | CT Communication cable | standard network cable: CAT 5E or above standard shielded network cable and RJ45 connector | User-provided |


5.4 Connecting the PE cable




WARNING

- The protective grounding of the chassis cannot replace the protective ground wire of the AC output port. When wiring, ensure the protective ground wires at both locations are reliably connected.
- To improve the corrosion resistance of the terminal, it is recommended to apply silicone or paint over the external part of the grounding terminal for protection after the protective ground wire connection installation is completed.
- When installing the equipment, the protective ground wire must be installed first; when removing the equipment, the protective ground wire must be removed last.
- The battery grounding is integrated into the blind-mating connector connected to the inverter. The system is uniformly grounded through the inverter, so no separate grounding operation is required for the battery during installation. If there is a requirement for split expansion, please separately ground the expansion battery pack.

Energy storage system grounding:



Expansion battery pack grounding:



5.5 Connecting the PV Cable

⚠ DANGER


- Do not connect the same PV string to multiple inverters, as this may cause inverter damage.
- Before connecting the PV string to the inverter, confirm the following information. Failure to do so may cause permanent damage to the inverter, and in severe cases, may lead to fire causing personal injury and property damage.
 1. Ensure the maximum short-circuit current and Max. Input Voltage for each MPPT are within the inverter's allowable range.
 2. Ensure the positive pole of the PV string is connected to the inverter's PV+, and the negative pole of the PV string is connected to the inverter's PV-.

 **WARNING**

- PV string output does not support grounding. Before connecting the PV string to the inverter, ensure the minimum insulation resistance to ground of the PV string meets the minimum insulation resistance requirement ($R = \text{Max. Input Voltage} / 30\text{mA}$).
- After completing the DC cable connection, ensure the cable connections are tight and secure, with no looseness.
- Use a multimeter to measure the positive and negative poles of the DC cables to ensure correct polarity (no reverse connection) and that the voltage is within the allowable range.


NOTICE

- The two PV strings within each MPPT must use the same model, the same number of panels, and the same tilt and azimuth angles to ensure maximum efficiency.
- Connecting PV cables is only for the ETA model; the BTA model does not have PV connection ports.



ESA20ELC0030

To disassemble the PV terminal, please refer to the following steps:



ESA20MTN0001

5.6 Connecting the Battery Expansion Cable




- Do not connect loads between the inverter and the battery.
- When connecting battery cables, use insulated tools to prevent accidental electric shock or short-circuiting of the battery.
- Ensure the battery open-circuit voltage is within the inverter's allowable range.
- Select whether to install a DC switch between batteries according to local laws and regulations.
- Do not route wires on the surface or around the inverter heat sink to prevent overheating and damage to the wiring harness.

Energy Storage System Expansion Overview


A1: Base shipped with the inverter

A2: Installation base with parallel port




ESA20ELC0025

Battery System Expansion Cable Harness Manufacturing Method



BAT20ELC0004

Battery Expansion Cable Harness Disassembly Method




BAT20INT0007

5.7 Connecting the AC Cable


⚠ WARNING


- The inverter integrates a Residual Current Monitoring Unit (RCMU) internally to prevent residual current from exceeding the specified value. When the inverter detects a leakage current greater than the allowable value, it will quickly disconnect from the grid.
- During wiring, ensure the AC cables fully match the "BACKUP" and "GRID" ground ports of the AC terminals. Incorrect cable connection will cause equipment damage.
- Ensure the wire cores are fully inserted into the terminal wiring holes with no exposed parts.
- Ensure the insulation plate at the AC terminals is securely fastened and not loose.
- Ensure the cable connections are tight. Otherwise, during operation, overheating of the terminals may occur, leading to equipment damage.



ESA20ELC0027

If you need to disassemble the AC terminal, please refer to the following steps:






5.8 Connecting the Meter Cable


NOTICE

- If there is a need for multiple inverters to be connected in parallel for networking, please consult the manufacturer to purchase a meter separately.
- Please ensure that the CT connection direction and phase sequence are correct; otherwise, it may lead to incorrect monitoring data.
- Ensure that all cables are connected correctly, tightly, and without looseness. Improper wiring may cause poor contact or damage to the meter.
- In areas with lightning risks, if the meter cable length exceeds 10m and the cables are not laid with grounded metal conduits, it is recommended to install external lightning protection devices.

GM330 Meter Wiring



Install CT (Type Two)





5.9 Connecting the Inverter Communication Cable

NOTICE

- To ensure proper operation of the meter and CT, please ensure the following: CT must be connected to the matching phase wire, with CT1 connected to L1, CT2 to L2, and CT3 to L3.
- When using the built-in meter of the Inverter, please use the CTs shipped with the unit.
- If DRED, RCR, or remote shutdown functions are required, please enable them in the SEMS+ App after wiring is completed.
- Do not enable these functions in the SEMS+ App if the Inverter is not connected to a DRED device or remote shutdown device, otherwise the Inverter will not be able to connect to the grid.
- To maintain the Inverter's waterproof rating, do not remove the waterproof plugs from unused communication ports on the Inverter.
- The Inverter's DO signal communication port can connect to dry contact signals with specifications: $\text{Max} \leq 24\text{Vdc}$, 1A.
- The Inverter's communication functions are optional; please select based on actual usage scenarios.
- The Inverter supports connecting via Bluetooth, WiFi, or LAN to a mobile phone or WEB interface to set device parameters, view operational information and error messages, and stay informed about system status.

Communication Function Description




ESA20ELC0028

| Port (Silkscreen) | | Function | Description |
|-------------------|------|--------------------|---|
| A | PAR1 | Reserved | - |
| B | PAR2 | | |
| C | CT | CT Connection Port | Connect the CT communication cable only when using the inverter's built-in meter. |

| Port (Silkscreen) | | Function | Description |
|-------------------|---------|---|--|
| D | DRM/RCR | RCR, DRED, or EnWG 14a Function Connection Port | <ul style="list-style-type: none"> • RCR (Ripple Control Receiver): Provides an RCR signal control port to meet grid dispatch requirements in European regions. • DRED (Demand Response Enabling Device): Provides a DRED signal control port to meet DERD certification requirements in regions such as Australia. • EnWG (Energy Industry Act) 14a: All controllable loads must accept emergency dimming from the grid. Grid operators can temporarily reduce the maximum grid purchase power of controllable loads to 4.2kW. |
| E | METER | Meter Connection Port | Use RS485 communication to connect an external smart meter. |
| F | DI | Remote Shutdown/Rapid Shutdown | <ul style="list-style-type: none"> • Connect an external Remote Shutdown device. Default is off. • In a Rapid Shutdown system, the rapid shutdown transmitter and receiver work together to achieve rapid system shutdown. The receiver maintains module output by receiving signals from the transmitter. The transmitter can be external or built into the inverter. In an emergency, enabling an external trigger device can stop the transmitter, thereby shutting down the modules. |

| Port (Silkscreen) | | Function | Description |
|-------------------|------|--------------------------------------|--|
| | LOAD | Load Control | <ul style="list-style-type: none"> • Supports connection to dry contact signals to achieve functions such as load control. The DO contact rating is 24V DC@1A, NO/COM normally open contacts. • Supports SG Ready heat pump connection, controlling the heat pump via dry contact signals. |
| | GEN | Generator Control Port | Supports connection to generator control signals to control generator start/stop. Not supported for generator connection in microgrid scenarios. |
| G | EMS | EMS/Charging Pile Communication Port | Connect to third-party EMS devices for energy control or connect to GoodWe charging piles. |
| H | SW1 | - | - |
| I | SW2 | - | - |

Method for Connecting the Communication Cable



ESA20ELC0005

6 System Commissioning

6.1 Check Before Power ON

| No. | Check Item |
|-----|---|
| 1 | The equipment is securely installed, the installation location facilitates operation and maintenance, the installation space allows for ventilation and heat dissipation, and the installation environment is clean and tidy. |
| 2 | The PE cable, DC cable, AC cable, and communication cable are connected correctly and securely. |
| 3 | Cable bundling meets wiring requirements, is reasonably distributed, and shows no damage. |
| 4 | For unused cable entry holes and ports, please use the terminals provided with the accessories for reliable connection, and ensure they are sealed. |
| 5 | Ensure that all used cable entry holes have been sealed. |
| 6 | The voltage and frequency at the inverter grid connection point meet the grid interconnection requirements. |

6.2 Power ON


WARNING

- Battery Black Start: When there is no PV power generation in the photovoltaic system and the grid is abnormal, if the inverter cannot operate normally, the battery black start function can be used to force the battery to discharge and start the inverter. The inverter can then enter off-grid mode operation, supplying power to the load from the battery.
- After the battery system starts, please ensure that the communication between the inverter and the battery system is normal within 15 minutes. If the inverter and the battery system cannot communicate normally, the battery system switch will automatically disconnect, cutting off power to the battery system.
- When the inverter is operating normally, set the manual transfer switch to position B to supply power to the load from the inverter's BACK-UP port; when the inverter is powered down for maintenance or has a fault, to ensure normal operation of the load, please set the manual transfer switch to position A to supply power to the load from the grid.
- "Step 4" and "Step 5" only apply to the ETA series.

NOTICE

When the system is powered on for the first time, it is recommended to perform a battery black start. Close the battery power switch and briefly press the multifunction button on one of the batteries. Observe whether the inverter's SOC indicator lights up. If the indicator lights up, it indicates the battery is connected normally, and you can proceed to close the inverter's DC switch.

power on



ESA20PWR0003


1. Close the battery power switch and briefly press the multifunction button on the battery. When there are multiple batteries in the system, close the power switches on all batteries. Briefly pressing the multifunction button on any one battery will start all batteries.
2. Close the DC switch of the inverter.
3. (Optional) Close the circuit breaker between the PV components and the inverter.
4. Close the GRID circuit breaker.
5. Close the BACK-UP circuit breaker, and (optional) set the manual transfer switch to the B state.

Battery Black Start

1. Close the battery power switch. When there are multiple batteries in the system, close the power switches on all batteries.

2. Close the DC switch of the inverter.
3. (Optional) Close the circuit breaker between the PV components and the inverter.
4. Close the GRID circuit breaker.
5. Close the BACK-UP circuit breaker.
6. After all batteries are powered on individually, wait for 15 seconds, then press and hold the multifunction button on any one battery for 2 seconds to force the battery to discharge and activate the inverter.

6.3 Install Protective Cover




Step 1: Install the top protective cover of the inverter. Align the cover with the top installation slot of the inverter and slide it forward.

Step 2: Install the side protective cover. Place the side cover into the card slot on the side of the battery and push it forward.

6.4 Indicators

6.4.1 Inverter Indicators








Breathing Light:

- When the system is upgrading: The breathing light is a green running light; the head of the running light is the brightest and the tail is the dimmest, the length of the running light and the upgrade percentage are affected by the Xiaogu Cloud Window+ App settings and the device's operational status.
- Except for inverter upgrade, system fault, and inverter power-off status, the breathing light status is affected by the App settings on the Xiaogu Cloud Window+ App. For setup instructions, please refer to the Xiaogu Cloud Window+ App User Manual.

| indicator | Indicator Status | Breathing Light Status | Description |
|---|---|--|---|
|  |  | <ul style="list-style-type: none"> • 3min/Always on: Blue-purple chasing light stays on | The inverter is powered on and in standby mode |
| |  | <ul style="list-style-type: none"> • Always off: Not lit | The inverter is starting up and in self-test mode |

| indicator | Indicator Status | Breathing Light Status | Description |
|---|---|---|---|
| |  | <ul style="list-style-type: none"> • 3min: Blue-purple breathing for 3min then off • Always on in App: Blue-purple breathing stays on • Always off in App: Not lit | The inverter is operating normally in grid-tied power generation or off-grid mode |
| |  | Red flashing | System fault |
| |  | Off | The inverter is powered off |
|  |  | / | Inverter monitoring module is resetting |
| |  | | Inverter and communication terminal are not connected |
| |  | | Communication failure between communication terminal and cloud server |
| |  | | Inverter monitoring is normal |
| |  | | Inverter monitoring module is not started |
| |  |  | |
|  | | | Grid normal, inverter BACK-UP port power supply normal |
|  | | | BACK-UP port has no power supply |

| indicator | Indicator Status | Breathing Light Status | Description |
|---|---|------------------------|--|
| |  | | System upgrade |
| |  | | System fault |
|  |  | | Battery has no charge |
| |  | | Constantly lit: Charge Flashing: Discharge Battery SOC: 0% < SOC ≤ 25% |
| |  | | Constantly lit: Charge Flashing: Discharge Battery SOC: 25% < SOC ≤ 50% |
| |  | | Constantly lit: Charge Flashing: Discharge Battery SOC: 50% < SOC ≤ 75% |
| |  | | Constantly lit: Charge Flashing: Discharge Battery SOC: 75% < SOC ≤ 100% |

6.4.3 Smart Meter Indicator Lights GM330&GMK330

6.4.3.1 Indicator Light Description

| Type | Status | Description |
|--|-----------|---|
|  Power Light | Steady On | The meter is powered on, with no RS485 communication. |
| | Blinking | The meter is powered on, with normal RS485 communication. |
| | Off | The meter is powered off. |
|  Comm Light | Off | Reserved. |
| | Blinking | Press and hold the Reset button for $\geq 5s$, and the Power Light and Buy/Sell Power Light blink: The meter is resetting. |
|  Buy/Sell Power Light | Steady On | buy power from the grid. |
| | Blinking | Selling power to the grid. |
| | Off | Not buying or selling power. |
|  Buy/Sell Power Light (GMK360 only) | Steady On | buy power from the grid. |
| | Blinking | Selling power to the grid. |
| | Off | Not buying or selling power. |

6.4.4 Smart Dongle Indicator

- WiFi/LAN Kit-20

NOTICE

- After double-clicking the Reload button to turn on Bluetooth, the communication indicator light will switch to a single-blink state. Please connect to the Xiaogu Cloud Window+ App within 5 minutes, otherwise Bluetooth will automatically turn off.
- The communication indicator light's single-blink state only appears after double-clicking the Reload button to turn on Bluetooth.

| Indicator | Status | Description |
|--|---|--|
| Power indicator  |  | Steady on: The Smart Communication Stick is powered on. |
| |  | Off: The Smart Communication Stick is not powered on. |
| Communication indicator  |  | Steady on: Communication is normal in WiFi mode or LAN mode. |
| |  | Single blink: The Smart Communication Stick's Bluetooth signal is enabled, waiting to connect to the Xiaogu Cloud Window+ App. |
| |  | Two blinks: The Smart Communication Stick has not connected to the router. |
| |  | Four blinks: The Smart Communication Stick communicates normally with the router but has not connected to the server. |
| |  | Six blinks: The Smart Communication Stick is identifying connected devices. |
| |  | Off: The Smart Communication Stick is undergoing a software reset or is not powered on. |

| Indicator | Color | Status | Description |
|-----------|-------|-----------|---|
| | Green | Steady on | 100Mbps wired network connection is normal. |

| Indicator | Color | Status | Description |
|---|--------|-----------|--|
| LAN port communication indicator  | Yellow | Off | <ul style="list-style-type: none"> • Network cable is not connected. • 100Mbps wired network connection is abnormal. • 10Mbps wired network connection is normal. |
| | | Steady on | 10/100Mbps wired network connection is normal, with no communication data being transmitted or received. |
| | | Flashing | Communication data is being transmitted or received. |
| | | Off | Network cable is not connected. |

| Button | Description |
|--------|--|
| Reload | Hold for 0.5 to 3 seconds to reset the Smart Communication Stick. |
| | Hold for 6 to 20 seconds to restore the Smart Communication Stick to factory settings. |
| | Double-click quickly to enable Bluetooth signal (maintained for only 5 minutes). |

7 System Commissioning

7.1 Setting Inverter Parameters via App

SEMS+ App is a software used for remote power plant monitoring or local device debugging. It supports installers or owners to:

- Remotely monitor the operation status of the power plant and set operation parameters for the plant and devices.
- Locally connect to devices to view their operation status and set device parameters.

For detailed functions, please refer to the "[SEMS+ App User Manual](#)". The user manual can be obtained from the official website or by scanning the QR code below.



SEMS+ App User Manual

7.1.1 Download and Install XiaoGu Cloud Window+ App

Phone Requirements:

- Operating System: Android 7.0 or above, iOS 15.1 or above.
- Phone must support a web browser and connect to the Internet.
- Phone must support WLAN/Bluetooth functionality.

Download Methods:

Method 1:

Search for "XiaoGu Cloud Window+" in Google Play, App Store, Huawei, Honor, Xiaomi, OPPO, or vivo app stores to download and install.



Method 2:

Scan the QR code below to download and install.



7.2 Monitoring power stations via SEM+ WEB

SEM+ WEB is a monitoring platform that can communicate via WiFi or LAN. The following are the common functions of SEM+ WEB:

- 1. Manage organization or user information, etc.
- 2. Add and monitor power station information, etc.
- 3. Maintain equipment.

For detailed functions, please refer to the [SEM+ WEB User Manual](#).



SEM+ WEB User Manual

8 Maintenance

8.1 Power OFF the System


DANGER

- When performing operation and maintenance on devices in the system, please power off the system. Operating devices with power on may cause device damage or electric shock DANGER.
- After the device is powered off, internal components require some time to discharge. Please wait until the device is completely discharged according to the label time requirements.
- Restarting the battery should be done using the air switch power-on method.
- When shutting down the battery system, strictly adhere to the battery system power-off requirements to prevent damage to the battery system.

NOTICE

- To ensure effective protection of the battery system, keep the cover plate of the battery system switch closed. If the battery system switch is not used for an extended period, secure it with screws.
- "Step 4" and "Step 5" are only applicable to the ETA series.

power off



ESA20PWR0003

1. Disconnect the BACK-UP circuit breaker.
2. Disconnect the GRID circuit breaker.
3. Press and hold any battery's multifunction button for 5 seconds to power off the battery system. If the system contains multiple batteries, this operation will power off all batteries; there is no need to operate them individually. Finally, disconnect the battery system switch.
4. (Optional) Disconnect the circuit breaker between the PV components and the inverter.
5. Disconnect the inverter's DC switch. (Optional) Set the manual transfer switch to position A.

8.2 Removing the Equipment

 DANGER

- Ensure the device is powered off.
- When operating the device, please wear personal protective equipment.
- When removing wiring terminals, use standard disassembly tools to avoid damaging the terminals or device.
- Unless otherwise specified, the device disassembly method is the reverse order of the installation method, and this document will not elaborate further.

1. Power down the system.
2. Label the cables connected in the system to indicate their types.
3. Disconnect the cables from the Inverter, Battery, and smart meter in the system, such as DC cables, AC cables, Communication cable, and PE cable.
4. Remove equipment such as the smart communication stick, Inverter, Battery, and smart meter.
5. Store the equipment properly. If it will be put into use again later, ensure the storage conditions meet the requirements.

8.3 Disposing of the Equipment

When the equipment can no longer be used and needs to be disposed of, please handle it according to the electrical waste disposal requirements of the regulations in the country/region where the equipment is located. The equipment must not be disposed of as general household waste.

8.4 Routine Maintenance

 WARNING

- If any issues that may affect the battery or energy storage inverter system are found, contact after-sales personnel. Disassembly by unauthorized persons is prohibited.
- If exposed copper wires inside the conductive wires are found, do not touch them. High voltage danger. Contact after-sales personnel. Disassembly by unauthorized persons is prohibited.
- In case of other emergencies, contact after-sales personnel immediately. Operate under the guidance of after-sales personnel or wait for on-site operation by after-sales personnel.


| Maintenance Item | Maintenance Method | Maintenance Cycle | Maintenance Purpose |
|------------------------|---|------------------------------------|--|
| System Cleaning | Check the heat sink and air inlet/outlet for foreign objects or dust. Check if the installation space meets requirements and if there is debris accumulation around the equipment. | Once every 6 months | Prevent cooling failures. |
| System Installation | Check if the equipment installation is secure and if fastening screws are loose. Check the equipment exterior for damage or deformation. | Once every 6 months to once a year | Confirm equipment installation stability. |
| Electrical Connections | Check electrical connections for looseness, inspect cable exteriors for damage or exposed copper. | Once every 6 months to once a year | Confirm electrical connection reliability. |
| Fan | Check the fan for abnormal noise; Check fan blades for cracks; Check the fan for abnormal blockage/stalling; | Once every 6 months | Prevent fan failure. |

| Maintenance Item | Maintenance Method | Maintenance Cycle | Maintenance Purpose |
|---------------------|---|--------------------|---|
| Sealing | Check if the sealing of equipment cable entry holes meets requirements. If gaps are too large or unsealed, reseal them. | Once a year | Confirm machine sealing and waterproof integrity. |
| Battery Maintenance | If the battery has not been used or fully charged for an extended period, it is recommended to charge it regularly. | Once every 15 days | Protect battery service life. |


For fan maintenance, refer to the following steps:

The inverter has a fan module on the outside. To better clean the fan module, please remove it from the machine before cleaning. The specific steps are as follows:

1. Power off the inverter. You can refer to [8.1.Power OFF the System\(Page 133\)](#).
2. Wait for the system residual voltage to be completely discharged and the fan module to completely stop running.
3. Use a screwdriver to remove the module mounting screws and take out the entire fan module.
4. Use a soft brush, cloth, or vacuum cleaner to clean the fan.



After cleaning is completed, reinstall the fan module back into the machine.



- 1.
- 2.

8.5 fault

8.5.1 Viewing Fault/Alarms Information

Detailed information for all faults and alarms in the energy storage system is displayed in the **XiaoGu CloudWindow+ App and XiaoGu CloudWindow+ WEB**. If your product experiences an abnormality and no related fault information is seen in the **XiaoGu CloudWindow+ App or XiaoGu CloudWindow+ WEB**, please contact the after-sales service center.

- In XiaoGu CloudWindow+ App

1. Open the XiaoGu CloudWindow+ App and log in with any account.
2. On the homepage, click "Alarms" to view alarm information for all power plants under the account.

- XiaoGu CloudWindow+ WEB

1. Open the XiaoGu CloudWindow+ WEB and log in with any account.
2. On the power plant details interface, click "Alarms" to view all alarm information for the current power plant.

8.5.2 Fault Information and Troubleshooting

Please perform troubleshooting according to the following methods. If the troubleshooting methods cannot help you, please contact the after-sales service center.

When contacting the after-sales service center, please collect the following information to facilitate a quick resolution.

1. Product information, such as: serial number, software version, device installation time, fault occurrence time, fault frequency, etc.
2. Device installation environment, such as: weather conditions, whether components are blocked, have shadows, etc. It is recommended to provide photos, videos, and

other files to assist in problem analysis.

3. Grid conditions.

If the system experiences a problem not listed, or if following the instructions still cannot prevent the problem or abnormality, immediately stop system operation and contact your dealer immediately.

| No. | fault | Resolution |
|-----|--|---|
| 1 | Unable to search for the Smart Communication Stick's wireless signal | <ol style="list-style-type: none"> 1. Ensure no other devices are connected to the Smart Communication Stick's wireless signal. 2. Ensure the Smart Communication Stick is powered normally, with the blue signal light flashing or steady on. 3. Ensure the smart device is within the communication range of the Smart Communication Stick. 4. Refresh the App device list again. 5. Restart the inverter. |
| 2 | Unable to connect to the Smart Communication Stick's wireless signal | <ol style="list-style-type: none"> 1. Ensure no other devices are connected to the Smart Communication Stick's wireless signal. 2. Restart the inverter or the communication stick, then try connecting to the Smart Communication Stick's wireless signal again. 3. Ensure Bluetooth pairing and encryption were successful. |
| 3 | Unable to find the router's SSID | <ol style="list-style-type: none"> 1. Place the router closer to the Smart Communication Stick, or add a WiFi repeater to enhance the WiFi signal. 2. Reduce the number of devices connected to the router. |

| No. | fault | Resolution |
|-----|---|---|
| 4 | After all configuration is complete, the Smart Communication Stick fails to connect to the router | <ol style="list-style-type: none"> 1. Restart the inverter. 2. Check if the network name, encryption method, and password in the WiFi configuration match those of the router. 3. Restart the router. 4. Place the router closer to the Smart Communication Stick, or add a WiFi repeater to enhance the WiFi signal. |
| 5 | After all configuration is complete, the Smart Communication Stick fails to connect to the server | Restart the router and the inverter. |

8.5.2.1 Inverter Fault

8.5.2.1.1 Troubleshooting (Fault Codes F01-F40)

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|-------------------|---|--|
| F01 | Grid Power Outage | <ol style="list-style-type: none"> 1. Grid power outage. 2. AC line or AC switch is disconnected. | <ol style="list-style-type: none"> 1. The alarm will disappear automatically after grid power is restored. 2. Check if the AC line or AC switch is disconnected. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|-----------------------------|--|---|
| F02 | Grid Overvoltage Protection | Grid voltage exceeds the allowable range, or the high-voltage duration exceeds the HVRT setting value. | <ol style="list-style-type: none"> 1. If it occurs occasionally, it may be a short-term grid anomaly. The inverter will resume normal operation after detecting a normal grid, requiring no manual intervention. 2. If it occurs frequently, check if the grid voltage is within the allowable range. If not, contact the local power operator. If it is, you also need to modify the grid overvoltage protection point after obtaining consent from the local power operator. 3. If it cannot be restored for a long time, check if the AC side circuit breaker and output cables are properly connected. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|------------------------------|--|--|
| F03 | Grid Undervoltage Protection | Grid voltage is below the allowable range, or the low-voltage duration exceeds the LVRT setting value. | <ol style="list-style-type: none"> 1. If it occurs occasionally, it may be a short-term grid anomaly. The inverter will resume normal operation after detecting a normal grid, requiring no manual intervention. 2. If it occurs frequently, check if the grid voltage is within the allowable range. If not, contact the local power operator. If it is, you also need to modify the grid undervoltage protection point after obtaining consent from the local power operator. 3. If it cannot be restored for a long time, check if the AC side circuit breaker and output cables are properly connected. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|-----------------------------------|--|---|
| F04 | Grid Rapid Overvoltage Protection | Abnormal grid voltage detection or ultra-high voltage triggers the fault. | <p>1. If it occurs occasionally, it may be a short-term grid anomaly. The inverter will resume normal operation after detecting a normal grid, requiring no manual intervention.</p> <p>2. If it occurs frequently, check if the grid voltage is within the allowable range. If not, contact the local power operator. If it is, you also need to modify the grid undervoltage protection point after obtaining consent from the local power operator.</p> <p>3. If it cannot be restored for a long time, check if the AC side circuit breaker and output cables are properly connected.</p> |
| F05 | 10min Overvoltage Protection | The moving average of grid voltage within 10min exceeds the safety regulation specified range. | Check if the grid voltage has been operating at a high level for a long time. If it occurs frequently, check if the grid frequency is within the allowable range. If not, contact the local power operator. If it is, you also need to modify the grid 10min overvoltage protection point after obtaining consent from the local power operator. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|---------------------|--|---|
| F06 | Grid Overfrequency | Grid anomaly: The actual grid frequency is higher than the local grid standard requirements. | <p>1. If it occurs occasionally, it may be a short-term grid anomaly. The inverter will resume normal operation after detecting a normal grid, requiring no manual intervention.</p> <p>2. If it occurs frequently, check if the grid frequency is within the allowable range. If not, contact the local power operator. If it is, you also need to modify the grid overfrequency protection point after obtaining consent from the local power operator.</p> |
| F07 | Grid Underfrequency | Grid anomaly: The actual grid frequency is lower than the local grid standard requirements. | <p>1. If it occurs occasionally, it may be a short-term grid anomaly. The inverter will resume normal operation after detecting a normal grid, requiring no manual intervention.</p> <p>2. If it occurs frequently, check if the grid frequency is within the allowable range. If not, contact the local power operator. If it is, you also need to modify the grid overfrequency protection point after obtaining consent from the local power operator.</p> |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|----------------------------|--|--|
| F08 | Grid Frequency Instability | Grid anomaly: The rate of change of the actual grid frequency does not comply with local grid standards. | <p>1. If it occurs occasionally, it may be a short-term grid anomaly. The inverter will resume normal operation after detecting a normal grid, requiring no manual intervention.</p> <p>2. If it occurs frequently, check if the grid frequency is within the allowable range. If not, contact the local power operator.</p> |
| F09 | Anti-islanding Protection | The grid has been disconnected, but grid voltage is maintained due to the presence of loads. Grid connection is stopped according to safety protection requirements. | <p>1. If it occurs occasionally, it may be a short-term grid anomaly. The inverter will resume normal operation after detecting a normal grid, requiring no manual intervention.</p> <p>2. If it occurs frequently, check if the grid frequency is within the allowable range. If not, contact the local power operator.</p> |
| F10 | LVRT Undervoltage Fault | Grid anomaly: The duration of abnormal grid voltage exceeds the time specified by the HVRT/LVRT. | <p>1. If it occurs occasionally, it may be a short-term grid anomaly. The inverter will resume normal operation after detecting a normal grid, requiring no manual intervention.</p> <p>2. If it occurs frequently, check if the grid voltage and frequency are within the allowable range and stable. If not, contact the local power operator.</p> |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|----------------------|--|--|
| F11 | HVRT Overvoltage | Grid anomaly: The duration of abnormal grid voltage exceeds the time specified by the HVRT/LVRT. | <p>1. If it occurs occasionally, it may be a short-term grid anomaly. The inverter will resume normal operation after detecting a normal grid, requiring no manual intervention.</p> <p>2. If it occurs frequently, check if the grid voltage and frequency are within the allowable range and stable. If not, contact the local power operator.</p> |
| F12 | 30mA GFCI Protection | The input-to-ground insulation impedance becomes low during inverter operation. | <p>1. If it occurs occasionally, it may be caused by occasional external line anomalies. It will resume normal operation after the fault is cleared, requiring no manual intervention.</p> <p>2. If it occurs frequently or cannot be restored for a long time, check if the PV string's impedance to ground is too low.</p> |
| F13 | 60mA GFCI Protection | The input-to-ground insulation impedance becomes low during inverter operation. | <p>1. If it occurs occasionally, it may be caused by occasional external line anomalies. It will resume normal operation after the fault is cleared, requiring no manual intervention.</p> <p>2. If it occurs frequently or cannot be restored for a long time, check if the PV string's impedance to ground is too low.</p> |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|--------------------------------|--|---|
| F14 | 150mA GFCI Protection | The input-to-ground insulation impedance becomes low during inverter operation. | <p>1. If it occurs occasionally, it may be caused by occasional external line anomalies. It will resume normal operation after the fault is cleared, requiring no manual intervention.</p> <p>2. If it occurs frequently or cannot be restored for a long time, check if the PV string's impedance to ground is too low.</p> |
| F15 | GFCI Gradual Change Protection | The input-to-ground insulation impedance becomes low during inverter operation. | <p>1. If it occurs occasionally, it may be caused by occasional external line anomalies. It will resume normal operation after the fault is cleared, requiring no manual intervention.</p> <p>2. If it occurs frequently or cannot be restored for a long time, check if the PV string's impedance to ground is too low.</p> |
| F16 | DCI Level 1 Protection | The DC component of the inverter output current is higher than the safety regulation or the machine's default allowable range. | <p>1. If it is caused by an external fault, the inverter will automatically resume normal operation after the fault disappears, requiring no manual intervention.</p> <p>2. If this alarm occurs frequently, affecting the normal power generation of the power station, contact the distributor or after-sales service center.</p> |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|------------------------|--|--|
| F17 | DCI Level 2 Protection | The DC component of the inverter output current is higher than the safety regulation or the machine's default allowable range. | <ol style="list-style-type: none"> 1. If it is caused by an external fault, the inverter will automatically resume normal operation after the fault disappears, requiring no manual intervention. 2. If this alarm occurs frequently, affecting the normal power generation of the power station, contact the distributor or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|---------------------------|--|---|
| F18 | Low Insulation Resistance | <ol style="list-style-type: none"> 1. PV string shorted to protective earth. 2. The PV string installation environment is long-term humid and the line has poor insulation to ground. 3. Battery port line has low impedance to ground. | <ol style="list-style-type: none"> 1. Check the impedance of the PV string/battery port to protective earth. A value greater than 80kΩ is normal. If the checked value is less than 80kΩ, locate and rectify the short-circuit point. 2. Check if the inverter's protective earth wire is correctly connected. 3. If it is confirmed that the impedance is indeed lower than the default value in rainy/overcast environments, reset the inverter's "Insulation Impedance Protection Point" via the App. <p>For inverters in the Australian and New Zealand markets, the following additional alarm methods apply when an insulation impedance fault occurs:</p> <ol style="list-style-type: none"> 1. The inverter is equipped with a buzzer. When a fault occurs, the buzzer sounds continuously for 1 minute; if the fault is not resolved, the buzzer sounds again every 30 minutes. 2. If the inverter is added to the monitoring platform and alarm notification methods are set, alarm information can be sent to the customer via email. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|-----------------------------------|---|--|
| F19 | Grounding Abnormal | 1. The inverter's protective earth wire is not connected. 2. When the PV string output is grounded, the inverter output side is not connected to an isolation transformer. | 1. Confirm if the inverter's protective earth wire is not properly connected. 2. In scenarios where the PV string output is grounded, confirm if the inverter output side is connected to an isolation transformer. |
| F20 | Hardware Anti-backfeed Protection | Load abnormal fluctuation | 1. If it is caused by an external fault, the inverter will automatically resume normal operation after the fault disappears, requiring no manual intervention. 2. If this alarm occurs frequently, affecting the normal power generation of the power station, contact the distributor or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|--------------------|---|---|
| F21 | Internal Comm Loss | Sub DSP1 communication timeout - Main DSP, Sub DSP2 communication timeout - Main DSP, Sub DSP2 communication timeout - Sub DSP1, Main DSP communication timeout - Sub DSP1, Main DSP communication timeout - Sub DSP2 or Sub DSP1 communication timeout - Sub DSP2: 1. Chip not powered on 2. Chip program version error | Disconnect the AC output side switch and DC input side switch, wait for 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, contact the distributor or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|------------------------------------|--|-----------------------------|
| | | Main DSP can module error, Sub DSP1 can module error or Sub DSP2 can module error: 1. Frame format error 2. Parity check error 3. can bus offline 4. Hardware CRC check error 5. Control bit is receive (transmit) during transmission (reception) 6. Transmission to an unauthorized unit | |
| F22 | Generator Waveform Detection Fault | 1. This fault will be displayed continuously when the generator is not connected; 2. When the generator is operating, failure to meet generator safety regulations will trigger this fault. | |
| F23 | Generator Abnormal Connection | | |
| F24 | Generator Voltage Low | | |
| F25 | Generator Voltage High | | |
| F26 | Generator Frequency Low | | |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|----------------------------------|---|---|
| F27 | Generator Frequency High | | <p>1. Ignore this fault when the generator is not connected;</p> <p>2. When this fault occurs due to a generator fault, it is normal. Wait for a period after the generator recovers, and the fault will clear automatically;</p> <p>3. This fault does not affect the normal operation of off-grid mode.</p> <p>4. When both the generator and grid are connected and meet safety requirements, the grid has priority for grid connection, and the system will operate in grid-connected status.</p> |
| F28 | Parallel I/O Self-check Abnormal | Parallel communication cable is not securely connected or parallel IO chip is damaged | Check if the parallel communication cable is securely connected, then check if the IO chip is damaged. If yes, replace the IO chip. |
| F29 | Parallel Grid Line Reversed | Some machines' grid lines are connected in reverse with others | Reconnect the grid lines correctly. |
| F30 | AC HCT check Abnormal | AC sensor has sampling abnormality | Disconnect the AC output side switch and DC input side switch, wait for 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, contact the distributor or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|---------------------------|--|---|
| F31 | GFCI HCT Check Abnormal | Leakage current sensor has sampling abnormality | Disconnect the AC output side switch and DC input side switch, wait for 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, contact the distributor or after-sales service center. |
| F32 | Inverter Internal Failure | Inverter has a fault | Disconnect the AC output side switch and DC input side switch, wait for 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, contact the distributor or after-sales service center. |
| F33 | Flash Read/Write Error | Possible causes: flash content changed; flash lifespan exhausted; | <ol style="list-style-type: none"> 1. Upgrade to the latest program version. 2. Contact the distributor or after-sales service center. |
| F34 | AFCI Check Failure | During the arc self-check process, the arc detection module did not detect an arc fault as expected. | Disconnect the AC output side switch and DC input side switch, wait for 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, contact the distributor or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|-------------------------|--|--|
| F35 | Cabinet Overtemperature | Cabinet temperature is too high, possible causes: 1. Inverter installation location is not ventilated. 2. Ambient temperature is too high. 3. Internal fan operation is abnormal. | 1. Check if the ventilation at the inverter installation location is good and if the ambient temperature exceeds the maximum allowable ambient temperature range. 2. If ventilation is poor or ambient temperature is too high, improve its ventilation and heat dissipation conditions. 3. If ventilation and ambient temperature are both normal, contact the distributor or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|-----------------|---|---|
| F36 | Bus Overvoltage | BUS overvoltage, possible causes: 1. PV voltage is too high; 2. Inverter BUS voltage sampling is abnormal; 3. The isolation effect of the dual-split transformer at the inverter rear end is poor, causing mutual influence when two inverters are connected in parallel, with one inverter reporting DC overvoltage during grid connection; | Disconnect the AC output side switch and DC input side switch, wait for 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, contact the distributor or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|------------|------------------------------------|---|---|
| F37 | PV Input Overvoltage | PV input voltage is too high, possible cause: PV array configuration error, too many PV panels connected in series per string, causing the string's open-circuit voltage to be higher than the inverter's maximum operating voltage. | Check the series configuration of the corresponding PV array string to ensure the string's open-circuit voltage is not higher than the inverter's maximum operating voltage. After the PV array is correctly configured, the inverter alarm will disappear automatically. |
| F38 | PV Continuous Hardware Overcurrent | 1. Module configuration unreasonable. 2. Hardware damaged. | Disconnect the AC output side switch and DC input side switch, wait for 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, contact the distributor or after-sales service center. |
| F39 | PV Continuous Software Overcurrent | 1. Module configuration unreasonable. 2. Hardware damaged. | Disconnect the AC output side switch and DC input side switch, wait for 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, contact the distributor or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestions |
|-------------------|---|------------------------------|---|
| F40, F98 | String Reverse Connection (String 1-n) n: Determined based on the actual number of inverter strings. | PV string reverse connection | Check if the string is reversely connected. |

8.5.2.1.2 Troubleshooting (Fault Codes F41-F80)

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|-------------------|-------------------------|---|--|
| F41 | Generator Port Overload | <ol style="list-style-type: none"> 1. Off-grid side output exceeds specification requirements. 2. Off-grid side short circuit. 3. Off-grid terminal voltage is too low. 4. When used as a heavy load port, the heavy load exceeds specification requirements. | <ol style="list-style-type: none"> 1. Confirm the off-grid side output voltage, current, power and other data to identify the cause of the problem. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|------------|--|---|--|
| F42 | DC Arcing Failure (String 1-n) n: Determined by the actual number of inverter strings. | <ol style="list-style-type: none"> 1. Loose DC side connection terminals. 2. Poor contact at DC side connection terminals. 3. Damaged DC cable cores causing poor contact. | <ol style="list-style-type: none"> 1. After the unit reconnects to the grid, check if the voltage and current of each string abnormally decrease or become zero. 2. Check if the DC side terminals are securely connected. |
| F43 | Grid Waveform Abnormal | Utility grid abnormality: Abnormal grid voltage detection triggers the fault. | <ol style="list-style-type: none"> 1. If it occurs occasionally, it may be due to a short-term grid abnormality. The inverter will resume normal operation after detecting a normal grid, requiring no manual intervention. 2. If it occurs frequently, please check if the grid voltage and frequency are within the allowable range and stable. If not, please contact the local power operator. |
| F44 | Grid Phase Loss | Utility grid abnormality: Single-phase voltage dip on the grid. | <ol style="list-style-type: none"> 1. If it occurs occasionally, it may be due to a short-term grid abnormality. The inverter will resume normal operation after detecting a normal grid, requiring no manual intervention. 2. If it occurs frequently, please check if the grid voltage and frequency are within the allowable range and stable. If not, please contact the local power operator. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|-------------------|---|---|---|
| F45 | Grid Voltage Imbalance | Excessive difference in grid phase voltages. | <p>1. If it occurs occasionally, it may be due to a short-term grid abnormality. The inverter will resume normal operation after detecting a normal grid, requiring no manual intervention.</p> <p>2. If it occurs frequently, please check if the grid voltage and frequency are within the allowable range and stable. If not, please contact the local power operator.</p> |
| F46 | Grid Phase Sequence Failure | Inverter and grid wiring abnormality: Wiring is not in positive sequence. | <p>1. Check if the inverter and grid wiring are in positive sequence. The fault will automatically disappear after correct wiring (e.g., swapping any two live wires).</p> <p>2. If the fault persists despite correct wiring, please contact the dealer or after-sales service center.</p> |
| F47 | Grid Rapid Shutdown Protection | Quickly shuts down output after detecting a grid power outage condition. | The fault automatically disappears after grid power supply is restored. |
| F48 | Grid Neutral Wire Loss (Split-phase Grid) | Loss of neutral wire in a split-phase grid. | <p>1. The alarm automatically disappears after grid power supply is restored.</p> <p>2. Check if the AC line or AC switch is disconnected.</p> |
| F49 | L-PE Short Circuit | Low impedance or short circuit between output phase line and PE. | Measure the impedance between the output phase line and PE, locate the position with low impedance and repair it. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|-------------------|--|--|---|
| F50 | DCV Level 1 Protection | Abnormal load fluctuation. | <p>1. If it is caused by an external fault, the inverter will automatically resume normal operation after the fault disappears, requiring no manual intervention.</p> <p>2. If this alarm occurs frequently, affecting normal power generation of the plant, please contact the dealer or after-sales service center.</p> |
| F51 | DCV Level 2 Protection | Abnormal load fluctuation. | |
| F52 | Leakage Current (GFCI) Multiple Fault Shutdown | North American safety regulations require manual reset or waiting 24h for recovery after multiple faults, no automatic recovery. | Please check if the PV string-to-ground impedance is too low. |
| F53 | DC Arcing (AFCI) Multiple Fault Shutdown | North American safety regulations require manual reset or waiting 24h for recovery after multiple faults, no automatic recovery. | <p>1. After the unit reconnects to the grid, check if the voltage and current of each string abnormally decrease or become zero.</p> <p>2. Check if the DC side terminals are securely connected.</p> |
| F54 | External Communication Link Failure | External device communication loss for the inverter. Possible causes: peripheral power issue, communication protocol mismatch, corresponding peripheral not configured, etc. | Determine based on the actual model and enabled detection bits. Peripherals not supported by certain models will not be detected. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|-------------------|--|--|---|
| F55 | Back-up Port Overload Fault | Prevents the inverter from continuously outputting overload. | Turn off some off-grid loads to reduce the inverter's off-grid output power. |
| F56 | Back-up Port Overvoltage Fault | Prevents inverter output overvoltage from damaging loads. | 1. If it occurs occasionally, it may be caused by load switching and requires no manual intervention. 2. If it occurs frequently, please contact the dealer or after-sales service center. |
| F57 | External Box Fault | Waiting too long for Box relay switching during grid-to-off-grid transition. | 1. Check if the Box is working normally. 2. Check if the Box communication wiring is correct. |
| F58 | CT Loss Fault | CT connection wire disconnected (Japanese safety regulation requirement). | Check if the CT wiring is correct. |
| F59 | Parallel CAN Communication Abnormality | Parallel communication cable not securely connected or some units are offline. | Check if all units are powered on and if the parallel communication cables are securely connected. |
| F60 | Parallel Back-up Connection Reversed | Backup wiring of some units is reversed with others. | Reconnect the backup wiring. |
| F61 | Inverter Soft Start Failure | Inverter soft start failure during off-grid cold start. | Check if the inverter module is damaged. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|-------------------|-----------------------------|--|--|
| F62 | AC HCT Failure | HCT sensor abnormality exists. | Disconnect the AC output side switch and DC input side switch, wait 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F63 | GFCI HCT Failure | Leakage current sensor abnormality exists. | Disconnect the AC output side switch and DC input side switch, wait 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F64 | Inverter Internal Failure | Inverter fault exists. | Disconnect the AC output side switch and DC input side switch, wait 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F65 | AC Terminal Overtemperature | AC terminal temperature is too high. Possible causes: 1. Inverter installation location lacks ventilation. 2. Ambient temperature is too high. 3. Internal fan operation is abnormal. | 1. Check if the ventilation at the inverter installation location is adequate and if the ambient temperature exceeds the maximum allowable range. 2. If ventilation is poor or ambient temperature is too high, improve its ventilation and heat dissipation conditions. 3. If both ventilation and ambient temperature are normal, please contact the dealer or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|------------|------------------------------|--|--|
| F66 | INV Module Overtemperature | Inverter module temperature is too high. Possible causes: 1. Inverter installation location lacks ventilation. 2. Ambient temperature is too high. 3. Internal fan operation is abnormal. | 1. Check if the ventilation at the inverter installation location is adequate and if the ambient temperature exceeds the maximum allowable range. 2. If ventilation is poor or ambient temperature is too high, improve its ventilation and heat dissipation conditions. 3. If both ventilation and ambient temperature are normal, please contact the dealer or after-sales service center. |
| F67 | Boost Module Overtemperature | Boost module temperature is too high. Possible causes: 1. Inverter installation location lacks ventilation. 2. Ambient temperature is too high. 3. Internal fan operation is abnormal. | 1. Check if the ventilation at the inverter installation location is adequate and if the ambient temperature exceeds the maximum allowable range. 2. If ventilation is poor or ambient temperature is too high, improve its ventilation and heat dissipation conditions. 3. If both ventilation and ambient temperature are normal, please contact the dealer or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|-------------------|------------------------------|--|--|
| F68 | AC Capacitor Overtemperature | Output filter capacitor temperature is too high. Possible causes: 1. Inverter installation location lacks ventilation. 2. Ambient temperature is too high. 3. Internal fan operation is abnormal. | 1. Check if the ventilation at the inverter installation location is adequate and if the ambient temperature exceeds the maximum allowable range. 2. If ventilation is poor or ambient temperature is too high, improve its ventilation and heat dissipation conditions. 3. If both ventilation and ambient temperature are normal, please contact the dealer or after-sales service center. |
| F69 | PV IGBT Short Circuit Fault | Possible causes: 1. IGBT short circuit. 2. Inverter sampling circuit abnormality. | Disconnect the AC output side switch and DC input side switch, wait 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F70 | PV IGBT Open Circuit Fault | 1. Software issue causing no PWM generation. 2. Drive circuit abnormality. 3. IGBT open circuit. | |
| F71 | NTC Abnormality | NTC temperature sensor abnormality. | Disconnect the AC output side switch and DC input side switch, wait 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|-------------------|----------------------------|--|---|
| F72 | PWM Abnormal | Abnormal PWM waveform detected. | Disconnect the AC output side switch and DC input side switch, wait 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F73 | CPU Interrupt Abnormality | CPU interrupt abnormality occurred. | Disconnect the AC output side switch and DC input side switch, wait 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F74 | Microelectronics Fault | Functional safety detection detected an abnormality. | Disconnect the AC output side switch and DC input side switch, wait 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F75 | PV HCT Fault | Boost current sensor abnormality. | Disconnect the AC output side switch and DC input side switch, wait 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F76 | 1.5V Reference Abnormality | Reference circuit fault. | Disconnect the AC output side switch and DC input side switch, wait 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F77 | 0.3V Reference Abnormality | Reference circuit fault. | |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|-------------------|--------------------------------|--|---|
| F78 | CPLD Version Recognition Error | CPLD version recognition error. | Disconnect the AC output side switch and DC input side switch, wait 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F79 | CPLD Communication Fault | CPLD and DSP communication content error or timeout. | Disconnect the AC output side switch and DC input side switch, wait 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F80 | Model Identification Fault | Fault related to model identification error. | Disconnect the AC output side switch and DC input side switch, wait 5 minutes, then close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |

8.5.2.1.3 Troubleshooting (Fault Codes F81-F121)

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|-------------------|-------------------|--------------------|---|
| F81 | P-Bus Overvoltage | | Disconnect the AC output side switch and the DC input side switch, wait for 5 minutes, then close the AC output side switch and the DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|------------|------------------------------|---|---|
| F82 | N-Bus Overvoltage | BUS overvoltage, possible causes: 1. PV voltage is too high; 2. Inverter BUS voltage sampling is abnormal; 3. Poor isolation effect of the split-phase transformer at the inverter output, causing mutual interference when two inverters are grid-connected, with one inverter reporting DC overvoltage during grid connection; | |
| F83 | Bus Overvoltage (Sub CPU1) | | Disconnect the AC output side switch and the DC input side switch, wait for 5 minutes, then close the AC output side switch and the DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F84 | P-Bus Overvoltage (Sub CPU1) | | |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|------------|------------------------------|---|---|
| F85 | N-Bus Overvoltage (Sub CPU1) | BUS overvoltage, possible causes: 1. PV voltage is too high; 2. Inverter BUS voltage sampling is abnormal; 3. Poor isolation effect of the split-phase transformer at the inverter output, causing mutual interference when two inverters are grid-connected, with one inverter reporting DC overvoltage during grid connection; | |
| F86 | Bus Overvoltage (Sub CPU2) | | Disconnect the AC output side switch and the DC input side switch, wait for 5 minutes, then close the AC output side switch and the DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F87 | P-Bus Overvoltage (Sub CPU2) | | |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|------------|------------------------------|---|---|
| F88 | N-Bus Overvoltage (Sub CPU2) | BUS overvoltage, possible causes: 1. PV voltage is too high; 2. Inverter BUS voltage sampling is abnormal; 3. Poor isolation effect of the split-phase transformer at the inverter output, causing mutual interference when two inverters are grid-connected, with one inverter reporting DC overvoltage during grid connection; | |
| F89 | P-Bus Overvoltage (CPLD) | | Disconnect the AC output side switch and the DC input side switch, wait for 5 minutes, then close the AC output side switch and the DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|------------|-----------------------------|---|---|
| F90 | N-Bus Overvoltage(CPLD) | BUS overvoltage, possible causes: 1. PV voltage is too high; 2. Inverter BUS voltage sampling is abnormal; 3. Poor isolation effect of the split-phase transformer at the inverter output, causing mutual interference when two inverters are grid-connected, with one inverter reporting DC overvoltage during grid connection; | |
| F91 | FlyCap Software Overvoltage | FlyCap overvoltage, possible causes: 1. PV voltage is too high; 2. Inverter FlyCap voltage sampling is abnormal; | Disconnect the AC output side switch and the DC input side switch, wait for 5 minutes, then close the AC output side switch and the DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F92 | FlyCap Hardware Overvoltage | | |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|------------|---------------------------|---|--|
| F93 | FlyCap Undervoltage | FlyCap undervoltage, possible causes: 1. PV energy is insufficient; 2. Inverter FlyCap voltage sampling is abnormal; | Disconnect the AC output side switch and the DC input side switch, wait for 5 minutes, then close the AC output side switch and the DC input side switch. If the fault persists, please contact the dealer or after-sales service center |
| F94 | FlyCap Precharge Failure | FlyCap precharge failure, possible causes: 1. PV energy is insufficient; 2. Inverter FlyCap voltage sampling is abnormal; | Disconnect the AC output side switch and the DC input side switch, wait for 5 minutes, then close the AC output side switch and the DC input side switch. If the fault persists, please contact the dealer or after-sales service center |
| F95 | FlyCap Precharge Abnormal | 1. Control loop parameters are unreasonable 2. Hardware damage | Disconnect the AC output side switch and the DC input side switch, wait for 5 minutes, then close the AC output side switch and the DC input side switch. If the fault persists, please contact the dealer or after-sales service center |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|------------|--|--|--|
| F96, F97 | String Overcurrent(String1-n) n: Determined based on the actual number of inverter strings | Possible causes: 1. String overcurrent; 2. String current sensor is abnormal | Disconnect the AC output side switch and the DC input side switch, wait for 5 minutes, then close the AC output side switch and the DC input side switch. If the fault persists, please contact the dealer or after-sales service center |
| F99, F100 | String Missing(String1-n) n: Determined based on the actual number of inverter strings | String fuse is open (if present) | Check if the fuse is open. |
| F101 | Battery 1 Precharge fault | Battery 1 precharge circuit fault (precharge resistor burned out, etc.) | Check if the precharge circuit is in good condition, and whether the battery voltage matches the bus voltage after the battery is powered on. If not, please contact the dealer or after-sales service center. |
| F102 | Battery 1 Relay Failure | Battery 1 relay cannot operate normally | After the battery is powered on, check if the battery relay is working, and if a closing sound is heard. If it does not operate, please contact the dealer or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|-------------------|----------------------------------|---|---|
| F103 | Battery 1 Connection Overvoltage | Battery 1 connection voltage exceeds the machine's rated range | Confirm if the battery voltage is within the machine's rated range. |
| F104 | Battery 2 Precharge fault | Battery 2 precharge circuit fault (precharge resistor burned out, etc.) | Check if the precharge circuit is in good condition, and whether the battery voltage matches the bus voltage after the battery is powered on. If not, please contact the dealer or after-sales service center. |
| F105 | Battery 2 Relay Failure | Battery 2 relay cannot operate normally | After the battery is powered on, check if the battery relay is working, and if a closing sound is heard. If it does not operate, please contact the dealer or after-sales service center. |
| F106 | Battery 2 Connection Overvoltage | Battery 2 connection voltage exceeds the machine's rated range | Confirm if the battery voltage is within the machine's rated range. |
| F107 | On-grid PWM Sync Failure | Abnormalities occurred during carrier synchronization grid connection | <ol style="list-style-type: none"> 1. Check if the synchronization cable connection is normal 2. Check if the master/slave settings are normal; 3. Disconnect the AC output side switch and the DC input side switch, wait for 5 minutes, then close the AC output side switch and the DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F108 | DSP Communication fault | - | - |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|-------------------|--------------------------|---|--|
| F109 | External STS fault | Abnormal cable connection between the inverter and the STS | Check if the wiring sequence of the harness between the inverter and the STS corresponds correctly one by one. |
| F110 | Export Limit Protection | <ol style="list-style-type: none"> 1. Inverter reports error and disconnects from grid 2. meter communication is unstable 3. Reverse power flow condition occurs | <ol style="list-style-type: none"> 1. Check if the inverter has other error messages. If yes, perform targeted troubleshooting; 2. Check if the meter connection is reliable; 3.If this alarm occurs frequently, affecting normal power generation of the power station, please contact the dealer or after-sales service center. |
| F111 | Bypass Overload | - | - |
| F112 | Black Start Failure | - | - |
| F113 | Offgrid AC Ins Volt High | - | - |
| F114 | Relay Failure2 | <p>Relay abnormality, causes:</p> <ol style="list-style-type: none"> 1. Relay abnormality (relay short circuit) 2. Relay sampling circuit is abnormal. 3. AC side wiring is abnormal (there may be poor connection or short circuit) | Disconnect the AC output side switch and the DC input side switch, wait for 5 minutes, then close the AC output side switch and the DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|-------------------|------------------------------------|--|---|
| F115 | SVG Precharge Disabled | SVG precharge hardware failure | Contact the dealer or after-sales service center. |
| F116 | Nighttime SVG PID Prevention fault | PID prevention hardware abnormality | |
| F117 | DSP Version Recognition Error | DSP software version recognition error | Disconnect the AC output side switch and the DC input side switch, wait for 5 minutes, then close the AC output side switch and the DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F118 | MOS Continuous Overvoltage | <ol style="list-style-type: none"> 1. Software issue causing inverter drive to turn off earlier than flyback drive; 2. Inverter drive circuit abnormal causing failure to turn on; 3. PV voltage is too high; 4. Mos voltage sampling is abnormal; | Disconnect the AC output side switch and the DC input side switch, wait for 5 minutes, then close the AC output side switch and the DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F119 | Bus Short Circuit fault | Hardware damage | If the inverter remains offline after a BUS short circuit fault occurs, please contact the dealer or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|------------|------------------------------|---|---|
| F120 | Bus Sampling Abnormality | 1. BUS voltage sampling hardware fault | Disconnect the AC output side switch and the DC input side switch, wait for 5 minutes, then close the AC output side switch and the DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F121 | DC Side Sampling Abnormality | 1. BUS voltage sampling hardware fault 2. Battery voltage sampling hardware fault 3. Dcrlly relay fault | Disconnect the AC output side switch and the DC input side switch, wait for 5 minutes, then close the AC output side switch and the DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|------------|------------------------------|--|--|
| F122 | PV Access Mode Setting Error | <p>There are three PV access modes, taking four MPPT channels as an example:</p> <ol style="list-style-type: none"> 1. Parallel mode: i.e., AAAA mode (same source mode), PV1-PV4 are from the same source, all 4 PV channels are connected to the same solar panel 2. Partial parallel mode: i.e., AACC mode, PV1 and PV2 are connected from the same source, PV3 and PV4 are connected from the same source 3. Independent mode: i.e., ABCD mode (different sources), PV1, PV2, PV3, PV4 are connected independently, each of the 4 PV channels is connected to one solar panel <p>If the actual PV</p> | <p>Check if the PV access mode is set correctly (ABCD, AACC, AAAA), reset the PV access mode correctly.</p> <ol style="list-style-type: none"> 1. Confirm that the actual connected PV channels are correctly wired; 2. If the PV is correctly connected, check the currently set "PV Access Mode" via the APP or screen to see if it corresponds to the actual access mode; 3. If the currently set "PV Access Mode" does not match the actual access mode, use the APP or screen to set the "PV Access Mode" to the mode consistent with the actual situation. After setting, disconnect the PV and AC power supply and restart; 4. After setting, if the current "PV Access Mode" matches the actual access mode, but this fault still occurs, please contact the dealer or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Recommendation |
|------------|------------|--|--------------------------------|
| | | access mode does not match the PV access mode set on the device, this fault will be reported | |

8.5.2.1.4 Troubleshooting (Fault Codes F122-F163)

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestion |
|------------|------------------------------------|--|---|
| F123 | Multi-channel PV Phase Error | PV Input Mode Setting Error | <p>Check if the PV Access Mode is set correctly (ABCD, AACC, AAAA). Reset the PV Access Mode correctly.</p> <ol style="list-style-type: none"> 1. Confirm that each actual PV channel is correctly connected. 2. If the PV is correctly connected, check via APP or screen whether the currently set "PV Access Mode" corresponds to the actual connection mode. 3. If the currently set "PV Access Mode" does not match the actual connection mode, use the APP or screen to set the "PV Access Mode" to the mode consistent with the actual situation. After setting, disconnect and restart the PV and AC power supply. 4. After setting, if the current "PV Access Mode" matches the actual connection mode but this fault still occurs, please contact the dealer or after-sales service center. |
| F124 | Battery 1 Reverse Connection fault | Battery 1 Positive and Negative Poles Reversed | Check if the polarities of the Battery and the machine terminals are consistent. |
| F125 | Battery 2 Reverse Connection fault | Battery 2 Positive and Negative Poles Reversed | Check if the polarities of the Battery and the machine terminals are consistent. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestion |
|-------------------|-----------------------------|--|---|
| F126 | Abnormal Battery Connection | Abnormal Battery Connection | Check if the Battery is working normally. |
| F127 | BAT Overtemperature | Battery temperature is too high. Possible causes: 1. Poor ventilation at the inverter installation location. 2. Ambient temperature is too high. 3. Internal fan operation is abnormal. | Disconnect the AC output side switch and DC input side switch. After 5 minutes, close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F128 | Ref Voltage Abnormal | Reference circuit fault | Disconnect the AC output side switch and DC input side switch. After 5 minutes, close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F129 | Cabinet Under Temperature | Cabinet temperature is too low. Possible cause: Ambient temperature is too low. | Disconnect the AC output side switch and DC input side switch. After 5 minutes, close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F130 | AC Side SPD fault | AC Side Surge Protective Device Failure | Replace the AC side surge protective device. |
| F131 | DC Side SPD fault | DC Side Surge Protective Device Failure | Replace the DC side surge protective device. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestion |
|------------|------------------------|---|---|
| F132 | Internal Fan Abnormal | Internal fan abnormal. Possible causes: 1. Abnormal fan power supply. 2. Mechanical fault (stall). 3. Fan aging or damage. | Disconnect the AC output side switch and DC input side switch. After 5 minutes, close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F133 | External Fan Abnormal | External fan abnormal. Possible causes: 1. Abnormal fan power supply. 2. Mechanical fault (stall). 3. Fan aging or damage. | Disconnect the AC output side switch and DC input side switch. After 5 minutes, close the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| F134 | PID Diagnosis Abnormal | PID hardware fault or PID paused due to high PV voltage. | No action required for PID pause warning caused by high PV voltage. For PID hardware fault, clear the PID fault by turning the PID switch off and then on, and replace the PID device. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestion |
|------------|--|--|--|
| F135 | Trip-Switch Trip Warning | Possible causes: Overcurrent or PV reverse connection caused the trip-switch to trip. | Contact the dealer or after-sales service center. The tripping reason was due to PV short circuit or reverse connection. Check if there is a history of PV short circuit warning or PV reverse connection warning. If present, maintenance personnel need to check the corresponding PV condition. After checking and confirming no fault, you can manually close the trip-switch and clear this warning via the APP interface's clear historical fault operation. |
| F136 | Historical PV IGBT Short Circuit Warning | Possible causes: Overcurrent caused the trip-switch to trip. | Contact the dealer or after-sales service center. Maintenance personnel need to check the Boost hardware and external string for faults according to the historical PV short circuit warning subcode. After checking and confirming no fault, this warning can be cleared via the APP interface's clear historical fault operation. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestion |
|-------------|--|---|---|
| F137 , F138 | Historical PV Reverse Connection Warning (String 1-n) (n: determined by the actual number of inverter strings) | Possible causes: PV reverse connection caused the trip-switch to trip. | Contact the dealer or after-sales service center. Maintenance personnel need to check if the corresponding string has a reverse connection according to the historical PV reverse connection warning subcode, and check if there is a voltage difference in the PV panel configuration. After checking and confirming no fault, this warning can be cleared via the APP interface's clear historical fault operation. |
| F139 | Flash Read/Write Error Warning | Possible causes: 1. Flash content changed. 2. Flash end of life reached. | 1. Upgrade to the latest firmware. 2. Contact the dealer or after-sales service center. |
| F140 | Meter Comm Loss | This warning may only occur after enabling anti-backflow function. Possible causes: 1. Meter not connected. 2. Incorrect wiring of the communication cable between the meter and the inverter. | Check the meter wiring and connect the meter correctly. After checking, if the fault persists, please contact the dealer or after-sales service center. |
| F141 | PV Panel Type Identification Failure | PV panel identification hardware abnormal | Contact the dealer or after-sales service center. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestion |
|-------------------|---|---|---|
| F142 | PV String Mismatch | PV string mismatch. Two strings under the same MPPT have different open-circuit voltage configurations. | Check the open-circuit voltage of the two strings. Configure strings with the same open-circuit voltage under the same MPPT. Prolonged string mismatch poses a safety hazard. |
| F143 | CT Not Connected | CT not connected | Check CT wiring. |
| F144 | CT Reverse Connection | CT reverse connection | Check CT wiring. |
| F145 | PE Loss | Ground wire not connected | Check the ground wire. |
| F146 | String Terminal High Temperature (String 1~8) | Register 37176 PV terminal temperature warning subcode 1 is set. | - |
| F147 | String Terminal High Temperature (String 9~16) | Register 37177 PV terminal temperature warning subcode 2 is set. | - |
| F148 | String Terminal High Temperature (String 17~20) | Register 37178 PV terminal temperature warning subcode 3 is set. | - |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestion |
|-------------------|---|---|---|
| F149 | Historical PV Reverse Connection Warning (String 33~48) | Possible causes: PV reverse connection caused the trip-switch to trip. | Contact the dealer or after-sales service center. Maintenance personnel need to check if the corresponding string has a reverse connection according to the historical PV reverse connection warning subcode, and check if there is a voltage difference in the PV panel configuration. After checking and confirming no fault, this warning can be cleared via the APP interface's clear historical fault operation. |
| F150 | Battery 1 Low Voltage | Battery voltage is below the set value. | - |
| F151 | Battery 2 Low Voltage | Battery voltage is below the set value. | - |
| F152 | Low Voltage of Battery Power | Battery not in charging mode, voltage below shutdown voltage. | - |
| F153 | Battery 1 High Voltage | - | - |
| F154 | Battery 2 High Voltage | - | - |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestion |
|-------------------|---|--|--|
| F155 | Online Low Insulation Resistance | <p>1. Photovoltaic string short circuit to protective earth.</p> <p>2. The photovoltaic string installation environment is humid for a long time and the line has poor insulation to ground.</p> | <p>1. Check the impedance of the photovoltaic string to the protective earth. If a short circuit is found, please rectify the short circuit point.</p> <p>2. Check if the inverter's protective earth wire is correctly connected.</p> <p>3. If it is confirmed that the impedance is indeed below the default value in rainy conditions, please reset the "Insulation Resistance Protection Point".</p> |
| F156 | Micro-grid Overload Warning | backup terminal input current is too high. | Occasional occurrence requires no action. If this warning occurs frequently, please contact the dealer or after-sales service center. |
| F157 | Manual Reset | - | - |
| F158 | Generator Phase Sequence Abnormal | - | - |
| F159 | Multiplexed Port Configuration Abnormal | Multiplexed (generator) port is configured for micro-grid or large load, but a generator is actually connected. | Use the APP to change the multiplexed (generator) port configuration. |
| F160 | EMS Forced Off-grid | EMS issued forced off-grid command, but off-grid function is not enabled. | Enable the off-grid function. |

| Fault Code | Fault Name | Fault Cause | Troubleshooting Suggestion |
|-------------------|-----------------------------------|--|---|
| F161 | Passive Anti-islanding Protection | - | - |
| F162 | Grid Type Fault | Actual grid type (two-phase or split-phase) does not match the set safety standard. | Switch to the corresponding safety standard according to the actual grid type. |
| F163 | Grid Phase Instability | Grid abnormal: The rate of change of grid voltage phase does not comply with local grid standards. | <p>1. If it occurs occasionally, it may be a temporary grid anomaly. The inverter will resume normal operation after detecting a normal grid, requiring no manual intervention.</p> <p>2. If it occurs frequently, please check if the grid frequency is within the allowable range. If not, please contact the local power operator.</p> |

8.5.2.1.5 Fault Phenomenon Handling

| Fault Name | Fault Cause | Troubleshooting Suggestion |
|-------------------------|--|--|
| Generator Failure | <ol style="list-style-type: none"> 1. This fault will be displayed continuously when the generator is not connected. 2. When the generator is operating, this fault will be triggered if generator safety regulations are not met. | <ol style="list-style-type: none"> 1. If the generator is not connected, ignore this fault; 2. If this fault appears when the generator malfunctions, this is normal. Wait for a period after the generator recovers, and the fault will clear automatically; 3. This fault does not affect the normal operation of off-grid mode. 4. When both the generator and grid are connected and meet safety requirements, the grid has priority for grid connection, and the system will operate in grid-tied mode. |
| BMS Status Bit Error | BMS module failure | Turn off the AC output side switch and DC input side switch, wait for 5 minutes, then turn on the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |
| Ambient Overtemperature | <ol style="list-style-type: none"> 1. Poor machine ventilation 2. Hot air flow back to the ambient temperature sampling point | Turn off the AC output side switch and DC input side switch, wait for 5 minutes, then turn on the AC output side switch and DC input side switch. If the fault persists, please contact the dealer or after-sales service center. |

| Fault Name | Fault Cause | Troubleshooting Suggestion |
|-------------------------------------|--|---|
| PV Terminal Overtemperature | PV terminal overtemperature, possible causes: 1. Poor ventilation at the inverter installation location. 2. Ambient temperature is too high. 3. Internal fan operation is abnormal. | 1. Check if the ventilation at the inverter installation location is adequate and if the ambient temperature exceeds the maximum allowable range. 2. If ventilation is poor or the ambient temperature is too high, please improve the ventilation and heat dissipation conditions. 3. If both ventilation and ambient temperature are normal, please contact the dealer or after-sales service center. |
| BAT Terminal Overtemperature | BAT terminal overtemperature, possible causes: 1. Poor ventilation at the inverter installation location. 2. Ambient temperature is too high. | 1. Check if the ventilation at the inverter installation location is adequate and if the ambient temperature exceeds the maximum allowable range. |
| AC Terminal Overtemperature Warning | AC terminal overtemperature, possible causes: 1. Poor ventilation at the inverter installation location. 2. Ambient temperature is too high. 3. Internal fan operation is abnormal. | 2. If ventilation is poor or the ambient temperature is too high, please improve the ventilation and heat dissipation conditions. 3. If both ventilation and ambient temperature are normal, please contact the dealer or after-sales service center. |

| Fault Name | Fault Cause | Troubleshooting Suggestion |
|--------------------------------------|---|---|
| BAT Terminal Overtemperature Warning | BAT terminal overtemperature, possible causes: 1. Poor ventilation at the inverter installation location. 2. Ambient temperature is too high. | 1. Check if the ventilation at the inverter installation location is adequate and if the ambient temperature exceeds the maximum allowable range. 2. If ventilation is poor or the ambient temperature is too high, please improve the ventilation and heat dissipation conditions. 3. If both ventilation and ambient temperature are normal, please contact the dealer or after-sales service center. |
| Three-phase on-grid fault | Three-phase external wiring error | Reconnect the wiring. |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|---------------------------------------|---|---|
| Parallel Comm Timeout Shutdown | In a parallel system, if a slave unit has not communicated with the master for over 400 seconds. | Check if the parallel communication harness is securely connected. Check for duplicate slave addresses. |
| Three-phase off-grid phase loss fault | Phase loss in a three-phase system group. | 1. Check if all inverters are powered on. 2. Check if each phase in the three-phase group is connected to an inverter. |
| EPO | External triggering of the hardware emergency stop button or remote triggering of the emergency stop command. | 1. If triggered intentionally via remote shutdown, it can be ignored. 2. If not triggered intentionally, please contact the distributor or after-sales service center. |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|----------------------------------|--|--|
| One-Touch Shutdown | Check via the App if the one-touch shutdown function is enabled. | Disable the one-touch shutdown. |
| Offline Shutdown | - | - |
| Remote Shutdown | - | - |
| On-Grid SPD Fault | - | - |
| Off-Grid SPD Fault | - | - |
| Child Node Communication Failure | Internal communication abnormality. | Restart the unit and observe if the fault clears. |
| DG Communication Failure | Abnormal communication link between the control board and the diesel generator. | <ol style="list-style-type: none"> 1. Check the communication harness link and observe if the fault clears. 2. Try restarting the unit and observe if the fault clears. 3. If the fault persists after restart, contact the after-sales service center. |
| Battery Over Voltage | <ol style="list-style-type: none"> 1. Single cell voltage too high. 2. Voltage sensing line abnormality. | Record the fault phenomenon, restart the battery, wait a few minutes, and confirm if the fault disappears. If the problem persists after restart, please contact the after-sales service center. |
| | <ol style="list-style-type: none"> 1. Battery total voltage too high. 2. Voltage sensing line abnormality. | |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|-------------------------|---|--------------------------------|
| Battery Undervoltage | 1. Single cell voltage too low. 2. Voltage sensing line abnormality. | |
| | 1. Battery total voltage too low. 2. Voltage sensing line abnormality. | |
| Battery Overcurrent | 1. Charging current too high, battery current limiting abnormality: sudden change in temperature and voltage values. 2. Inverter response abnormality. | |
| | Battery discharge current too high. | |
| Battery Overtemperature | 1. Ambient temperature too high. 2. Temperature sensor abnormality. | |
| | 1. Ambient temperature too high. 2. Temperature sensor abnormality. | |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|----------------------------------|---|--------------------------------|
| Battery Undertemperature | 1. Ambient temperature too low. 2. Temperature sensor abnormality. | |
| | 1. Ambient temperature too low. 2. Temperature sensor abnormality. | |
| Battery Terminal Overtemperature | Terminal temperature too high. | |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|-------------------|--|--------------------------------|
| Battery Imbalance | <ol style="list-style-type: none"> 1. Excessive temperature difference. At different stages, the battery will limit its power, i.e., limit charge/discharge current. Therefore, this issue is generally difficult to occur. 2. Cell capacity degradation leads to excessive internal resistance, causing high temperature rise during overcurrent and thus large temperature difference. 3. Poor welding of cell tabs leads to rapid cell temperature rise during overcurrent. 4. Temperature sampling issue. 5. Loose power line connection. | |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|-----------------------|---|--|
| | <ol style="list-style-type: none"> 1. Inconsistent cell aging levels. 2. Slave board chip issues can also cause excessive cell voltage difference. 3. Slave board balancing issues can also cause excessive cell voltage difference. 4. Caused by harness issues. | |
| | <ol style="list-style-type: none"> 1. Inconsistent cell aging levels. 2. Slave board chip issues can also cause excessive cell voltage difference. 3. Slave board balancing issues can also cause excessive cell voltage difference. 4. Caused by harness issues. | |
| Insulation Resistance | Insulation resistance damaged. | Check if the ground wire is properly connected, restart the battery. If the problem persists after restart, please contact the after-sales service center. |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|----------------------|--|---|
| Pre-charging Failure | Pre-charging failure. | Indicates that during the pre-charging process, the voltage across the pre-charge MOS always exceeds the specified threshold. After powering off and restarting, observe if this fault persists. Check if the wiring is correct and if the pre-charge MOS is damaged. |
| Harness Fault | Battery harness poor contact or disconnection. | Check wiring, restart the battery. If the problem persists after restart, please contact the after-sales service center. |
| | Cell voltage sensing line poor contact or disconnection. | |
| | Cell temperature sensing line poor contact or disconnection. | |
| | Excessive error in dual-channel current comparison, or abnormal current sensing line loop. | |
| | Excessive error in dual-channel voltage comparison or MCU vs. AFE voltage comparison, or abnormal voltage sensing line loop. | |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|--|--|---|
| | Temperature sensing line loop abnormal or poor contact/disconnection. | |
| | Overvoltage level 5 or overtemperature level 5, tripping the three-terminal fuse. | The three-terminal fuse is blown. Contact the after-sales service center to replace the main control board. |
| Relay or MOS Overtemperature | Relay or MOS overtemperature. | This fault indicates the MOS transistor temperature exceeds the specified threshold. Power off and let it sit for 2 hours for temperature recovery. |
| Shunt Overtemperature | Shunt overtemperature. | This fault indicates the shunt temperature exceeds the specified threshold. Power off and let it sit for 2 hours for temperature recovery. |
| BMS1 Other Fault 1 (Residential Storage) | Relay or MOS open circuit. | <ol style="list-style-type: none"> 1. Upgrade software, power off and let it sit for 5 minutes, restart and see if the fault persists. 2. If it persists, replace the battery pack. |
| | Relay or MOS short circuit. | <ol style="list-style-type: none"> 1. Upgrade software, power off and let it sit for 5 minutes, restart and see if the fault persists. 2. If it persists, replace the battery pack. |
| | Communication abnormality between master and slave racks, or cell inconsistency between racks. | <ol style="list-style-type: none"> 1. Check the slave battery information and software version, and if the communication cable connection to the master is normal. 2. Upgrade software. |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|------------|---|---|
| | Battery system loop harness abnormality, causing the interlock signal not to form a loop. | Check if the terminal resistor is installed correctly. |
| | BMS and PCS communication abnormality. | <ol style="list-style-type: none"> 1. Confirm if the communication cable interface definitions between the inverter and the connected battery are correct. 2. Please contact the after-sales service center to check backend data and observe if the inverter and battery software are correctly matched. |
| | BMS master control and slave control communication harness abnormality. | <ol style="list-style-type: none"> 1. Check wiring, restart the battery. 2. Upgrade the battery. If the problem persists after restart, please contact the after-sales service center. |
| | Communication loss between main negative chips. | |
| | Circuit breaker, shunt trip abnormality. | <ol style="list-style-type: none"> 1. Power off and let it sit for 5 minutes, restart and see if the fault persists. 2. Observe the blind-mating connectors at the bottom of PACK and PCU, check if communication pins are loose or bent. |
| | MCU self-test failure. | Upgrade software, restart the battery. If the problem persists after restart, contact the after-sales service center. |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|------------|--|---|
| | 1. Software version too low or BMS board damaged. 2. Large number of inverters in parallel, excessive inrush current during battery pre-charging. | 1. Upgrade software, observe if the fault persists. 2. In parallel scenarios, perform a black start of the battery first, then start the inverters. |
| | MCU internal fault. | Upgrade software, restart the battery. This usually indicates MCU or external component damage. If the problem persists after restart, please contact the after-sales service center. |
| | Total control current exceeds specified threshold. | 1. Power off and let it sit for 5 minutes, restart and see if the fault persists. 2. Check if the inverter power setting is too high, exceeding the bus load capacity. |
| | Inconsistent cells in parallel battery racks. | Confirm if the cells in the parallel battery racks are consistent. |
| | Reverse polarity connection of parallel battery racks. | Check if the positive and negative terminals of the parallel battery racks are connected reversely. |
| | Severe overtemperature/overvoltage etc., triggering the fire suppression system. | Contact the after-sales service center. |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|--|--|---|
| Air Conditioner Failure | Air conditioner abnormal failure. | Try restarting the system. If the fault is not resolved, please contact the after-sales service center. |
| | Cabinet door not closed. | Check if the cabinet door is properly closed. |
| | Supply voltage too high. | Confirm if the supply voltage value meets the air conditioner input voltage requirements. After confirmation, power on again. |
| | Insufficient supply voltage. | |
| | No voltage input. | |
| | Unstable supply voltage. | |
| | Compressor voltage unstable. | Try restarting the system. If the fault is not resolved, please contact the after-sales service center. |
| | Sensor poor contact or damaged. | |
| | Air conditioner fan abnormal. | |
| BMS1 Other Fault 2 (Residential Storage) | Internal voltage or current abnormality in DCDC. | Refer to specific DC fault content. |
| | DCDC overload or heatsink temperature too high, etc. | |
| | Cell sensing abnormality or inconsistent aging levels. | Please contact the after-sales service center. |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|------------|--|--|
| | Fan operation not executed normally. | Please contact the after-sales service center. |
| | Output port screws loose or poor contact. | <ol style="list-style-type: none"> 1. Power off the battery, check wiring and output port screw condition. 2. After confirmation, restart the battery, observe if the fault persists. If it exists, please contact the after-sales service center. |
| | Battery used for too long or cells severely damaged. | Please contact the after-sales service center to replace the pack. |
| | <ol style="list-style-type: none"> 1. Software version too low or BMS board damaged. 2. Large number of inverters in parallel, excessive inrush current during battery pre-charging. | <ol style="list-style-type: none"> 1. Upgrade software, observe if the fault persists. 2. In parallel scenarios, perform a black start of the battery first, then start the inverters. |
| | Heating film damaged. | Please contact the after-sales service center. |
| | Heating film three-terminal fuse blown, heating function unavailable. | Please contact the after-sales service center. |
| | Software model, cell type, hardware model mismatch. | Check if the software model, SN, cell type, and hardware model are consistent. If not, please contact the after-sales service center. |
| | Thermal management board communication line break. | <ol style="list-style-type: none"> 1. Power off and let it sit for 5 minutes, restart and see if the fault persists. 2. If the fault does not recover, contact after-sales to replace the pack. |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|------------|---|---|
| | Thermal management board communication line break. | 1. Power off and let it sit for 5 minutes, restart and see if the fault persists. 2. If the fault does not recover, contact after-sales to replace the pack. |
| | Thermal management board communication line break. | 1. Power off and let it sit for 5 minutes, restart and see if the fault persists. 2. If the fault does not recover, contact after-sales to replace the pack. |
| | Pack fan fault signal triggered. | 1. Power off and let it sit for 5 minutes, restart and see if the fault persists. 2. If the fault does not recover, contact after-sales to replace the pack. |
| DCDC Fault | Output port voltage too high. | Check the output port voltage. If the output port voltage is normal and the fault does not clear by itself after restarting the battery, please contact the after-sales service center. |
| | DCDC module detects battery voltage exceeding maximum charging voltage. | Stop charging, discharge to below 90% SOC or let it sit for 2 hours. If ineffective and the fault persists after restart, please contact the after-sales service center. |
| | Heatsink temperature too high. | Let the battery sit for 1 hour for heatsink temperature to drop. If ineffective and the fault persists after restart, please contact the after-sales service center. |
| | Battery discharge current too high. | Check if the load exceeds the battery's discharge capability. Turn off the load or stop the PCS for 60 seconds. If ineffective and the fault persists after restart, please contact the after-sales service center. |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|--|---|--|
| | Output port power harness positive/negative terminals connected reversely to parallel racks or PCS. | Turn off the battery manual switch, check if the output port wiring is correct, restart the battery. |
| | Output power relay cannot close. | Check if the output port wiring is correct and if there is a short circuit. If ineffective and the fault persists after restart, please contact the after-sales service center. |
| | Power device temperature too high. | Let the battery sit for 1 hour for internal power device temperature to drop. If ineffective and the fault persists after restart, please contact the after-sales service center. |
| | Relay welded/stuck. | If the fault persists after restart, please contact the after-sales service center. |
| Battery Rack Circulating Current Failure | 1. Cell imbalance. 2. First power-on without full charge calibration. | Record the fault phenomenon, restart the battery, wait a few minutes, and confirm if the fault disappears. If the problem persists after restart, please contact the after-sales service center. |
| BMS1 Other Fault 3 (Utility Storage) | Communication abnormality with Linux module. | 1. Check if the communication cable link is normal. 2. Upgrade software, restart the battery and observe if the fault persists. If it exists, please contact the after-sales service center. |
| | Cell temperature rise too fast. | Cell abnormality, contact after-sales to replace the pack. |
| | SOC below 10%. | Charge the battery. |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|--------------------------------------|---|--|
| | SN writing does not conform to rules. | Check if the SN digit count is normal. If abnormal, please contact the after-sales service center. |
| | 1. Daisy-chain communication abnormality within a battery rack. 2. Inconsistent cell aging levels between battery racks. | 1. Check the pack contact condition within a single rack. 2. Confirm the usage of each rack, such as cumulative charge/discharge capacity, cycle count, etc. 3. Please contact the after-sales service center. |
| | Excessive humidity inside pack. | - |
| | Fuse blown. | Contact after-sales to replace the pack. |
| | Battery low power. | Charge the battery. |
| BMS1 Other Fault 4 (Utility Storage) | Circuit breaker abnormality. | Contact after-sales to replace the pack. |
| | External device abnormality. | Contact after-sales to replace the pack. |
| Contactor Failure 1 | - | - |
| Contactor Failure 2 | - | - |
| Overload Protection (Ksic) | Sustained overload (exceeding 690KVA) for 10s. | Please contact the after-sales service center. |
| Overload Protection (Smart Port) | Sustained overload (exceeding 690KVA) for 10s. | Please contact the after-sales service center. |

| Fault Name | Fault Cause | Troubleshooting Recommendation |
|-------------------------------------|--|--|
| Overcurrent Protection (Ksic) | - | - |
| Overcurrent Protection (Smart Port) | - | - |
| Master AC On Meter Comm Error | <ol style="list-style-type: none"> 1. Possibly the meter is not connected to the master. 2. Possibly the meter communication cable is loose. | <ol style="list-style-type: none"> 1. Check if the meter is connected to the master. 2. Check if the meter communication cable is loose. |
| Parallel Slave Meter Error | Meter connected to a slave unit. | Set the unit with the meter as the master. |
| Slave AC On Timeout with Master | <ol style="list-style-type: none"> 1. Slave address setting error. 2. Slave communication cable loose. | <ol style="list-style-type: none"> 1. Check for duplicate slave addresses. 2. Check if the parallel communication cable is loose. |

8.5.2.2 Battery Fault

| No. | Fault Name | Fault Cause | Fault Handling Suggestion |
|------------|--|--|--|
| 1 | BMS1 RACK1 Total voltage is too high warning | <ol style="list-style-type: none"> 1. Battery system voltage is too high. 2. Voltage acquisition line is abnormal. | <ol style="list-style-type: none"> 1. Discharge the battery and observe if the fault persists. 2. If the fault does not recover, contact the after-sales service center. |

| No. | Fault Name | Fault Cause | Fault Handling Suggestion |
|-----|---|---|---|
| 2 | BMS1 RACK1 Total voltage is too low warning | <ol style="list-style-type: none"> 1. Battery system voltage is too low. 2. Voltage acquisition line is abnormal. | <ol style="list-style-type: none"> 1. Charge the battery, let it rest, and observe if the fault persists. 2. Check the inverter's working condition to see if it is not charging the battery due to issues like working mode. Try charging the battery via the inverter and observe if the fault recovers. 3. If the fault does not recover, contact the after-sales service center. |
| 3 | BMS1 RACK1 Cell voltage is too high warning | <ol style="list-style-type: none"> 1. Single cell voltage is too high. 2. Voltage acquisition line is abnormal. | <ol style="list-style-type: none"> 1. Discharge the battery, let it rest, and observe if the fault persists. 2. If the fault does not recover, contact the after-sales service center. |

| No. | Fault Name | Fault Cause | Fault Handling Suggestion |
|-----|---|--|--|
| 4 | BMS1 RACK1 Cell voltage is too low warning | <ol style="list-style-type: none"> 1. Single cell voltage is too low. 2. Voltage acquisition line is abnormal. | <ol style="list-style-type: none"> 1. Charge the battery, let it rest, and observe if the fault persists. 2. Check the inverter's working condition to see if it is not charging the battery due to issues like working mode. Try charging the battery via the inverter and observe if the fault recovers. 3. If the fault does not recover, contact after-sales. |
| 5 | BMS1 RACK1 Charging temperature is too high warning | <ol style="list-style-type: none"> 1. Ambient Overtemperature 2. Temperature sensor is abnormal. | <ol style="list-style-type: none"> 1. Stop charging/discharging, let it rest, and observe if the fault persists. 2. If the fault does not recover, contact the after-sales service center. |

| No. | Fault Name | Fault Cause | Fault Handling Suggestion |
|-----|--|--|--|
| 6 | BMS1 RACK1 Discharging temperature is too high warning | <ol style="list-style-type: none"> 1. Ambient Overtemperature 2. Temperature sensor is abnormal. | <ol style="list-style-type: none"> 1. Stop charging/discharging, let it rest, and observe if the fault persists. 2. If the fault does not recover, contact after-sales. |
| 7 | BMS1 RACK1 Charging temperature is too low warning | <ol style="list-style-type: none"> 1. Ambient temperature is too low. 2. Temperature sensor is abnormal. | <ol style="list-style-type: none"> 1. Check the cell temperature in the background. If the minimum temperature is above -20°C, set the battery to discharge to increase the cell temperature. 2. If the temperature is below -20°C, power off the battery and place it in a warm environment. Use it after the cell temperature rises. 3. If none of the above works, contact the after-sales service center. |

| No. | Fault Name | Fault Cause | Fault Handling Suggestion |
|-----|---|---|--|
| 8 | BMS1 RACK1 Discharging temperature is too low warning | <ol style="list-style-type: none"> 1. Ambient temperature is too low. 2. Temperature sensor is abnormal. | <ol style="list-style-type: none"> 1. Check the cell temperature in the background. If the minimum temperature is above -20°C, set the battery to discharge to increase the cell temperature. 2. If the temperature is below -20°C, power off the battery and place it in a warm environment. Use it after the cell temperature rises. 3. If none of the above works, contact the after-sales service center. |
| 9 | BMS1 RACK1 Charge overcurrent warning | <ol style="list-style-type: none"> 1. Charging current is too high, battery current limiting is abnormal: sudden changes in temperature and voltage values. 2. Inverter response is abnormal. | <ol style="list-style-type: none"> 1. Stop charging, let it rest, and observe if the fault persists. 2. Check if the inverter is set to a power output that exceeds the battery's rated operating current. 3. If overcurrent persists, contact the after-sales service center. |

| No. | Fault Name | Fault Cause | Fault Handling Suggestion |
|-----|--|--|--|
| 10 | BMS1 RACK1 Discharge overcurrent warning | 1. Discharging current is too high, battery current limiting is abnormal: sudden changes in temperature and voltage values. 2. Inverter response is abnormal. | 1. Stop discharging, let it rest, and observe if the fault persists. 2. Check if the inverter is set to a power output that exceeds the battery's rated operating current. 3. If overcurrent persists, contact the after-sales service center. |
| 11 | BMS1 RACK1 Insulation resistance is too low warning | Insulation resistance is damaged or contact is abnormal. | Check if the ground wire is properly connected, restart the battery. If the problem persists after restarting, please contact the after-sales service center. |

| No. | Fault Name | Fault Cause | Fault Handling Suggestion |
|-----|---|--|---|
| 12 | BMS1 RACK1 Cell excessive temperature differentials warning | <p>1. At different stages of excessive temperature differential, the battery will limit the battery power, i.e., limit the charge/discharge current. Therefore, this problem is generally difficult to occur.</p> <p>2. Cell capacity degradation leads to excessive internal resistance, causing large temperature rise during overcurrent, resulting in large temperature differential.</p> <p>3. Poor welding of cell tabs leads to rapid cell temperature rise during overcurrent.</p> <p>4. Temperature sampling issue.</p> <p>5. Power line connection is loose.</p> | Power off, restart the battery, wait for 2 hours. If the problem is not resolved, contact the after-sales service center. |

| No. | Fault Name | Fault Cause | Fault Handling Suggestion |
|-----|---|---|--|
| 13 | BMS1 RACK1 Post temperature is too high warning | Post temperature is too high. | <ol style="list-style-type: none"> 1. Stop charging/discharging, let it rest, and observe if the fault persists. 2. If the fault does not recover, contact the after-sales service center. |
| 14 | BMS1 RACK1 Cell excessive voltage differentials warning | <ol style="list-style-type: none"> 1. Inconsistent cell aging levels. 2. Issues with the slave board chip can also cause excessive cell voltage differential. 3. Slave board balancing issues can also cause excessive cell voltage differential. 4. Caused by wiring harness issues. | <ol style="list-style-type: none"> 1. Stop charging/discharging, let it rest, and observe if the fault persists. 2. If the fault does not recover, contact the after-sales service center. |
| 15 | BMS1 RACK1 PCS communication loss warning | Communication between BMS and PCS is abnormal. | Check if the communication cable connection between the battery and the inverter is intact. |
| 16 | BMS1 RACK1 DCDC warning | Internal voltage or current abnormality exists in the DCDC. | Upgrade the software, restart the battery. If the problem persists after restarting, please contact the after-sales service center. |
| 17 | BMS1 RACK1 Heat film MOS adhesion warning | Heating film MOS is damaged. | Please contact the after-sales service center. |

| No. | Fault Name | Fault Cause | Fault Handling Suggestion |
|-----|--|--|--|
| 18 | BMS1 RACK1 Heat film MOS open warning | Heating circuit is abnormal. | Please contact the after-sales service center. |
| 19 | BMS1 RACK1 Total voltage is too high fault | <ol style="list-style-type: none"> 1. Battery system voltage is too high. 2. Voltage acquisition line is abnormal. | <ol style="list-style-type: none"> 1. Discharge the battery and observe if the fault persists. 2. If the fault does not recover, please contact the after-sales service center. |
| 20 | BMS1 RACK1 Total voltage is too low fault | <ol style="list-style-type: none"> 1. Battery system voltage is too low. 2. Voltage acquisition line is abnormal. | <ol style="list-style-type: none"> 1. Charge the battery, let it rest, and observe if the fault persists. 2. Check the inverter's working condition to see if it is not charging the battery due to issues like working mode. Try charging the battery via the inverter and observe if the fault recovers. 3. If the fault does not recover, please contact the after-sales service center. |
| 21 | BMS1 RACK1 Cell voltage is too high fault | <ol style="list-style-type: none"> 1. Single cell voltage is too high. 2. Voltage acquisition line is abnormal. | <ol style="list-style-type: none"> 1. Discharge the battery, let it rest, and observe if the fault persists. 2. If the fault does not recover, please contact the after-sales service center. |

| No. | Fault Name | Fault Cause | Fault Handling Suggestion |
|-----|---|--|--|
| 22 | BMS1 RACK1 Cell voltage is too low fault | <ol style="list-style-type: none"> 1. Single cell voltage is too low. 2. Voltage acquisition line is abnormal. | <ol style="list-style-type: none"> 1. Charge the battery, let it rest, and observe if the fault persists. 2. Check the inverter's working condition to see if it is not charging the battery due to issues like working mode. Try charging the battery via the inverter and observe if the fault recovers. 3. If the fault does not recover, please contact the after-sales service center. |
| 23 | BMS1 RACK1 Charging temperature is too high fault | <ol style="list-style-type: none"> 1. Ambient Overtemperature 2. Temperature sensor is abnormal. | <ol style="list-style-type: none"> 1. Place the battery in a cool place, power it off and let it rest for 30 minutes, then restart and observe if the fault persists. 2. If the fault persists, please contact the after-sales service center. |

| No. | Fault Name | Fault Cause | Fault Handling Suggestion |
|-----|---|---|---|
| 24 | BMS1 RACK1 Discharging temperature is too high fault | 1. Ambient Overtemperature 2. Temperature sensor is abnormal. | 1. Place the battery in a cool place, power it off and let it rest for 30 minutes, then restart and observe if the fault persists. 2. If the fault persists, please contact the after-sales service center. |
| 25 | BMS1 RACK1 Charging temperature is too low fault | 1. Ambient temperature is too low. 2. Temperature sensor is abnormal. | 1. Check the cell temperature in the background. If the minimum temperature is above -20°C, set the battery to discharge to increase the cell temperature. 2. If the temperature is below -20°C, power off the battery and place it in a warm environment. Use it after the cell temperature rises. 3. If none of the above works, contact the after-sales service center. |

| No. | Fault Name | Fault Cause | Fault Handling Suggestion |
|-----|---|---|--|
| 26 | BMS1 RACK1 Discharging temperature is too low fault | <ol style="list-style-type: none"> 1. Ambient temperature is too low. 2. Temperature sensor is abnormal. | <ol style="list-style-type: none"> 1. Check the cell temperature in the background. If the minimum temperature is above -20°C, set the battery to discharge to increase the cell temperature. 2. If the temperature is below -20°C, power off the battery and place it in a warm environment. Use it after the cell temperature rises. 3. If none of the above works, contact the after-sales service center. |
| 27 | BMS1 RACK1 Charge overcurrent fault | <ol style="list-style-type: none"> 1. Charging current is too high, battery current limiting is abnormal: sudden changes in temperature and voltage values. 2. Inverter response is abnormal. | <ol style="list-style-type: none"> 1. Power off and let it rest for 5 minutes, restart and observe if the fault persists. 2. Check if the inverter is set to a power output that exceeds the battery's rated operating current. 3. If overcurrent persists, contact the after-sales service center. |

| No. | Fault Name | Fault Cause | Fault Handling Suggestion |
|-----|---|--|--|
| 28 | BMS1 RACK1 Discharge overcurrent fault | <ol style="list-style-type: none"> 1. Discharging current is too high, battery current limiting is abnormal: sudden changes in temperature and voltage values. 2. Inverter response is abnormal. | <ol style="list-style-type: none"> 1. Power off and let it rest for 5 minutes, restart and observe if the fault persists. 2. Check if the inverter is set to a power output that exceeds the battery's rated operating current. 3. If overcurrent persists, contact the after-sales service center. |
| 29 | BMS1 RACK1 Insulation resistance is too low fault | Insulation resistance is damaged or contact is abnormal. | <ol style="list-style-type: none"> 1. Check if the ground wire is properly connected, restart the battery. 2. Upgrade the software. If the problem persists, please contact the after-sales service center. |

| No. | Fault Name | Fault Cause | Fault Handling Suggestion |
|-----|---|---|---|
| 30 | BMS1 RACK1 Cell excessive temperature differentials fault | <ol style="list-style-type: none"> 1. At different stages of excessive temperature differential, the battery will limit the battery power, i.e., limit the charge/discharge current. Therefore, this problem is generally difficult to occur. 2. Cell capacity degradation leads to excessive internal resistance, causing large temperature rise during overcurrent, resulting in large temperature differential. 3. Poor welding of cell tabs leads to rapid cell temperature rise during overcurrent. 4. Temperature sampling issue. 5. Power line connection is loose. | Power off, restart the battery, wait for 2 hours. If the problem is not resolved, contact the after-sales service center. |

| No. | Fault Name | Fault Cause | Fault Handling Suggestion |
|-----|---|---|--|
| 31 | BMS1 RACK1 Post temperature is too high fault | Post temperature is too high. | <ol style="list-style-type: none"> 1. Power off and let it rest for 30 minutes, restart and observe if the fault persists. 2. If the fault persists, please contact the after-sales service center. |
| 32 | BMS1 RACK1 Cell excessive voltage differentials fault | <ol style="list-style-type: none"> 1. Inconsistent cell aging levels. 2. Issues with the slave board chip can also cause excessive cell voltage differential. 3. Slave board balancing issues can also cause excessive cell voltage differential. 4. Caused by wiring harness issues. | Power off, restart the battery, wait for 2 hours. If the problem is not resolved, contact the after-sales service center. |
| 33 | BMS1 RACK1 Relay or MOS short-circuit fault | MOS short-circuit. | <ol style="list-style-type: none"> 1. Upgrade the software, power off and let it rest for 5 minutes, restart and observe if the fault persists. 2. If it persists, contact the after-sales service center. |

| No. | Fault Name | Fault Cause | Fault Handling Suggestion |
|-----|---|--|---|
| 34 | BMS1 RACK1 Relay or MOS open-circuit fault | MOS open-circuit. | <ol style="list-style-type: none"> 1. Upgrade the software, power off and let it rest for 5 minutes, restart and observe if the fault persists. 2. If it persists, contact the after-sales service center. |
| 35 | BMS1 RACK1 The precharge failed fault | The voltage across the precharge MOS always exceeds the specified threshold. | <ol style="list-style-type: none"> 1. Upgrade the software, power off and let it rest for 5 minutes, restart and observe if the fault persists. 2. If it persists, contact the after-sales service center. |
| 36 | BMS1 RACK1 Acquisition line fault | Battery acquisition line has poor contact or is disconnected. | Power off, check the wiring, restack the battery. If the problem persists after restarting, please contact the after-sales service center. |
| 37 | BMS1 RACK1 Relay or MOS temperature is too high fault | Relay or MOS overtemperature. | <ol style="list-style-type: none"> 1. Upgrade the software, power off and let it rest for 30 minutes, restart and observe if the fault persists. 2. If it persists, contact the after-sales service center. |

| No. | Fault Name | Fault Cause | Fault Handling Suggestion |
|-----|---|--|---|
| 38 | BMS1 RACK1 Diverter temperature is too high fault | Diverter overtemperature. | <ol style="list-style-type: none"> 1. Upgrade the software, power off and let it rest for 30 minutes, restart and observe if the fault persists. 2. If it persists, contact the after-sales service center. |
| 39 | BMS1 RACK1 Slave MCU communication fault | Communication loss between master and slave chips. | <ol style="list-style-type: none"> 1. Check the wiring, restart the battery. 2. Upgrade the battery. If the problem persists after restarting, please contact the after-sales service center. |
| 40 | BMS1 RACK1 BMU communication fault | BMS master and slave control wiring harness is abnormal. | <ol style="list-style-type: none"> 1. Check the wiring, restart the battery. 2. Upgrade the battery. If the problem persists after restarting, please contact the after-sales service center. |
| 41 | BMS1 RACK1 Micro-electronics fault | Internal MCU fault. | Upgrade the software, restart the battery. If the problem persists after restarting, please contact the after-sales service center. |

| No. | Fault Name | Fault Cause | Fault Handling Suggestion |
|-----|---|--|---|
| 42 | BMS1 RACK1 Hardware overcurrent fault | 1. Software version is too low or BMS board is damaged. 2. Large number of parallel inverters, causing excessive inrush current during battery precharge. | 1. Upgrade the software, observe if the fault persists. 2. In case of parallel operation, start the battery with a black start first, then start the inverter. |
| 43 | BMS1 RACK1 Application software fault | MCU self-test failed. | Upgrade the software, restart the battery. If the problem persists after restarting, please contact the after-sales service center. |
| 44 | BMS1 RACK1 Parallel RACK fault | Communication abnormality between the main RACK and slave RACKs, or inconsistency of cells between RACKs. | 1. Check the slave battery information and software version, and whether the communication cable connection to the master is normal. 2. Upgrade the software. |
| 45 | BMS1 RACK1 DCDC fault | DCDC overload or heat sink temperature is too high, etc. | Upgrade the software, restart the battery. If the problem persists after restarting, please contact the after-sales service center. |
| 46 | BMS1 RACK1 Inconsistent cell fault | 1. Cell identification is abnormal. 2. Different types of cells are stacked. | Check the cell type. |

| No. | Fault Name | Fault Cause | Fault Handling Suggestion |
|-----|---|---|---|
| 47 | BMS1 RACK1 The output port over temperature fault | Output port screws are loose or have poor contact. | 1. Power off the battery, check the wiring and the condition of the output port screws. 2. After confirmation, restart the battery, observe if the fault persists. If it exists, contact the after-sales service center. |
| 48 | BMS1 RACK1 SOH too low fault | Battery has been used for too long or cells are severely damaged. | Replace the pack. |
| 49 | BMS1 RACK1 Heating film MOS Three-terminal fault | Heating film MOS is damaged. | Please contact the after-sales service center. |

9 technical parameter

9.1 Inverter Parameters

| Technical Data | GW5K-ETA-G20 | GW6K-ETA-G20 | GW8K-ETA-G20 | GW9.999K-ETA-G20 |
|---|--------------|--------------|--------------|------------------|
| Battery Side | | | | |
| Battery Type | Li-Ion | Li-Ion | Li-Ion | Li-Ion |
| Nominal Voltage (V) | 750 | 750 | 750 | 750 |
| Voltage Range (V) | 700-950 | 700-950 | 700-950 | 700-950 |
| Start-up Voltage (V) | 720 | 720 | 720 | 720 |
| Number of Battery Inputs | 1 | 1 | 1 | 1 |
| Max. Continuous Charging Current (A) | 6.7 | 8.1 | 10.7 | 13.4 |
| Max. Continuous Discharging Current (A) | 7.4 | 8.9 | 11.8 | 14.7 |
| Max. Charging Power (kW) | 5 | 6 | 8 | 10 |
| Max. Discharging Power (kW) | 5.5 | 6.6 | 8.8 | 11 |
| PV Side | | | | |

| Technical Data | GW5K-ETA-G20 | GW6K-ETA-G20 | GW8K-ETA-G20 | GW9.999K-ETA-G20 |
|--|---------------------|---------------------|---------------------|-------------------------|
| Max. Input Power (kW) | 10 | 12 | 16 | 20 |
| Max. Input Voltage (V) ^{*1} | 1000 | 1000 | 1000 | 1000 |
| MPPT Operating Voltage Range (V) ^{*2} | 120~950 | 120~950 | 120~950 | 120~950 |
| MPPT Voltage Range at Nominal Power (V) | 185~850 | 225~850 | 300~850 | 250~850 |
| Start-up Voltage (V) | 150 | 150 | 150 | 150 |
| Nominal Input Voltage (V) | 750 | 750 | 750 | 750 |
| Max. MPPT Current (A) | 21/21/21 | 21/21/21 | 21/21/21 | 21/21/21/21 |
| Max. MPPT Short Circuit Current (A) | 26/26/26 | 26/26/26 | 26/26/26 | 26/26/26/26 |
| Number of MPPTs | 3 | 3 | 3 | 4 |
| Number of Strings per MPPT | 1/1/1 | 1/1/1 | 1/1/1 | 1/1/1/1 |
| AC Side (On-Grid) | | | | |
| Rated Power (kW) | 5 | 6 | 8 | 9.999 |

| Technical Data | GW5K-ETA-G20 | GW6K-ETA-G20 | GW8K-ETA-G20 | GW9.999K-ETA-G20 |
|--------------------------------------|---|---|---|---|
| Max. Power (kW) | 5 | 6 | 8 | 9.999 |
| Rated Apparent Power to Grid (kVA) | 5 | 6 | 8 | 9.999 |
| Rated Apparent Power from Grid (kVA) | 5 | 6 | 8 | 9.999 |
| Max. Apparent Power to Grid (kVA) | 5 | 6 | 8 | 9.999 |
| Max. Apparent Power from Grid (kVA) | 43.5 | 43.5 | 43.5 | 43.5 |
| Nominal Voltage (V) | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE |
| Voltage Range (V) | 180 ~ 260 (According to local standard) |
| Nominal Frequency (Hz) | 50/60 | 50/60 | 50/60 | 50/60 |
| Frequency Range (Hz) | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 |
| Rated Current to Grid (A) | 7.6 at 380V 7.3 at 400V | 9.1 at 380V 8.7 at 400V | 12.2 at 380V 11.6 at 400V | 15.2 at 380V 14.5 at 400V |
| Rated Current from Grid (A) | 7.6 at 380V 7.3 at 400V | 9.1 at 380V 8.7 at 400V | 12.2 at 380V 11.6 at 400V | 15.2 at 380V 14.5 at 400V |

| Technical Data | GW5K-ETA-G20 | GW6K-ETA-G20 | GW8K-ETA-G20 | GW9.999K-ETA-G20 |
|---|---|--|---|---|
| Max. Current to Grid (A) | 7.6 at 380V 7.3 at 400V | 9.1 at 380V 8.7 at 400V | 12.2 at 380V 11.6 at 400V | 15.2 at 380V 14.5 at 400V |
| Max. Current from Grid (A) | 63.0 | 63.0 | 63.0 | 63.0 |
| Max. Output Fault Current (Peak and Duration) (A) | 46.7@4μs | 46.7@4μs | 46.7@4μs | 74.6@4μs |
| Inrush Current (Peak and Duration) (A) | 21.3@5ms | 21.3@5ms | 21.3@5ms | 25.4@5ms |
| THDi | <3% | <3% | <3% | <3% |
| Maximum Output Overcurrent Protection (A) | 46.7 | 46.7 | 46.7 | 74.6 |
| Type of Voltage | a.c. | a.c. | a.c. | a.c. |
| Back-up Side | | | | |
| Rated Output Apparent Power (kVA) | 5 | 6 | 8 | 10 |
| Max. Output Apparent Power (kVA) | Off-grid: 5.5 (10.0, 10s), on-grid: 43.5 | Off-grid: 6.6(12, 10s), on-grid: 43.5 | Off-grid: 8.8 (16.0, 10s), on-grid: 43.5 | Off-grid: 11(20.0, 10s), on-grid: 43.5 |
| Nominal Output Voltage (V) | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE |

| Technical Data | GW5K-ETA-G20 | GW6K-ETA-G20 | GW8K-ETA-G20 | GW9.999K-ETA-G20 |
|---|--------------------------------|-------------------------------|--------------------------------|-------------------------------|
| Nominal Output Frequency (Hz) | 50/60 | 50/60 | 50/60 | 50/60 |
| Frequency Range (Hz) | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 |
| Rated Output Current (A) | 7.6 at 380V 7.3 at 400V | 9.1 at 380V 8.7 at 400V | 12.2 at 380V 11.6 at 400V | 15.2 at 380V 14.5 at 400V |
| Max. Output Current (A) ^{*3} | Off-grid: 11.4, on-grid: 63 | Off-grid: 13.7, on-grid:63 | Off-grid: 18.2, on-grid: 63 | Off-grid: 22.8, on-grid:63 |
| Max. Output Fault Current (Peak and Duration) (A) | 46.7@4μs | 46.7@4μs | 46.7@4μs | 74.6@4μs |
| Inrush Current (Peak and Duration) (A) | 21.3@5ms | 21.3@5ms | 21.3@5ms | 25.4@5ms |
| Maximum Overcurrent Protection (A) | 46.7 | 46.7 | 46.7 | 74.6 |
| THDv (@Linear Load) | <3% | <3% | <3% | <3% |
| On/Off-grid Switching Time (ms) | <4 | <4 | <4 | <4 |
| Efficiency | | | | |
| Max. Efficiency | 98.00% | 98.00% | 98.00% | 98.10% |
| European Efficiency | 96.40% | 96.90% | 97.10% | 97.20% |

| Technical Data | GW5K-ETA-G20 | GW6K-ETA-G20 | GW8K-ETA-G20 | GW9.999K-ETA-G20 |
|-------------------------------------|---------------------|---------------------|---------------------|-------------------------|
| Max. Battery to AC Efficiency | 98.00% | 98.00% | 98.00% | 98.00% |
| Protection | | | | |
| PV String Current Monitoring | Integrated | Integrated | Integrated | Integrated |
| PV Insulation Resistance Detection | Integrated | Integrated | Integrated | Integrated |
| Residual Current Monitoring | Integrated | Integrated | Integrated | Integrated |
| PV Reverse Polarity Protection | Integrated | Integrated | Integrated | Integrated |
| Battery Reverse Polarity Protection | Integrated | Integrated | Integrated | Integrated |
| Anti-islanding Protection | Integrated | Integrated | Integrated | Integrated |
| AC Overcurrent Protection | Integrated | Integrated | Integrated | Integrated |
| AC Short Circuit Protection | Integrated | Integrated | Integrated | Integrated |

| Technical Data | GW5K-ETA-G20 | GW6K-ETA-G20 | GW8K-ETA-G20 | GW9.999K-ETA-G20 |
|----------------------------------|--------------------------------|--------------------------------|--------------------------------|--------------------------------|
| AC Overvoltage Protection | Integrated | Integrated | Integrated | Integrated |
| DC Switch | Integrated | Integrated | Integrated | Integrated |
| DC Surge Protection | Type II(Type I+II optional) |
| AC Surge Protection | Type II | Type II | Type II | Type II |
| Rapid Shutdown | Optional | Optional | Optional | Optional |
| AFCI | Optional | Optional | Optional | Optional |
| Remote Shutdown | Integrated | Integrated | Integrated | Integrated |
| General Data | | | | |
| Power Factor | 0.8 leading ... 0.8 lagging |
| Operating Temperature Range (°C) | -35~+60 | -35~+60 | -35~+60 | -35~+60 |
| Operating Environment | Indoor/Outdoor | Indoor/Outdoor | Indoor/Outdoor | Indoor/Outdoor |
| Relative Humidity | 0~100% | 0~100% | 0~100% | 0~100% |
| Max. Operating Altitude (m) | 4000 (>2000 derating) | 4000 (>2000 derating) | 4000 (>2000 derating) | 4000 (>2000 derating) |
| Cooling Method | Smart Fan Cooling | Smart Fan Cooling | Smart Fan Cooling | Smart Fan Cooling |

| Technical Data | GW5K-ETA-G20 | GW6K-ETA-G20 | GW8K-ETA-G20 | GW9.999K-ETA-G20 |
|-------------------------------|---|---|---|---|
| User Interface | LED, WLAN+APP | LED, WLAN+APP | LED, WLAN+APP | LED, WLAN+APP |
| Communication with BMS | CAN | CAN | CAN | CAN |
| Communication | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) |
| Communication Protocols | Modbus-RTU, Modbus-TCP | Modbus-RTU, Modbus-TCP | Modbus-RTU, Modbus-TCP | Modbus-RTU, Modbus-TCP |
| Weight (kg) | 34 | 34 | 34 | 34 |
| Dimension (W×H×D mm) | 800*340*270 | 800*340*270 | 800*340*270 | 800*340*270 |
| Noise Emission (dB) | ≤35 | ≤35 | ≤35 | ≤40 |
| Topology | Non-isolated | Non-isolated | Non-isolated | Non-isolated |
| Self-consumption at Night (W) | ≤10 | ≤10 | ≤10 | ≤10 |
| Ingress Protection Rating | IP66 | IP66 | IP66 | IP66 |
| DC Connector | MC4, VACONN Terminal | MC4, VACONN Terminal | MC4, VACONN Terminal | MC4, VACONN Terminal |
| AC Connector | VACONN Terminal | VACONN Terminal | VACONN Terminal | VACONN Terminal |

| Technical Data | GW5K-ETA-G20 | GW6K-ETA-G20 | GW8K-ETA-G20 | GW9.999K-ETA-G20 |
|----------------------------------|--|--|--|--|
| Environmental Category | 4K4H | 4K4H | 4K4H | 4K4H |
| Pollution Degree | III | III | III | III |
| Overvoltage Category | DC II / AC III |
| Protective Class | I | I | I | I |
| Storage Temperature (°C) | -40~+70 | -40~+70 | -40~+70 | -40~+70 |
| The Decisive Voltage Class (DVC) | Battery: C | Battery: C | Battery: C | Battery: C |
| | PV: C | PV: C | PV: C | PV: C |
| | AC: C | AC: C | AC: C | AC: C |
| | Com: A | Com: A | Com: A | Com: A |
| Mounting Method | Wall/Floor Mounted | Wall/Floor Mounted | Wall/Floor Mounted | Wall/Floor Mounted |
| Active Anti-islanding Method | SMS(Slip-mode frequency) +AFD ^{*4} | SMS(Slip-mode frequency) +AFD ^{*4} | SMS(Slip-mode frequency) +AFD ^{*4} | SMS(Slip-mode frequency) +AFD ^{*4} |
| Type of Electrical Supply System | three phase | three phase | three phase | three phase |
| Country of Manufacture | China | China | China | China |
| Certification | | | | |
| Grid Standard | | | | |

| Technical Data | GW5K-ETA-G20 | GW6K-ETA-G20 | GW8K-ETA-G20 | GW9.999K-ETA-G20 |
|-----------------------|--------------------------------------|---------------------|---------------------|-------------------------|
| Safety Regulation | Please refer to the official website | | | |
| EMC | | | | |

| Technical Data | GW10K-ETA-G20 | GW12K-ETA-G20 | GW15K-ETA-G20 | GW20K-ETA-G20 |
|---|----------------------|----------------------|----------------------|----------------------|
| Battery Side | | | | |
| Battery Type | Li-Ion | Li-Ion | Li-Ion | Li-Ion |
| Nominal Voltage (V) | 750 | 750 | 750 | 750 |
| Voltage Range (V) | 700-950 | 700-950 | 700-950 | 700-950 |
| Start-up Voltage (V) ^{*1} | 720 | 720 | 720 | 720 |
| Number of Battery Inputs | 1 | 1 | 1 | 1 |
| Max. Continuous Charging Current (A) | 13.4 | 16.1 | 20.1 | 26.7 |
| Max. Continuous Discharging Current (A) | 14.7 | 17.7 | 22.1 | 29.4 |
| Max. Charging Power (kW) | 10 | 12 | 15 | 20 |
| Max. Discharging Power (kW) | 11 | 13.2 | 16.5 | 22 |

| Technical Data | GW10K-ETA-G20 | GW12K-ETA-G20 | GW15K-ETA-G20 | GW20K-ETA-G20 |
|--|----------------------|----------------------|----------------------|----------------------|
| PV Side | | | | |
| Max. Input Power (kW) | 20 | 24 | 30 | 40 |
| Max. Input Voltage (V) ^{*1} | 1000 | 1000 | 1000 | 1000 |
| MPPT Operating Voltage Range (V) ^{*2} | 120~950 | 120~950 | 120~950 | 120~950 |
| MPPT Voltage Range at Nominal Power (V) | 250~850 | 300~850 | 360~850 | 400~850 |
| Start-up Voltage (V) | 150 | 150 | 150 | 150 |
| Nominal Input Voltage (V) | 750 | 750 | 750 | 750 |
| Max. MPPT Current (A) | 21/21/21/21 | 21/21/21/21 | 21/21/21/21 | 21/21/21/21 |
| Max. MPPT Short Circuit Current (A) | 26/26/26/26 | 26/26/26/26 | 26/26/26/26 | 26/26/26/26 |
| Number of MPPTs | 4 | 4 | 4 | 4 |
| Number of Strings per MPPT | 1/1/1/1 | 1/1/1/1 | 1/1/1/1 | 1/1/1/1 |
| AC Side (On-Grid) | | | | |

| Technical Data | GW10K-ETA-G20 | GW12K-ETA-G20 | GW15K-ETA-G20 | GW20K-ETA-G20 |
|--------------------------------------|--|--|--|--|
| Rated Power (kW) | 10 | 12 | 15 | 20 |
| Max. Power (kW) | 10 | 12 | 15 | 20 |
| Rated Apparent Power to Grid (kVA) | 10 | 12 | 15 | 20 |
| Rated Apparent Power from Grid (kVA) | 10 | 12 | 15 | 20 |
| Max. Apparent Power to Grid (kVA) | 10 | 12 | 15 | 20 |
| Max. Apparent Power from Grid (kVA) | 43.5 | 43.5 | 43.5 | 43.5 |
| Nominal Voltage (V) | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE |
| Voltage Range (V) | 180 ~ 260 (According to local standard) |
| Nominal Frequency (Hz) | 50/60 | 50/60 | 50/60 | 50/60 |
| Frequency Range (Hz) | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 |
| Rated Current to Grid (A) | 15.2 at 380V 14.5 at 400V | 18.2 at 380V 17.4 at 400V | 22.8 at 380V 21.8 at 400V | 30.4 at 380V 29.0 at 400V |

| Technical Data | GW10K-ETA-G20 | GW12K-ETA-G20 | GW15K-ETA-G20 | GW20K-ETA-G20 |
|---|--|--|---|---|
| Rated Current from Grid (A) | 15.2 at 380V 14.5 at 400V | 18.2 at 380V 17.4 at 400V | 22.8 at 380V 21.8 at 400V | 30.4 at 380V 29.0 at 400V |
| Max. Current to Grid (A) | 15.2 at 380V 14.5 at 400V | 18.2 at 380V 17.4 at 400V | 22.8 at 380V 21.8 at 400V | 30.4 at 380V 29.0 at 400V |
| Max. Current from Grid (A) | 63.0 | 63.0 | 63.0 | 63.0 |
| Max. Output Fault Current (Peak and Duration) (A) | 74.6@4 μ s | 74.6@4 μ s | 83.3@4 μ s | 83.3@4 μ s |
| Inrush Current (Peak and Duration) (A) | 25.4@5ms | 25.4@5ms | 29.1@5ms | 29.1@5ms |
| THDi | <3% | <3% | <3% | <3% |
| Maximum Output Overcurrent Protection (A) | 74.6 | 74.6 | 83.3 | 83.3 |
| Type of Voltage | a.c. | a.c. | a.c. | a.c. |
| Back-up Side | | | | |
| Rated Output Apparent Power (kVA) | 10 | 12 | 15 | 20 |
| Max. Output Apparent Power (kVA) | Off-grid: 11(20.0, 10s), on-grid: 43.5 | Off-grid: 13.2(24, 10s), on-grid: 43.5 | Off-grid: 16.5(30, 10s), on-grid:43.5 | Off-grid: 22(30.0, 10s), on-grid:43.5 |

| Technical Data | GW10K-ETA-G20 | GW12K-ETA-G20 | GW15K-ETA-G20 | GW20K-ETA-G20 |
|---|--------------------------------|--------------------------------|--------------------------------|--------------------------------|
| Nominal Output Voltage (V) | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE |
| Nominal Output Frequency (Hz) | 50/60 | 50/60 | 50/60 | 50/60 |
| Frequency Range (Hz) | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 |
| Rated Output Current (A) | 15.2 at 380V 14.5 at 400V | 18.2 at 380V 17.4 at 400V | 22.8 at 380V 21.8 at 400V | 30.4 at 380V 29.0 at 400V |
| Max. Output Current (A)*3 | Off-grid: 22.8, on-grid: 63 | Off-grid: 27.3, on-grid: 63 | Off-grid: 33.4, on-grid: 63 | Off-grid: 33.4, on-grid: 63 |
| Max. Output Fault Current (Peak and Duration) (A) | 74.6@4μs | 74.6@4μs | 83.3@4μs | 83.3@4μs |
| Inrush Current (Peak and Duration) (A) | 25.4@5ms | 25.4@5ms | 29.1@5ms | 29.1@5ms |
| Maximum Overcurrent Protection (A) | 74.6 | 74.6 | 83.3 | 83.3 |
| THDv (@Linear Load) | <3% | <3% | <3% | <3% |
| On/Off-grid Switching Time (ms) | <4 | <4 | <4 | <4 |
| Efficiency | | | | |
| Max. Efficiency | 98.10% | 98.10% | 98.10% | 98.10% |

| Technical Data | GW10K-ETA-G20 | GW12K-ETA-G20 | GW15K-ETA-G20 | GW20K-ETA-G20 |
|-------------------------------------|----------------------|----------------------|----------------------|----------------------|
| European Efficiency | 97.20% | 97.20% | 97.30% | 97.30% |
| Max. Battery to AC Efficiency | 98.00% | 98.00% | 98.00% | 98.00% |
| Protection | | | | |
| PV String Current Monitoring | Integrated | Integrated | Integrated | Integrated |
| PV Insulation Resistance Detection | Integrated | Integrated | Integrated | Integrated |
| Residual Current Monitoring | Integrated | Integrated | Integrated | Integrated |
| PV Reverse Polarity Protection | Integrated | Integrated | Integrated | Integrated |
| Battery Reverse Polarity Protection | Integrated | Integrated | Integrated | Integrated |
| Anti-islanding Protection | Integrated | Integrated | Integrated | Integrated |
| AC Overcurrent Protection | Integrated | Integrated | Integrated | Integrated |
| AC Short Circuit Protection | Integrated | Integrated | Integrated | Integrated |

| Technical Data | GW10K-ETA-G20 | GW12K-ETA-G20 | GW15K-ETA-G20 | GW20K-ETA-G20 |
|----------------------------------|--------------------------------|--------------------------------|--------------------------------|--------------------------------|
| AC Overvoltage Protection | Integrated | Integrated | Integrated | Integrated |
| DC Switch | Integrated | Integrated | Integrated | Integrated |
| DC Surge Protection | Type II(Type I+II optional) |
| AC Surge Protection | Type II | Type II | Type II | Type II |
| Rapid Shutdown | Optional | Optional | Optional | Optional |
| AFCI | Optional | Optional | Optional | Optional |
| Remote Shutdown | Integrated | Integrated | Integrated | Integrated |
| General Data | | | | |
| Power Factor | 0.8 leading ... 0.8 lagging |
| Operating Temperature Range (°C) | -35~+60 | -35~+60 | -35~+60 | -35~+60 |
| Operating Environment | Indoor/Outdoor | Indoor/Outdoor | Indoor/Outdoor | Indoor/Outdoor |
| Relative Humidity | 0~100% | 0~100% | 0~100% | 0~100% |
| Max. Operating Altitude (m) | 4000 (>2000 derating) | 4000 (>2000 derating) | 4000 (>2000 derating) | 4000 (>2000 derating) |
| Cooling Method | Smart Fan Cooling | Smart Fan Cooling | Smart Fan Cooling | Smart Fan Cooling |

| Technical Data | GW10K-ETA-G20 | GW12K-ETA-G20 | GW15K-ETA-G20 | GW20K-ETA-G20 |
|-------------------------------|---|---|---|---|
| User Interface | LED, WLAN+APP | LED, WLAN+APP | LED, WLAN+APP | LED, WLAN+APP |
| Communication with BMS | CAN | CAN | CAN | CAN |
| Communication | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) |
| Communication Protocols | Modbus-RTU, Modbus-TCP | Modbus-RTU, Modbus-TCP | Modbus-RTU, Modbus-TCP | Modbus-RTU, Modbus-TCP |
| Weight (kg) | 34 | 34 | 34 | 34 |
| Dimension (W×H×D mm) | 800*340*270 | 800*340*270 | 800*340*270 | 800*340*270 |
| Noise Emission (dB) | ≤40 | ≤40 | ≤40 | ≤40 |
| Topology | Non-isolated | Non-isolated | Non-isolated | Non-isolated |
| Self-consumption at Night (W) | ≤10 | ≤10 | ≤10 | ≤10 |
| Ingress Protection Rating | IP66 | IP66 | IP66 | IP66 |
| DC Connector | MC4, VACONN Terminal | MC4, VACONN Terminal | MC4, VACONN Terminal | MC4, VACONN Terminal |
| AC Connector | VACONN Terminal | VACONN Terminal | VACONN Terminal | VACONN Terminal |

| Technical Data | GW10K-ETA-G20 | GW12K-ETA-G20 | GW15K-ETA-G20 | GW20K-ETA-G20 |
|----------------------------------|--|--|--|--|
| Environmental Category | 4K4H | 4K4H | 4K4H | 4K4H |
| Pollution Degree | III | III | III | III |
| Overvoltage Category | DC II / AC III |
| Protective Class | I | I | I | I |
| Storage Temperature (°C) | -40~+70 | -40~+70 | -40~+70 | -40~+70 |
| The Decisive Voltage Class (DVC) | Battery: C | Battery: C | Battery: C | Battery: C |
| | PV: C | PV: C | PV: C | PV: C |
| | AC: C | AC: C | AC: C | AC: C |
| | Com: A | Com: A | Com: A | Com: A |
| Mounting Method | Wall/Floor Mounted | Wall/Floor Mounted | Wall/Floor Mounted | Wall/Floor Mounted |
| Active Anti-islanding Method | SMS(Slip-mode frequency) +AFD ^{*4} | SMS(Slip-mode frequency) +AFD ^{*4} | SMS(Slip-mode frequency) +AFD ^{*4} | SMS(Slip-mode frequency) +AFD ^{*4} |
| Type of Electrical Supply System | three phase | three phase | three phase | three phase |
| Country of Manufacture | China | China | China | China |
| Certification | | | | |
| Grid Standard | | | | |

| Technical Data | GW10K-ETA-G20 | GW12K-ETA-G20 | GW15K-ETA-G20 | GW20K-ETA-G20 |
|-----------------------|--------------------------------------|----------------------|----------------------|----------------------|
| Safety Regulation | Please refer to the official website | | | |
| EMC | | | | |

| Technical Data | GW25K-ETA-G20 | GW29.999K-ETA-G20 | GW30K-ETA-G20 |
|---|----------------------|--------------------------|----------------------|
| Battery Side | | | |
| Battery Type | Li-Ion | Li-Ion | Li-Ion |
| Nominal Voltage (V) | 750 | 750 | 750 |
| Voltage Range (V) | 700-950 | 700-950 | 700-950 |
| Start-up Voltage (V) | 720 | 720 | 720 |
| Number of Battery Inputs | 1 | 1 | 1 |
| Max. Continuous Charging Current (A) | 33.3 | 40.0 | 40.0 |
| Max. Continuous Discharging Current (A) | 36.7 | 44.1 | 44.1 |
| Max. Charging Power (kW) | 25 | 30 | 30 |
| Max. Discharging Power (kW) | 27.5 | 33 | 33 |
| PV Side | | | |
| Max. Input Power (kW) | 50 | 60 | 60 |

| Technical Data | GW25K-ETA-G20 | GW29.999K-ETA-G20 | GW30K-ETA-G20 |
|--|----------------------|--------------------------|----------------------|
| Max. Input Voltage (V) ^{*1} | 1000 | 1000 | 1000 |
| MPPT Operating Voltage Range (V) ^{*2} | 120~950 | 120~950 | 120~950 |
| MPPT Voltage Range at Nominal Power (V) | 400~850 | 450~850 | 450~850 |
| Start-up Voltage (V) | 150 | 150 | 150 |
| Nominal Input Voltage (V) | 750 | 750 | 750 |
| Max. MPPT Current (A) | 21/21/42/42 | 21/21/42/42 | 21/21/42/42 |
| Max. MPPT Short Circuit Current (A) | 26/26/52/52 | 26/26/52/52 | 26/26/52/52 |
| Number of MPPTs | 4 | 4 | 4 |
| Number of Strings per MPPT | 1/1/2/2 | 1/1/2/2 | 1/1/2/2 |
| AC Side (On-Grid) | | | |
| Rated Power (kW) | 25 | 29.999 | 30 |
| Max. Power (kW) | 25 | 29.999 | 30 |
| Rated Apparent Power to Grid (kVA) | 25 | 29.999 | 30 |
| Rated Apparent Power from Grid (kVA) | 25 | 29.999 | 30 |

| Technical Data | GW25K-ETA-G20 | GW29.999K-ETA-G20 | GW30K-ETA-G20 |
|---|--|--|--|
| Max. Apparent Power to Grid (kVA) | 25 | 29.999 | 30 |
| Max. Apparent Power from Grid (kVA) | 55.2 | 55.2 | 55.2 |
| Nominal Voltage (V) | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE |
| Voltage Range (V) | 180 ~ 260 (According to local standard) | 180 ~ 260 (According to local standard) | 180 ~ 260 (According to local standard) |
| Nominal Frequency (Hz) | 50/60 | 50/60 | 50/60 |
| Frequency Range (Hz) | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 |
| Rated Current to Grid (A) | 37.9 at 380V 36.3 at 400V | 45.5 at 380V 43.5 at 400V | 45.5 at 380V 43.5 at 400V |
| Rated Current from Grid (A) | 37.9 at 380V 36.3 at 400V | 45.5 at 380V 43.5 at 400V | 45.5 at 380V 43.5 at 400V |
| Max. Current to Grid (A) | 37.9 at 380V 36.3 at 400V | 45.5 at 380V 43.5 at 400V | 45.5 at 380V 43.5 at 400V |
| Max. Current from Grid (A) | 80.0 | 80.0 | 80.0 |
| Max. Output Fault Current (Peak and Duration) (A) | 125@4μs | 125@4μs | 125@4μs |
| Inrush Current (Peak and Duration) (A) | 32.3@5ms | 32.3@5ms | 32.3@5ms |

| Technical Data | GW25K-ETA-G20 | GW29.999K-ETA-G20 | GW30K-ETA-G20 |
|---|--|---|--|
| THDi | <3% | <3% | <3% |
| Maximum Output Overcurrent Protection (A) | 125 | 125 | 125 |
| Type of Voltage | a.c. | a.c. | a.c. |
| Back-up Side | | | |
| Rated Output Apparent Power (kVA) | 25 | 30 | 30 |
| Max. Output Apparent Power (kVA) | Off-grid: 27.5(45.0, 10s), on-grid:55.2 | Off-grid: 33(45.0, 10s), on-grid: 55.2 | Off-grid: 33(45.0, 10s), on-grid:55.2 |
| Nominal Output Voltage (V) | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE |
| Nominal Output Frequency (Hz) | 50/60 | 50/60 | 50/60 |
| Frequency Range (Hz) | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 |
| Rated Output Current (A) | 37.9 at 380V 36.3 at 400V | 45.5 at 380V 43.5 at 400V | 45.5 at 380V 43.5 at 400V |
| Max. Output Current (A) ^{*3} | Off-grid: 50.0, on-grid: 80 | Off-grid: 50.0, on-grid: 80 | Off-grid: 50.0, on-grid: 80 |
| Max. Output Fault Current (Peak and Duration) (A) | 125@4μs | 125@4μs | 125@4μs |
| Inrush Current (Peak and Duration) (A) | 32.3@5ms | 32.3@5ms | 32.3@5ms |

| Technical Data | GW25K-ETA-G20 | GW29.999K-ETA-G20 | GW30K-ETA-G20 |
|-------------------------------------|----------------------|--------------------------|----------------------|
| Maximum Overcurrent Protection (A) | 125 | 125 | 125 |
| THDv (@Linear Load) | <3% | <3% | <3% |
| On/Off-grid Switching Time (ms) | <4 | <4 | <4 |
| Efficiency | | | |
| Max. Efficiency | 98.20% | 98.20% | 98.20% |
| European Efficiency | 97.40% | 97.40% | 97.40% |
| Max. Battery to AC Efficiency | 98.00% | 98.00% | 98.00% |
| Protection | | | |
| PV String Current Monitoring | Integrated | Integrated | Integrated |
| PV Insulation Resistance Detection | Integrated | Integrated | Integrated |
| Residual Current Monitoring | Integrated | Integrated | Integrated |
| PV Reverse Polarity Protection | Integrated | Integrated | Integrated |
| Battery Reverse Polarity Protection | Integrated | Integrated | Integrated |
| Anti-islanding Protection | Integrated | Integrated | Integrated |

| Technical Data | GW25K-ETA-G20 | GW29.999K-ETA-G20 | GW30K-ETA-G20 |
|----------------------------------|-----------------------------|-----------------------------|-----------------------------|
| AC Overcurrent Protection | Integrated | Integrated | Integrated |
| AC Short Circuit Protection | Integrated | Integrated | Integrated |
| AC Overvoltage Protection | Integrated | Integrated | Integrated |
| DC Switch | Integrated | Integrated | Integrated |
| DC Surge Protection | Type II(Type I+II optional) | Type II(Type I+II optional) | Type II(Type I+II optional) |
| AC Surge Protection | Type II | Type II | Type II |
| Rapid Shutdown | Optional | Optional | Optional |
| AFCI | Optional | Optional | Optional |
| Remote Shutdown | Integrated | Integrated | Integrated |
| General Data | | | |
| Power Factor | 0.8 leading ... 0.8 lagging | 0.8 leading ... 0.8 lagging | 0.8 leading ... 0.8 lagging |
| Operating Temperature Range (°C) | -35~+60 | -35~+60 | -35~+60 |
| Operating Environment | Indoor/Outdoor | Indoor/Outdoor | Indoor/Outdoor |
| Relative Humidity | 0~100% | 0~100% | 0~100% |
| Max. Operating Altitude (m) | 4000 (>2000 derating) | 4000 (>2000 derating) | 4000 (>2000 derating) |
| Cooling Method | Smart Fan Cooling | Smart Fan Cooling | Smart Fan Cooling |

| Technical Data | GW25K-ETA-G20 | GW29.999K-ETA-G20 | GW30K-ETA-G20 |
|-------------------------------|---|---|---|
| User Interface | LED, WLAN+APP | LED, WLAN+APP | LED, WLAN+APP |
| Communication with BMS | CAN | CAN | CAN |
| Communication | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) |
| Communication Protocols | Modbus-RTU, Modbus-TCP | Modbus-RTU, Modbus-TCP | Modbus-RTU, Modbus-TCP |
| Weight (kg) | 38 | 38 | 38 |
| Dimension (W×H×D mm) | 800*340*270 | 800*340*270 | 800*340*270 |
| Noise Emission (dB) | ≤45 | ≤45 | ≤45 |
| Topology | Non-isolated | Non-isolated | Non-isolated |
| Self-consumption at Night (W) | ≤10 | ≤10 | ≤10 |
| Ingress Protection Rating | IP66 | IP66 | IP66 |
| DC Connector | MC4, VACONN Terminal | MC4, VACONN Terminal | MC4, VACONN Terminal |
| AC Connector | VACONN Terminal | VACONN Terminal | VACONN Terminal |
| Environmental Category | 4K4H | 4K4H | 4K4H |
| Pollution Degree | III | III | III |

| Technical Data | GW25K-ETA-G20 | GW29.999K-ETA-G20 | GW30K-ETA-G20 |
|----------------------------------|--------------------------------------|---------------------------------|---------------------------------|
| Overvoltage Category | DC II / AC III | DC II / AC III | DC II / AC III |
| Protective Class | I | I | I |
| Storage Temperature (°C) | -40~+70 | -40~+70 | -40~+70 |
| The Decisive Voltage Class (DVC) | Battery: C | Battery: C | Battery: C |
| | PV: C | PV: C | PV: C |
| | AC: C | AC: C | AC: C |
| | Com: A | Com: A | Com: A |
| Mounting Method | Wall/Floor Mounted | Wall/Floor Mounted | Wall/Floor Mounted |
| Active Anti-islanding Method | SMS(Slip-mode frequency) +AFD*4 | SMS(Slip-mode frequency) +AFD*4 | SMS(Slip-mode frequency) +AFD*4 |
| Type of Electrical Supply System | three phase | three phase | three phase |
| Country of Manufacture | China | China | China |
| Certification | | | |
| Grid Standard | Please refer to the official website | | |
| Safety Regulation | | | |
| EMC | | | |

| Technical Data | GW5K-BTA-G20 | GW6K-BTA-G20 | GW8K-BTA-G20 | GW9.999K-BTA-G20 |
|-----------------------|---------------------|---------------------|---------------------|-------------------------|
| Battery Side | | | | |
| Battery Type | Li-Ion | Li-Ion | Li-Ion | Li-Ion |

| Technical Data | GW5K-BTA-G20 | GW6K-BTA-G20 | GW8K-BTA-G20 | GW9.999K-BTA-G20 |
|---|---------------------|---------------------|---------------------|-------------------------|
| Nominal Voltage (V) | 750 | 750 | 750 | 750 |
| Voltage Range (V) | 700-950 | 700-950 | 700-950 | 700-950 |
| Start-up Voltage (V) | 720 | 720 | 720 | 720 |
| Number of Battery Inputs | 1 | 1 | 1 | 1 |
| Max. Continuous Charging Current (A) | 6.7 | 8.1 | 10.7 | 13.4 |
| Max. Continuous Discharging Current (A) | 7.4 | 8.9 | 11.8 | 14.7 |
| Max. Charging Power (kW) | 5 | 6 | 8 | 10 |
| Max. Discharging Power (kW) | 5.5 | 6.6 | 8.8 | 11 |
| AC Side (On-Grid) | | | | |
| Rated Power (kW) | 5 | 6 | 8 | 9.999 |
| Max. Power (kW) | 5 | 6 | 8 | 9.999 |

| Technical Data | GW5K-BTA-G20 | GW6K-BTA-G20 | GW8K-BTA-G20 | GW9.999K-BTA-G20 |
|--------------------------------------|--|--|--|--|
| Rated Apparent Power to Grid (kVA) | 5 | 6 | 8 | 9.999 |
| Rated Apparent Power from Grid (kVA) | 5 | 6 | 8 | 9.999 |
| Max. Apparent Power to Grid (kVA) | 5 | 6 | 8 | 9.999 |
| Max. Apparent Power from Grid (kVA) | 43.5 | 43.5 | 43.5 | 43.5 |
| Nominal Voltage (V) | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE |
| Voltage Range (V) | 180 ~ 260 (According to local standard) |
| Nominal Frequency (Hz) | 50/60 | 50/60 | 50/60 | 50/60 |
| Frequency Range (Hz) | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 |
| Rated Current to Grid (A) | 7.6 at 380V 7.3 at 400V | 9.1 at 380V 8.7 at 400V | 12.2 at 380V 11.6 at 400V | 15.2 at 380V 14.5 at 400V |
| Rated Current from Grid (A) | 7.6 at 380V 7.3 at 400V | 9.1 at 380V 8.7 at 400V | 12.2 at 380V 11.6 at 400V | 15.2 at 380V 14.5 at 400V |
| Max. Current to Grid (A) | 7.6 at 380V 7.3 at 400V | 9.1 at 380V 8.7 at 400V | 12.2 at 380V 11.6 at 400V | 15.2 at 380V 14.5 at 400V |

| Technical Data | GW5K-BTA-G20 | GW6K-BTA-G20 | GW8K-BTA-G20 | GW9.999K-BTA-G20 |
|---|--|---------------------------------------|--|--|
| Max. Current from Grid (A) | 63.0 | 63.0 | 63.0 | 63.0 |
| Max. Output Fault Current (Peak and Duration) (A) | 46.7@4μs | 46.7@4μs | 46.7@4μs | 74.6@4μs |
| Inrush Current (Peak and Duration) (A) | 21.3@5ms | 21.3@5ms | 21.3@5ms | 25.4@5ms |
| THDi | <3% | <3% | <3% | <3% |
| Maximum Output Overcurrent Protection (A) | 46.7 | 46.7 | 46.7 | 74.6 |
| Type of Voltage | a.c. | a.c. | a.c. | a.c. |
| Back-up Side | | | | |
| Rated Output Apparent Power (kVA) | 5 | 6 | 8 | 10 |
| Max. Output Apparent Power (kVA) | Off-grid: 5.5 (10.0, 10s), on-grid: 43.5 | Off-grid: 6.6(12, 10s), on-grid: 43.5 | Off-grid: 8.8 (16.0, 10s), on-grid: 43.5 | Off-grid: 11(20.0, 10s), on-grid: 43.5 |
| Nominal Output Voltage (V) | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE |
| Nominal Output Frequency (Hz) | 50/60 | 50/60 | 50/60 | 50/60 |

| Technical Data | GW5K-BTA-G20 | GW6K-BTA-G20 | GW8K-BTA-G20 | GW9.999K-BTA-G20 |
|---|--------------------------------|-------------------------------|--------------------------------|-------------------------------|
| Frequency Range (Hz) | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 |
| Rated Output Current (A) | 7.6 at 380V 7.3 at 400V | 9.1 at 380V 8.7 at 400V | 12.2 at 380V 11.6 at 400V | 15.2 at 380V 14.5 at 400V |
| Max. Output Current (A)* ³ | Off-grid: 11.4, on-grid: 63 | Off-grid: 13.7, on-grid:63 | Off-grid: 18.2, on-grid: 63 | Off-grid: 22.8, on-grid:63 |
| Max. Output Fault Current (Peak and Duration) (A) | 46.7@4μs | 46.7@4μs | 46.7@4μs | 74.6@4μs |
| Inrush Current (Peak and Duration) (A) | 21.3@5ms | 21.3@5ms | 21.3@5ms | 25.4@5ms |
| Maximum Overcurrent Protection (A) | 46.7 | 46.7 | 46.7 | 74.6 |
| THDv (@Linear Load) | <3% | <3% | <3% | <3% |
| On/Off-grid Switching Time (ms) | <4 | <4 | <4 | <4 |
| Efficiency | | | | |
| Max. Efficiency | 98.00% | 98.00% | 98.00% | 98.10% |
| European Efficiency | 96.40% | 96.90% | 97.10% | 97.20% |
| CEC Efficiency | NA | NA | NA | NA |

| Technical Data | GW5K-BTA-G20 | GW6K-BTA-G20 | GW8K-BTA-G20 | GW9.999K-BTA-G20 |
|-------------------------------------|--------------------------------|--------------------------------|--------------------------------|--------------------------------|
| Max. Battery to AC Efficiency | 98.00% | 98.00% | 98.00% | 98.00% |
| Protection | | | | |
| Residual Current Monitoring | Integrated | Integrated | Integrated | Integrated |
| Battery Reverse Polarity Protection | Integrated | Integrated | Integrated | Integrated |
| Anti-islanding Protection | Integrated | Integrated | Integrated | Integrated |
| AC Overcurrent Protection | Integrated | Integrated | Integrated | Integrated |
| AC Short Circuit Protection | Integrated | Integrated | Integrated | Integrated |
| AC Overvoltage Protection | Integrated | Integrated | Integrated | Integrated |
| AC Surge Protection | Type II | Type II | Type II | Type II |
| Remote Shutdown | Integrated | Integrated | Integrated | Integrated |
| General Data | | | | |
| Power Factor | 0.8 leading ... 0.8 lagging |

| Technical Data | GW5K-BTA-G20 | GW6K-BTA-G20 | GW8K-BTA-G20 | GW9.999K-BTA-G20 |
|----------------------------------|---|---|---|---|
| Operating Temperature Range (°C) | -35~+60 | -35~+60 | -35~+60 | -35~+60 |
| Operating Environment | Indoor/Outdoor | Indoor/Outdoor | Indoor/Outdoor | Indoor/Outdoor |
| Relative Humidity | 0~100% | 0~100% | 0~100% | 0~100% |
| Max. Operating Altitude (m) | 4000 (>2000 derating) | 4000 (>2000 derating) | 4000 (>2000 derating) | 4000 (>2000 derating) |
| Cooling Method | Smart Fan Cooling | Smart Fan Cooling | Smart Fan Cooling | Smart Fan Cooling |
| User Interface | LED, WLAN+APP | LED, WLAN+APP | LED, WLAN+APP | LED, WLAN+APP |
| Communication with BMS | CAN | CAN | CAN | CAN |
| Communication | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) |
| Communication Protocols | Modbus-RTU, Modbus-TCP | Modbus-RTU, Modbus-TCP | Modbus-RTU, Modbus-TCP | Modbus-RTU, Modbus-TCP |
| Weight (kg) | 30 | 30 | 30 | 30 |
| Dimension (W×H×D mm) | 800*340*270 | 800*340*270 | 800*340*270 | 800*340*270 |
| Noise Emission (dB) | ≤35 | ≤35 | ≤35 | ≤35 |

| Technical Data | GW5K-BTA-G20 | GW6K-BTA-G20 | GW8K-BTA-G20 | GW9.999K-BTA-G20 |
|---------------------------------------|----------------------|----------------------|----------------------|-------------------------|
| Topology | Non-isolated | Non-isolated | Non-isolated | Non-isolated |
| Self-consumption at Night (W) | ≤10 | ≤10 | ≤10 | ≤10 |
| Conditional Short-circuit Current (A) | 6000 | 6000 | 6000 | 6000 |
| Ingress Protection Rating | IP66 | IP66 | IP66 | IP66 |
| DC Connector | MC4, VACONN Terminal | MC4, VACONN Terminal | MC4, VACONN Terminal | MC4, VACONN Terminal |
| AC Connector | VACONN Terminal | VACONN Terminal | VACONN Terminal | VACONN Terminal |
| Environmental Category | 4K4H | 4K4H | 4K4H | 4K4H |
| Pollution Degree | III | III | III | III |
| Overvoltage Category | DC II / AC III |
| Protective Class | I | I | I | I |
| Storage Temperature (°C) | -40~+70 | -40~+70 | -40~+70 | -40~+70 |
| The Decisive Voltage Class (DVC) | Battery: C | Battery: C | Battery: C | Battery: C |
| | AC: C | AC: C | AC: C | AC: C |
| | Com: A | Com: A | Com: A | Com: A |

| Technical Data | GW5K-BTA-G20 | GW6K-BTA-G20 | GW8K-BTA-G20 | GW9.999K-BTA-G20 |
|----------------------------------|--------------------------------------|---------------------------------|---------------------------------|---------------------------------|
| Mounting Method | Wall/Floor Mounted | Wall/Floor Mounted | Wall/Floor Mounted | Wall/Floor Mounted |
| Active Anti-islanding Method | SMS(Slip-mode frequency) +AFD*4 | SMS(Slip-mode frequency) +AFD*4 | SMS(Slip-mode frequency) +AFD*4 | SMS(Slip-mode frequency) +AFD*4 |
| Type of Electrical Supply System | three phase | three phase | three phase | three phase |
| Country of Manufacture | China | China | China | China |
| Certification | | | | |
| Grid Standard | Please refer to the official website | | | |
| Safety Regulation | | | | |
| EMC | | | | |

| Technical Data | GW10K-BTA-G20 | GW12K-BTA-G20 | GW15K-BTA-G20 | GW20K-BTA-G20 |
|-----------------------|----------------------|----------------------|----------------------|----------------------|
| Battery Side | | | | |
| Battery Type | Li-Ion | Li-Ion | Li-Ion | Li-Ion |
| Nominal Voltage (V) | 750 | 750 | 750 | 750 |
| Voltage Range (V) | 700-950 | 700-950 | 700-950 | 700-950 |
| Start-up Voltage (V) | 720 | 720 | 720 | 720 |

| Technical Data | GW10K-BTA-G20 | GW12K-BTA-G20 | GW15K-BTA-G20 | GW20K-BTA-G20 |
|---|----------------------|----------------------|----------------------|----------------------|
| Number of Battery Inputs | 1 | 1 | 1 | 1 |
| Max. Continuous Charging Current (A) | 13.4 | 16.1 | 20.1 | 26.7 |
| Max. Continuous Discharging Current (A) | 14.7 | 17.7 | 22.1 | 29.4 |
| Max. Charging Power (kW) | 10 | 12 | 15 | 20 |
| Max. Discharging Power (kW) | 11 | 13.2 | 16.5 | 22 |
| AC Side (On-Grid) | | | | |
| Rated Power (kW) | 10 | 12 | 15 | 20 |
| Max. Power (kW) | 10 | 12 | 15 | 20 |
| Rated Apparent Power to Grid (kVA) | 10 | 12 | 15 | 20 |
| Rated Apparent Power from Grid (kVA) | 10 | 12 | 15 | 20 |

| Technical Data | GW10K-BTA-G20 | GW12K-BTA-G20 | GW15K-BTA-G20 | GW20K-BTA-G20 |
|---|--|--|--|--|
| Max. Apparent Power to Grid (kVA) | 10 | 12 | 15 | 20 |
| Max. Apparent Power from Grid (kVA) | 43.5 | 43.5 | 43.5 | 43.5 |
| Nominal Voltage (V) | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE |
| Voltage Range (V) | 180 ~ 260 (According to local standard) |
| Nominal Frequency (Hz) | 50/60 | 50/60 | 50/60 | 50/60 |
| Frequency Range (Hz) | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 |
| Rated Current to Grid (A) | 15.2 at 380V 14.5 at 400V | 18.2 at 380V 17.4 at 400V | 22.8 at 380V 21.8 at 400V | 30.4 at 380V 29.0 at 400V |
| Rated Current from Grid (A) | 15.2 at 380V 14.5 at 400V | 18.2 at 380V 17.4 at 400V | 22.8 at 380V 21.8 at 400V | 30.4 at 380V 29.0 at 400V |
| Max. Current to Grid (A) | 15.2 at 380V 14.5 at 400V | 18.2 at 380V 17.4 at 400V | 22.8 at 380V 21.8 at 400V | 30.4 at 380V 29.0 at 400V |
| Max. Current from Grid (A) | 63.0 | 63.0 | 63.0 | 63.0 |
| Max. Output Fault Current (Peak and Duration) (A) | 74.6@4μs | 74.6@4μs | 83.3@4μs | 83.3@4μs |

| Technical Data | GW10K-BTA-G20 | GW12K-BTA-G20 | GW15K-BTA-G20 | GW20K-BTA-G20 |
|---|---|---|---|---|
| Inrush Current (Peak and Duration) (A) | 25.4@5ms | 25.4@5ms | 29.1@5ms | 29.1@5ms |
| THDi | <3% | <3% | <3% | <3% |
| Maximum Output Overcurrent Protection (A) | 74.6 | 74.6 | 83.3 | 83.3 |
| Type of Voltage | a.c. | a.c. | a.c. | a.c. |
| Back-up Side | | | | |
| Rated Output Apparent Power (kVA) | 10 | 12 | 15 | 20 |
| Max. Output Apparent Power (kVA)*6 | Off-grid: 11(20.0, 10s), on-grid: 43.5 | Off-grid: 13.2(24, 10s), on-grid: 43.5 | Off-grid: 16.5(30, 10s), on-grid: 43.5 | Off-grid: 22(30.0, 10s), on-grid: 43.5 |
| Nominal Output Voltage (V) | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE |
| Nominal Output Frequency (Hz) | 50/60 | 50/60 | 50/60 | 50/60 |
| Frequency Range (Hz) | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 |
| Rated Output Current (A) | 15.2 at 380V 14.5 at 400V | 18.2 at 380V 17.4 at 400V | 22.8 at 380V 21.8 at 400V | 30.4 at 380V 29.0 at 400V |
| Max. Output Current (A)*3 | Off-grid: 22.8, on-grid: 63 | Off-grid: 27.3, on-grid: 63 | Off-grid: 33.4, on-grid: 63 | Off-grid: 33.4, on-grid: 63 |

| Technical Data | GW10K-BTA-G20 | GW12K-BTA-G20 | GW15K-BTA-G20 | GW20K-BTA-G20 |
|---|----------------------|----------------------|----------------------|----------------------|
| Max. Output Fault Current (Peak and Duration) (A) | 74.6@4μs | 74.6@4μs | 83.3@4μs | 83.3@4μs |
| Inrush Current (Peak and Duration) (A) | 25.4@5ms | 25.4@5ms | 29.1@5ms | 29.1@5ms |
| Maximum Overcurrent Protection (A) | 74.6 | 74.6 | 83.3 | 83.3 |
| THDv (@Linear Load) | <3% | <3% | <3% | <3% |
| On/Off-grid Switching Time (ms) | <4 | <4 | <4 | <4 |
| Efficiency | | | | |
| Max. Efficiency | 98.10% | 98.10% | 98.10% | 98.10% |
| European Efficiency | 97.20% | 97.20% | 97.30% | 97.30% |
| CEC Efficiency | NA | NA | NA | NA |
| Max. Battery to AC Efficiency | 98.00% | 98.00% | 98.00% | 98.00% |
| MPPT Efficiency | NA | NA | NA | NA |
| Protection | | | | |

| Technical Data | GW10K-BTA-G20 | GW12K-BTA-G20 | GW15K-BTA-G20 | GW20K-BTA-G20 |
|-------------------------------------|--------------------------------|--------------------------------|--------------------------------|--------------------------------|
| Residual Current Monitoring | Integrated | Integrated | Integrated | Integrated |
| Battery Reverse Polarity Protection | Integrated | Integrated | Integrated | Integrated |
| Anti-islanding Protection | Integrated | Integrated | Integrated | Integrated |
| AC Overcurrent Protection | Integrated | Integrated | Integrated | Integrated |
| AC Short Circuit Protection | Integrated | Integrated | Integrated | Integrated |
| AC Overvoltage Protection | Integrated | Integrated | Integrated | Integrated |
| AC Surge Protection | Type II | Type II | Type II | Type II |
| Remote Shutdown | Integrated | Integrated | Integrated | Integrated |
| General Data | | | | |
| Power Factor | 0.8 leading ... 0.8 lagging |
| Operating Temperature Range (°C) | -35~+60 | -35~+60 | -35~+60 | -35~+60 |

| Technical Data | GW10K-BTA-G20 | GW12K-BTA-G20 | GW15K-BTA-G20 | GW20K-BTA-G20 |
|-----------------------------|---|---|---|---|
| Operating Environment | Indoor/Outdoor | Indoor/Outdoor | Indoor/Outdoor | Indoor/Outdoor |
| Relative Humidity | 0~100% | 0~100% | 0~100% | 0~100% |
| Max. Operating Altitude (m) | 4000 (>2000 derating) | 4000 (>2000 derating) | 4000 (>2000 derating) | 4000 (>2000 derating) |
| Cooling Method | Smart Fan Cooling | Smart Fan Cooling | Smart Fan Cooling | Smart Fan Cooling |
| User Interface | LED, WLAN+APP | LED, WLAN+APP | LED, WLAN+APP | LED, WLAN+APP |
| Communication with BMS | CAN | CAN | CAN | CAN |
| Communication | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) |
| Communication Protocols | Modbus-RTU, Modbus-TCP | Modbus-RTU, Modbus-TCP | Modbus-RTU, Modbus-TCP | Modbus-RTU, Modbus-TCP |
| Weight (kg) | 30 | 30 | 30 | 30 |
| Dimension (W×H×D mm) | 800*340*270 | 800*340*270 | 800*340*270 | 800*340*270 |
| Noise Emission (dB) | ≤35 | ≤35 | ≤40 | ≤40 |
| Topology | Non-isolated | Non-isolated | Non-isolated | Non-isolated |

| Technical Data | GW10K-BTA-G20 | GW12K-BTA-G20 | GW15K-BTA-G20 | GW20K-BTA-G20 |
|---------------------------------------|----------------------|----------------------|----------------------|----------------------|
| Self-consumption at Night (W) | ≤10 | ≤10 | ≤10 | ≤10 |
| Conditional Short-circuit Current (A) | 6000 | 6000 | 6000 | 6000 |
| Ingress Protection Rating | IP66 | IP66 | IP66 | IP66 |
| DC Connector | MC4, VACONN Terminal | MC4, VACONN Terminal | MC4, VACONN Terminal | MC4, VACONN Terminal |
| AC Connector | VACONN Terminal | VACONN Terminal | VACONN Terminal | VACONN Terminal |
| Environmental Category | 4K4H | 4K4H | 4K4H | 4K4H |
| Pollution Degree | III | III | III | III |
| Overvoltage Category | DC II / AC III |
| Protective Class | I | I | I | I |
| Storage Temperature (°C) | -40~+70 | -40~+70 | -40~+70 | -40~+70 |
| The Decisive Voltage Class (DVC) | Battery: C | Battery: C | Battery: C | Battery: C |
| | AC: C | AC: C | AC: C | AC: C |
| | Com: A | Com: A | Com: A | Com: A |

| Technical Data | GW10K-BTA-G20 | GW12K-BTA-G20 | GW15K-BTA-G20 | GW20K-BTA-G20 |
|----------------------------------|--------------------------------------|---------------------------------|---------------------------------|---------------------------------|
| Mounting Method | Wall/Floor Mounted | Wall/Floor Mounted | Wall/Floor Mounted | Wall/Floor Mounted |
| Active Anti-islanding Method | SMS(Slip-mode frequency) +AFD*4 | SMS(Slip-mode frequency) +AFD*4 | SMS(Slip-mode frequency) +AFD*4 | SMS(Slip-mode frequency) +AFD*4 |
| Type of Electrical Supply System | three phase | three phase | three phase | three phase |
| Country of Manufacture | China | China | China | China |
| Certification | | | | |
| Grid Standard | Please refer to the official website | | | |
| Safety Regulation | | | | |
| EMC | | | | |

| Technical Data | GW25K-BTA-G20 | GW29.999K-BTA-G20 | GW30K-BTA-G20 |
|--------------------------|----------------------|--------------------------|----------------------|
| Battery Side | | | |
| Battery Type | Li-Ion | Li-Ion | Li-Ion |
| Nominal Voltage (V) | 750 | 750 | 750 |
| Voltage Range (V) | 700-950 | 700-950 | 700-950 |
| Start-up Voltage (V) | 720 | 720 | 720 |
| Number of Battery Inputs | 1 | 1 | 1 |

| Technical Data | GW25K-BTA-G20 | GW29.999K-BTA-G20 | GW30K-BTA-G20 |
|---|--|--|--|
| Max. Continuous Charging Current (A) | 33.3 | 40.0 | 40.0 |
| Max. Continuous Discharging Current (A) | 36.7 | 44.1 | 44.1 |
| Max. Charging Power (kW) | 25 | 30 | 30 |
| Max. Discharging Power (kW) | 27.5 | 33 | 33 |
| AC Side (On-Grid) | | | |
| Rated Power (kW) | 25 | 29.999 | 30 |
| Max. Power (kW) | 25 | 29.999 | 30 |
| Rated Apparent Power to Grid (kVA) | 25 | 29.999 | 30 |
| Rated Apparent Power from Grid (kVA) | 25 | 29.999 | 30 |
| Max. Apparent Power to Grid (kVA) | 25 | 29.999 | 30 |
| Max. Apparent Power from Grid (kVA) | 55.2 | 55.2 | 55.2 |
| Nominal Voltage (V) | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE |
| Voltage Range (V) | 180 ~ 260 (According to local standard) | 180 ~ 260 (According to local standard) | 180 ~ 260 (According to local standard) |

| Technical Data | GW25K-BTA-G20 | GW29.999K-BTA-G20 | GW30K-BTA-G20 |
|---|------------------------------|------------------------------|------------------------------|
| Nominal Frequency (Hz) | 50/60 | 50/60 | 50/60 |
| Frequency Range (Hz) | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 |
| Rated Current to Grid (A) | 37.9 at 380V 36.3 at 400V | 45.5 at 380V 43.5 at 400V | 45.5 at 380V 43.5 at 400V |
| Rated Current from Grid (A) | 37.9 at 380V 36.3 at 400V | 45.5 at 380V 43.5 at 400V | 45.5 at 380V 43.5 at 400V |
| Max. Current to Grid (A) | 37.9 at 380V 36.3 at 400V | 45.5 at 380V 43.5 at 400V | 45.5 at 380V 43.5 at 400V |
| Max. Current from Grid (A) | 80.0 | 80.0 | 80.0 |
| Max. Output Fault Current (Peak and Duration) (A) | 125@4 μ s | 125@4 μ s | 125@4 μ s |
| Inrush Current (Peak and Duration) (A) | 32.3@5ms | 32.3@5ms | 32.3@5ms |
| THDi | <3% | <3% | <3% |
| Maximum Output Overcurrent Protection (A) | 125 | 125 | 125 |
| Type of Voltage | a.c. | a.c. | a.c. |
| Back-up Side | | | |
| Rated Output Apparent Power (kVA) | 25 | 30 | 30 |

| Technical Data | GW25K-BTA-G20 | GW29.999K-BTA-G20 | GW30K-BTA-G20 |
|---|---|---|---|
| Max. Output Apparent Power (kVA)*6 | Off-grid: 27.5(45.0, 10s), on-grid: 55.2 | Off-grid: 33(45.0, 10s), on-grid: 55.2 | Off-grid: 33(45.0, 10s), on-grid: 55.2 |
| Nominal Output Voltage (V) | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE | 220/380, 230/400, 3L/N/PE |
| Nominal Output Frequency (Hz) | 50/60 | 50/60 | 50/60 |
| Frequency Range (Hz) | 45~55 / 55~65 | 45~55 / 55~65 | 45~55 / 55~65 |
| Rated Output Current (A) | 37.9 at 380V 36.3 at 400V | 45.5 at 380V 43.5 at 400V | 45.5 at 380V 43.5 at 400V |
| Max. Output Current (A)*3 | Off-grid: 50.0, on-grid: 80 | Off-grid: 50.0, on-grid: 80 | Off-grid: 50.0, on-grid: 80 |
| Max. Output Fault Current (Peak and Duration) (A) | 125@4 μ s | 125@4 μ s | 125@4 μ s |
| Inrush Current (Peak and Duration) (A) | 32.3@5ms | 32.3@5ms | 32.3@5ms |
| Maximum Overcurrent Protection (A) | 125 | 125 | 125 |
| THDv (@Linear Load) | <3% | <3% | <3% |
| On/Off-grid Switching Time (ms) | <4 | <4 | <4 |
| Efficiency | | | |

| Technical Data | GW25K-BTA-G20 | GW29.999K-BTA-G20 | GW30K-BTA-G20 |
|-------------------------------------|-----------------------------|-----------------------------|-----------------------------|
| Max. Efficiency | 98.20% | 98.20% | 98.20% |
| European Efficiency | 97.40% | 97.40% | 97.40% |
| CEC Efficiency | NA | NA | NA |
| Max. Battery to AC Efficiency | 98.00% | 98.00% | 98.00% |
| Protection | | | |
| Residual Current Monitoring | Integrated | Integrated | Integrated |
| Battery Reverse Polarity Protection | Integrated | Integrated | Integrated |
| Anti-islanding Protection | Integrated | Integrated | Integrated |
| AC Overcurrent Protection | Integrated | Integrated | Integrated |
| AC Short Circuit Protection | Integrated | Integrated | Integrated |
| AC Overvoltage Protection | Integrated | Integrated | Integrated |
| AC Surge Protection | Type II | Type II | Type II |
| Remote Shutdown | Integrated | Integrated | Integrated |
| General Data | | | |
| Power Factor | 0.8 leading ... 0.8 lagging | 0.8 leading ... 0.8 lagging | 0.8 leading ... 0.8 lagging |

| Technical Data | GW25K-BTA-G20 | GW29.999K-BTA-G20 | GW30K-BTA-G20 |
|----------------------------------|---|---|---|
| Operating Temperature Range (°C) | -35~+60 | -35~+60 | -35~+60 |
| Operating Environment | Indoor/Outdoor | Indoor/Outdoor | Indoor/Outdoor |
| Relative Humidity | 0~100% | 0~100% | 0~100% |
| Max. Operating Altitude (m) | 4000 (>2000 derating) | 4000 (>2000 derating) | 4000 (>2000 derating) |
| Cooling Method | Smart Fan Cooling | Smart Fan Cooling | Smart Fan Cooling |
| User Interface | LED, WLAN+APP | LED, WLAN+APP | LED, WLAN+APP |
| Communication with BMS | CAN | CAN | CAN |
| Communication | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) | RS485, WiFi+LAN+Bluetooth, 4G+Bluetooth(Optional) |
| Communication Protocols | Modbus-RTU, Modbus-TCP | Modbus-RTU, Modbus-TCP | Modbus-RTU, Modbus-TCP |
| Weight (kg) | 32 | 32 | 32 |
| Dimension (W×H×D mm) | 800*340*270 | 800*340*270 | 800*340*270 |
| Noise Emission (dB) | ≤45 | ≤45 | ≤45 |
| Topology | Non-isolated | Non-isolated | Non-isolated |
| Self-consumption at Night (W) | ≤10 | ≤10 | ≤10 |

| Technical Data | GW25K-BTA-G20 | GW29.999K-BTA-G20 | GW30K-BTA-G20 |
|---------------------------------------|---------------------------------|---------------------------------|---------------------------------|
| Conditional Short-circuit Current (A) | 6000 | 6000 | 6000 |
| Ingress Protection Rating | IP66 | IP66 | IP66 |
| DC Connector | MC4, VACONN Terminal | MC4, VACONN Terminal | MC4, VACONN Terminal |
| AC Connector | VACONN Terminal | VACONN Terminal | VACONN Terminal |
| Environmental Category | 4K4H | 4K4H | 4K4H |
| Pollution Degree | IV | IV | IV |
| Overvoltage Category | DC II / AC III | DC II / AC III | DC II / AC III |
| Protective Class | I | I | I |
| Storage Temperature (°C) | -40~+70 | -40~+70 | -40~+70 |
| The Decisive Voltage Class (DVC) | Battery: C | Battery: C | Battery: C |
| | AC: C | AC: C | AC: C |
| | Com: A | Com: A | Com: A |
| Mounting Method | Wall/Floor Mounted | Wall/Floor Mounted | Wall/Floor Mounted |
| Active Anti-islanding Method | SMS(Slip-mode frequency) +AFD*4 | SMS(Slip-mode frequency) +AFD*4 | SMS(Slip-mode frequency) +AFD*4 |
| Type of Electrical Supply System | three phase | three phase | three phase |
| Country of Manufacture | China | China | China |

| Technical Data | GW25K-BTA-G20 | GW29.999K-BTA-G20 | GW30K-BTA-G20 |
|-------------------|--------------------------------------|-------------------|---------------|
| Certification | | | |
| Grid Standard | Please refer to the official website | | |
| Safety Regulation | | | |
| EMC | | | |

*1: When the input voltage ranges from 950V to 1000V, the inverter will enter the standby mode, and the voltage returns to 950V to enter the normal operation state.

*2: Please refer to the user manual for the MPPT Voltage Range at nominal Power.

*3: The Max. Output Current in off-grid operation accounts for a three-phase maximum 150% unbalanced capability.

*4: AFDPF: Active Frequency Drift with Positive Feedback, AQDPF: Active Q Drift with Positive Feedback.

9.2 Battery Technical Data

| Technical Data | GW5.1-BAT-D-G20 | GW8.3-BAT-D-G20 | GW5.1-BAT-D-G21 | GW8.3-BAT-D-G21 |
|---|----------------------------|-----------------|-----------------|-----------------|
| Rated Energy (kWh) | 5.12 | 8.32 | 5.12 | 8.32 |
| Usable Energy (kWh)*1 | 5 | 8 | 5 | 8 |
| Battery Type | LFP (LiFePO ₄) | | | |
| Operating Voltage Range (V) (single phase system) | 350~550 | | | |
| Operating Voltage Range (V) (three phase system) | 700~950 | | | |
| Max. Input Current (System) (A) | 12 | 19 | 12 | 19 |
| Max. Output Current (System) (A) | 13.2 | 21 | 13.2 | 21 |

| Technical Data | GW5.1-BAT-D-G20 | GW8.3-BAT-D-G20 | GW5.1-BAT-D-G21 | GW8.3-BAT-D-G21 |
|------------------------------------|------------------------|-----------------|-----------------|-----------------|
| Max. Input Power (System) (kW)*2 | 5 | 8 | 5 | 8 |
| Max. Output Power (System) (kW)*2 | 5 | 8 | 5 | 8 |
| Peak.Output Power (System) (kW)*2 | 7.5 @10s | 12 @10s | 7.5 @10s | 12 @10s |
| Charging Temperature Range (°C) | -18~55 | | 2~55 | |
| Discharging Temperature Range (°C) | -20~55 | | -20~55 | |
| Relative Humidity | 5-95% | | | |
| Max. Operating Altitude (m) | 4000 | | | |
| Noise Emission (dB) | ≤29 | | | |
| Communication | CAN | | | |
| Weight (kg) | 57.5±1 | 79±1 | 57.5±1 | 79±1 |
| Dimensions (W×H×D mm) | 800*326*270 | | | |
| Optional Function Configuration | heating | | / | |
| Ingress Protection | IP66 | | | |
| Storage Temperature (°C) | -20 ~55 | | | |
| Max. Storage time | 12 months (-20°C~35°C) | | | |
| | 6 months (35°C~45°C) | | | |
| Scalability | 6 pcs | | | |

| Technical Data | | GW5.1-BAT-D-G20 | GW8.3-BAT-D-G20 | GW5.1-BAT-D-G21 | GW8.3-BAT-D-G21 |
|----------------------------|----------------|---|-----------------|-----------------|-----------------|
| Mounting Method | | Floor stacked / Wall-mounted | | | |
| Cycle Life | | ≥6000 (25±2°C, 0.5C, 90%DOD, 70%EOL) | | | |
| Country of Manufacture | | China | | | |
| Standard and Certification | Safety | IEC62619, IEC60730, EN62477, IEC63056, IEC62040, CE, CEC, VDE2510 | | | |
| | EMC | CE, RCM | | | |
| | Transportation | UN38.3 ADR | | | |

*1: Test conditions, 100% DOD (cell 2.85~3.6V voltage range), 0.2P charge & discharge at 25±2 °C for battery system at the beginning of life. Usable energy is defined by its initial design value. Actual available energy may vary depending on charge/discharge rate, environmental conditions (e.g. temperature), transport and storage factors.

*2: Max. Input Power /Max. Output Power/Peak.Output Power derating will occur related to Temperature and SOC.

9.3 Smart Meter Technical Data

9.3.1 GM330

| technical parameter | | GM330 |
|---------------------|-------------------------|--|
| Measurement Range | Supported Grid Type | Three-phase, Split-phase, Single-phase |
| | voltage range L-L (Vac) | 172~817 |
| | voltage range L-N (Vac) | 100~472 |
| | Nominal Frequency (Hz) | 50/60 |
| | CT ratio | nA:5A |

| technical parameter | | GM330 |
|--------------------------|-------------------------------------|-------------------------|
| Communication Parameters | Communication Method | RS485 |
| | Communication Distance (m/ft) | 1000/3280 |
| Accuracy Parameters | voltage/current | Class 0.5 |
| | Active Energy | Class 0.5 |
| | Reactive Energy | Class 1 |
| General Parameters | Dimensions (WxHxD mm/in) | 72x85x72/2.83x3.35x2.83 |
| | Housing | 4-module |
| | Weight (g/lb) | 240/0.53 |
| | Mounting Method | DIN Rail |
| | User Interface | 4 LEDs, Reset Button |
| | Power Consumption (W) | ≤5 |
| Environmental Parameters | IP Rating | IP20 |
| | Operating Temperature Range (°C/°F) | -30~+70/-22~+158 |
| | Storage Temperature Range (°C/°F) | -30~70/-22~+158 |
| | Relative Humidity (non-condensing) | 0~95% |
| | Max. Operating Altitude (m/ft) | 3000/9842 |
| Certification Parameters | Certificates | UL1741/ANSI |

9.3.2 GMK330

| model | GMK330 |
|--------------------------|--------------------------------------|
| Measurement Range | |
| Supported Grid Types | 1P2W/3P3W/3P4W |
| Operating voltage (Vac)* | 3P4W: 90~264 L-N 3P3W: 90~264 L-L |

| | |
|----------------------------------|---------------------------|
| model | GMK330 |
| Frequency (Hz) | 50/60 |
| CT ratio | 120A: 40mA 200A: 50mA* |
| Number of CTs | 3 |
| Accuracy Parameters | |
| voltage/current | Class 0.5 |
| Active Energy | Class 0.5 |
| Reactive Energy | Class 1 |
| Communication Parameters | |
| Communication Method | RS485 |
| Communication Distance (m) | 1000 |
| General Parameters | |
| Dimensions (W*H*D mm) | 72*85*72 |
| Housing | 4-module |
| Weight (g) | 240 |
| Mounting Method | DIN Rail |
| User Interface | 4 LEDs, Reset Button |
| Power Consumption (W) | < 5 |
| Environmental Parameters | |
| IP Rating | IP20 |
| Operating Temperature Range (°C) | -30-+70 |

| | |
|------------------------------------|---------------|
| model | GMK330 |
| Storage Temperature Range (°C) | -30-+70 |
| Relative Humidity (non-condensing) | 0-95% |
| Max. Operating Altitude (m) | 3000 |

*Supports 1.1 times rated voltage connection.

*The standard CT for the meter has been uniformly changed to the 120A:40mA specification. Meters equipped with CTs of the 200A:50mA specification will no longer be sold after June 2026.

9.4 Smart Dongle Technical Data

9.4.1 WiFi/LAN Kit-20

| technical parameter | | WiFi/LAN Kit-20 |
|----------------------------------|---------------------------|---|
| Output Voltage (V) | | 5 |
| Power Consumption (W) | | ≤2 |
| Communication Interface | | USB |
| Communication Parameters | Ethernet | 10M/100Mbps Auto-negotiation |
| | Wireless | IEEE 802.11 b/g/n @2.4 GHz |
| | Bluetooth | Bluetooth V4.2 BR/EDR and Bluetooth LE Standard |
| Mechanical Parameters | Dimensions (W×H×D mm) | 48.3*159.5*32.1 |
| | Weight (g) | 82 |
| | Ingress Protection Rating | IP65 |
| | Mounting Method | USB Port Plug and Play |
| Operating Temperature Range (°C) | | -30~+60 |
| Storage Temperature Range (°C) | | -40~+70 |
| Relative Humidity | | 0-95% |
| Max. Operating Altitude (m) | | 4000 |

10 Appendix

10.1 FAQ

10.1.1 How to conduct auxiliary detection for smart meters/CT?

The meter detection function can detect whether the meter CT is connected correctly and the current operating status of the meter and CT.

1. Navigate to the detection page via **[Home] > [Settings] > [Meter/CT Auxiliary Detection]**.
2. Click Start Detection, wait for the detection to complete, and then view the detection results.

10.1.2 How to Upgrade the Device Version

Through firmware information, you can view or upgrade:

The inverter's DSP version, ARM version, communication module software version, battery's BMS version, DCDC version, etc.

- **Prompt Upgrade:**

When the user opens the App, an upgrade prompt pops up on the home page. The user can choose whether to upgrade. If they choose to upgrade, they can complete the upgrade by following the on-screen instructions.

- **Regular Upgrade:**

Go to **[Home] > [Settings] > [Firmware Information]** to enter the firmware information viewing interface.

Click "Check for Updates". If a new version is available, complete the upgrade by following the on-screen instructions.

- **Forced Upgrade:**

The App pushes upgrade information. The user must upgrade according to the prompts; otherwise, the App cannot be used. Complete the upgrade by following the

on-screen instructions.

Inverter Software Version Upgrade

- The inverter supports software upgrade via a USB drive.
- Before using a USB drive to upgrade the device, please contact the after-sales service center to obtain the software upgrade package and upgrade method.

10.2 Abbreviations

| Abbreviation | English Description | Chinese Description |
|--------------------|---|--|
| Ubatt | Battery Voltage Range | Battery voltage range |
| Ubatt,r | Nominal Battery Voltage | Nominal battery voltage |
| Ibatt,max (C/D) | Max. Charging Current Max. Discharging Current | Max. charging/discharging current |
| EC,R | Rated Energy | Rated energy |
| UDCmax | Max.Input Voltage | Max. Input Voltage |
| UMPP | MPPT Operating Voltage Range | MPPT voltage range |
| IDC,max | Max. Input Current per MPPT | Max. input current per MPPT string |
| ISC PV | Max. Short Circuit Current per MPPT | Max. short-circuit current per MPPT string |
| PAC,r | Nominal Output Power | Nominal output power |
| Sr (to grid) | Nominal Apparent Power Output to Utility Grid | Nominal Apparent Power Output to Utility Grid |
| Smax (to grid) | Max. Apparent Power Output to Utility Grid | Max. Apparent Power Output to Utility Grid |
| Sr (from grid) | Nominal Apparent Power from Utility Grid | Nominal apparent power purchased from utility grid |
| Smax (from grid) | Max. Apparent Power from Utility Grid | Max. apparent power purchased from utility grid |
| UAC,r | Nominal Output Voltage | Nominal output voltage |
| fAC,r | Nominal AC Grid Frequency | Nominal AC Grid Frequency |
| IAC,max(to grid) | Max. AC Current Output to Utility Grid | Max. AC Current Output to Utility Grid |
| IAC,max(from grid) | Max. AC Current From Utility Grid | Max. Current from Grid |

| Abbreviation | English Description | Chinese Description |
|----------------------|--|----------------------------------|
| P.F. | Power Factor | Power Factor |
| Sr | Back-up Nominal apparent power | Off-grid nominal apparent power |
| Smax | Max. Output Apparent Power (VA) Max. Output Apparent Power without Grid | Max. Apparent Power to Grid |
| IAC,max | Max. Output Current | Max. Current to Grid |
| UAC,r | Nominal Output Voltage | Max. output voltage |
| fAC,r | Nominal Output Frequency | Nominal output voltage frequency |
| Toperating | Operating Temperature Range | Operating Temperature Range |
| IDC,max | Max. Input Current | Max. input current |
| UDC | Input Voltage | Input voltage |
| UDC,r | DC Power Supply | DC input |
| UAC | Power Supply/AC Power Supply | Input voltage range/AC input |
| UAC,r | Power Supply/Input Voltage Range | Input voltage range/AC input |
| Toperating | Operating Temperature Range | Operating Temperature Range |
| Pmax | Max Output Power | Maximum Power |
| PRF | TX Power | Transmit power |
| PD | Power Consumption | Power consumption |
| PAC,r | Power Consumption | Power consumption |
| F (Hz) | Frequency | Frequency |
| ISC PV | Max. Input Short Circuit Current | Max. input short-circuit current |
| Udcmin-Udcmax | Range of input Operating Voltage | Operating Voltage range |
| UAC,rang(L-N) | Power Supply Input Voltage | Adapter input voltage range |
| U _{sys,max} | Max System Voltage | Max. system voltage |
| Haltitude,max | Max. Operating Altitude | Max. operating altitude |
| PF | Power Factor | Power Factor |
| THDi | Total Harmonic Distortion of Current | Current harmonic distortion |

| Abbreviation | English Description | Chinese Description |
|---------------------|---|----------------------------------|
| THDv | Total Harmonic Distortion of Voltage | Voltage harmonic distortion |
| C&I | Commercial & Industrial | Commercial & Industrial |
| SEMS | Smart Energy Management System | Smart Energy Management System |
| MPPT | Maximum Power Point Tracking | Maximum power point tracking |
| PID | Potential-Induced Degradation | Potential-induced degradation |
| Voc | Open-Circuit Voltage | open-circuit voltage |
| Anti PID | Anti-PID | Anti-PID |
| PID Recovery | PID Recovery | PID Recovery |
| PLC | Power-line Commucation | Power-line carrier communication |
| Modbus TCP/IP | Modbus Transmission Control / Internet Protocol | Modbus over TCP/IP |
| Modbus RTU | Modbus Remote Terminal Unit | Modbus over serial link |
| SCR | Short-Circuit Ratio | Short-circuit ratio |
| UPS | Uninterruptable Power Supply | Uninterruptible power supply |
| ECO mode | Economical Mode | Economic Mode |
| TOU | Time of Use | Time of use |
| ESS | Energy Stroage System | energy storage system |
| PCS | Power Conversion System | Power conversion system |
| RSD | Rapid shutdown | Rapid Shutdown |
| EPO | Emergency Power Off | Emergency Poweroff |
| SPD | Surge Protection Device | Lightning protection |
| ARC | zero injection/zero export Power Limit / Export Power Limit | Power Limit |
| DRED | Demand Response Enabling Device | Demand response enabling device |
| RCR | Ripple Control Receiver | - |
| AFCI | AFCI | AFCI DC arc-fault protection |
| GFCI | Ground Fault Circuit Interrupter | GFCI |

| Abbreviation | English Description | Chinese Description |
|--------------|----------------------------------|----------------------------------|
| RCMU | Residual Current Monitoring Unit | Residual current monitoring unit |
| FRT | Fault Ride Through | Fault ride-through |
| HVRT | High Voltage Ride Through | High voltage ride-through |
| LVRT | Low Voltage Ride Through | Low voltage ride-through |
| EMS | Energy Management System | Energy management system |
| BMS | Battery Management System | Battery management system |
| BMU | Battery Measure Unit | Battery measurement unit |
| BCU | Battery Control Unit | Battery control unit |
| SOC | State of Charge | State of charge |
| SOH | State of Health | State of health |
| SOE | State Of Energy | State of energy |
| SOP | State Of Power | State of power |
| SOF | State Of Function | State of function |
| SOS | State Of Safety | State of safety |
| DOD | Depth of discharge | depth of discharge |

10.3 Explanation of Terms

- **Definition of Overvoltage Categories**
 - **Overvoltage Category I:** Equipment connected to circuits where measures are taken to limit transient overvoltages to a suitably low level.
 - **Overvoltage Category II:** Energy-consuming equipment supplied from a fixed electrical installation. This category includes appliances, portable tools, and other household and similar loads. If special requirements for reliability and suitability of such equipment exist, Overvoltage Category III applies.
 - **Overvoltage Category III:** Equipment in fixed electrical installations where special requirements for reliability and suitability must be met. This includes switching devices in fixed installations and industrial equipment permanently connected to fixed electrical installations.
 - **Overvoltage Category IV:** Equipment used at the origin of the electrical installation. This includes meters and primary overcurrent protection devices, etc.
- **Definition of Damp Location Categories**

| Environmental Parameters | Level | | |
|--------------------------|-----------|-------------|------------|
| | 3K3 | 4K2 | 4K4H |
| Temperature Range | 0~+40°C | -33~+40°C | -33~+40°C |
| Humidity Range | 5% to 85% | 15% to 100% | 4% to 100% |

- **Definition of Environmental Categories:**
 - **Outdoor Inverter:** Ambient air temperature range from -25°C to +60°C, suitable for Pollution Degree 3 environments.
 - **Indoor Type II Inverter:** Ambient air temperature range from -25°C to +40°C, suitable for Pollution Degree 3 environments.
 - **Indoor Type I Inverter:** Ambient air temperature range from 0°C to +40°C, suitable for Pollution Degree 2 environments.
- **Definition of Pollution Degree Categories**
 - **Pollution Degree 1:** No pollution or only dry, non-conductive pollution.
 - **Pollution Degree 2:** Normally only non-conductive pollution occurs. Temporary conductivity caused by condensation must be expected occasionally.
 - **Pollution Degree 3:** Conductive pollution occurs, or dry non-conductive pollution becomes conductive due to condensation.
 - **Pollution Degree 4:** Persistent conductive pollution occurs, for example, due to conductive dust, rain, or snow.

10.4 Battery SN Code Meaning

*****2388*****



The 11th-14th digits

LXD10DSC0002

The 11th to 14th digits of the product SN code represent the production time code. The production date in the above image is 2023-08-08

- The 11th and 12th digits are the last two digits of the production year, e.g., 2023 is represented as 23;

- The 13th digit is the production month, e.g., August is represented as 8;
Details are as follows:

| | | | | |
|------------|---------|-----|-----|-----|
| Month | Jan-Sep | Oct | Nov | Dec |
| Month Code | 1~9 | A | B | C |

- The 14th digit is the production date, e.g., the 8th day is represented as 8;
Numbers are preferred for representation, e.g., 1~9 represent the 1st to 9th days,
A represents the 10th day, and so on. Among them, the letters I and O are not used
to avoid confusion. Details are as follows:

| | | | | | | | | | |
|----------------|---|---|---|---|---|---|---|---|---|
| Production Day | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
| Code | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |

| | | | | | | | | | |
|-----------------|----|----|----|----|----|----|----|----|----|
| Production Date | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 |
| Code | A | B | C | D | E | F | G | H | J |

| | | | | | | | | | |
|-----------------|----|----|----|----|----|----|----|----|----|
| Production Date | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 |
| Code | M | N | P | Q | R | S | T | U | V |

11 Contact Information

GoodWe Technologies Co., Ltd.
90 Zijin Road, Suzhou New District, China
400-998-1212
www.goodwe.com
service@goodwe.com